

Allen Bradley Ethernet IP(Controllogix, Compactlogix)

(Support Allen Bradley ControlLogix, CompactLogix series PLC)

HMI Factory Setting:

Controller IP Address: 192.168.0.1

Controller COM Port: 44818 ([Note 4](#))

Controller Station Number: 0 (Slot Number) ([Note 5](#))

Control Area / Status Area: None / None

Connection

Standard Jumper Cable / Network Cable without jumper (Auto-detected by HMI)

Definition of PLC Read/Write Address

a. Registers

Type	Format	Read/Write Range	Data Length	Note
	File No.(f) Word No.(n)			
SINT Variable	SINTf:n	SINT0:0 – SINT999:65534	Byte	1
INT Variable	INTf:n	INT0:0 – INT999:65535	Word	
DINT Variable	DINTf:n	DINT0:0 – DINT999:65535	Double Word	
BOOL Variable	BOOLf:n	BOOL0:0 – BOOL999:65504	Double Word	2
REAL Variable	REALf:n	REAL0:0 – REAL999:65535	Double Word	

b. Contacts

Type	Format	Read/Write Range	Note
	File No.(f) Word No.(n) Bit No.(b)		
SINT Variable	SINTf:n/b	SINT0:0/0 – SINT999:65535/7	
INT Variable	INTf:n/b	INT0:0/0 – INT999:65535/15	
DINT Variable	DINTf:n/b	DINT0:0/0 – DINT999:65535/31	
BOOL Variable	BOOLf:n	BOOL0:0 – BOOL999:65535	

 **NOTE**

- 1) **SINTf:n** : n must be an even number.
- 2) **BOOLf:n** : n must be the multiple of 32.
- 3) PLC IP address must be set first on RSLogix 5000 software and downloaded to PLC; otherwise PLC IP address can not be read. For detailed information about the setting methods, please refer to RSLogix 5000 software user manual.
- 4) Please do not change the COM port setting.
- 5) In this driver, PLC station number represents PLC slot number.