# YASKAWA SIO UDP PLC

### HMI Factory Setting:

Controller IP Address: 192.168.0.1

Controller COM Port: 10000

Controller Station Number: 1

Control Area / Status Area: MWO/MW10

# Connection

Standard Jumper Cable / Network Cable without jumper (Auto-detected by HMI)

#### **Definition of PLC Read/Write Address**

#### a. Registers

Туре	Format Word No.(n)	Read/Write Range	Data Length	Note
Holding Register	MWn	<b>MW</b> 0 – <b>MW</b> 65534	Word	
Input Register	IWn	IWO – IWFFFF	Word	Hexadecimal, <u>1</u>
Coil	MBn	<b>MB</b> 0 – <b>MB</b> 65534	Word	
Input Relay	IBn	IBO – IBFFFF	Word	Hexadecimal, <mark>2</mark>
System Register	SWn	<b>SW</b> 0 – <b>SW</b> 8191	Word	
Output Register	OWn	owo – owffff	Word	Hexadecimal, <u>3</u>
C Register	CWn	<b>CW</b> 0 – <b>CW</b> 16383	Word	Read Only

# b. Contacts

Туре	Format Bit No.(b)	Read/Write Range	Note
Coil	MBn.b	<b>MB</b> 0.0 – <b>MB</b> 65534.F	Bit is Hexadecimal
Input Relay	lBn.b	<b>IB</b> 0.0 – <b>IB</b> FFF.F	Hexadecimal, <u>4</u>
System Register	SBn.b	<b>SB</b> 0.0 – <b>SB</b> 8191.F	Bit is Hexadecimal
Output Register	<b>OB</b> n.b	<b>OB</b> 0.0 – <b>OB</b> FFFF.F	Hexadecimal

#### 

- 1) Register IW9000~ IWFFFF is Read Only.
- 2) Register **IB**9000~ **IB**FFFF is Read Only.
- 3) Register **OW**9000~ **OW**FFFF is Read Only.
- 4) Contact **IB**9000.0~ **IB**FFFF.F is Read Only.