

## Industrial Automation Headquarters

**Delta Electronics, Inc.**  
 Taoyuan Technology Center  
 No.18, Xinglong Rd., Taoyuan City,  
 Taoyuan County 33068, Taiwan  
 TEL: 886-3-362-6301 / FAX: 886-3-371-6301

## Asia

**Delta Electronics (Jiangsu) Ltd.**  
 Wujiang Plant 3  
 1688 Jiangxing East Road,  
 Wujiang Economic Development Zone  
 Wujiang City, Jiang Su Province, P.R.C. 215200  
 TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290

**Delta Greentech (China) Co., Ltd.**  
 238 Min-Xia Road, Pudong District,  
 Shanghai, P.R.C. 201209  
 TEL: 86-21-58635678 / FAX: 86-21-58630003

**Delta Electronics (Japan), Inc.**  
 Tokyo Office  
 2-1-14 Minato-ku Shibadaimon,  
 Tokyo 105-0012, Japan  
 TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

**Delta Electronics (Korea), Inc.**  
 1511, Byucksan Digital Valley 6-cha, Gasan-dong,  
 Geumcheon-gu, Seoul, Korea, 153-704  
 TEL: 82-2-515-5303 / FAX: 82-2-515-5302

**Delta Electronics Int'l (S) Pte Ltd.**  
 4 Kaki Bukit Ave 1, #05-05, Singapore 417939  
 TEL: 65-6747-5155 / FAX: 65-6744-9228

**Delta Electronics (India) Pvt. Ltd.**  
 Plot No 43 Sector 35, HSIIIDC  
 Gurgaon, PIN 122001, Haryana, India  
 TEL : 91-124-4874900 / FAX : 91-124-4874945

## Americas

**Delta Products Corporation (USA)**  
 Raleigh Office  
 P.O. Box 12173, 5101 Davis Drive,  
 Research Triangle Park, NC 27709, U.S.A.  
 TEL: 1-919-767-3800 / FAX: 1-919-767-8080

**Delta Greentech (Brasil) S.A.**  
 Sao Paulo Office  
 Rua Itapeva, 26 - 3° andar Edifício Itapeva One-Bela Vista  
 01332-000-São Paulo-SP-Brazil  
 TEL: 55 11 3568-3855 / FAX: 55 11 3568-3865

## Europe

**Deltronics (The Netherlands) B.V.**  
 Eindhoven Office  
 De Witbogt 20, 5652 AG Eindhoven, The Netherlands  
 TEL: 31-40-2592850 / FAX: 31-40-2592851

DVP-0051720-03

\*We reserve the right to change the information in this manual without prior notice.



# DVP201/202/211LC-SL Load Cell Module Operation Manual

# DVP201/202/211LC-SL

## Load Cell Module Operation Manual

### Revision History

| Version         | Revision  | Date       |
|-----------------|---|------------|
| 1 <sup>st</sup> | The first version was published.  | 2014/09/26 |
| 2 <sup>nd</sup> | <ol style="list-style-type: none"><li>1. CH1: update resolution information</li><li>2. CH2: update indicator information</li><li>3. CH4: add CR#20-21, CR#95-98, CR#106-143 and update CR#2, CR#7, CR#27-28, CR#48-49, CR#52-53, CR#104-105, and CR#109</li></ol> | 2019/02/21 |
| 3 <sup>rd</sup> | 1.CH4:Add section 4.3.6, 4.3.7 and 4.3.8  | 2021/08/11 |



# DVP201/202/211LC-SL Load Cell Module

## Operation Manual

### Table of Contents

#### Chapter 1 Introduction

|     |                                   |     |
|-----|-----------------------------------|-----|
| 1.1 | Principle of a Load Cell.....     | 1-2 |
| 1.2 | Introduction of a Load Cell ..... | 1-2 |
| 1.3 | Functional Specifications .....   | 1-2 |

#### Chapter 2 Dimensions and Profile

|     |                                    |     |
|-----|------------------------------------|-----|
| 2.1 | Dimensions .....                   | 2-2 |
| 2.2 | Profile.....                       | 2-2 |
| 2.3 | Arrangement of the Terminals ..... | 2-3 |
| 2.4 | Description of the Indicators..... | 2-3 |

#### Chapter 3 Installation and Wiring

|       |   |     |
|-------|---|-----|
| 3.1   | Installation.....   | 3-2 |
| 3.1.1 | Connecting a Load Cell Module to a DVP-SV series PLC .....                | 3-2 |
| 3.1.2 | Installing a DVP-SV series PLC and a Load Cell Module on a DIN rail ..... | 3-2 |
| 3.2   | Communication.....  | 3-3 |
| 3.3   | External Wiring .....   | 3-4 |
| 3.4   | Selecting a Load Cell Sensor.....   | 3-6 |

#### Chapter 4 Control Registers

|       |  |      |
|-------|--|------|
| 4.1   | Table of Control Registers.....                          | 4-2  |
| 4.2   | Descriptions of the Control Registers .....              | 4-10 |
| 4.3   | Descriptions of Functions .....                          | 4-15 |
| 4.3.1 | Measuring a Net Weight .....                             | 4-15 |
| 4.3.2 | Stability Check .....                                    | 4-15 |
| 4.3.3 | Determining Zero.....                                    | 4-16 |
| 4.3.4 | Filtering out Weights .....                              | 4-16 |
| 4.3.5 | Correspondence between Current Outputs and Weights ..... | 4-17 |
| 4.3.6 | Zero Tracking .....                                      | 4-18 |
| 4.3.7 | Weight Updates .....                                     | 4-18 |
| 4.3.8 | Output Values Set For Y Points.....                      | 4-18 |

**Chapter 5 Making Adjustment**

5.1 Steps in Adjusting Points ..... 5-3  
5.2 Example 1 ..... 5-4  
5.3 Example 2 ..... 5-5

# 1

## Chapter 1 Introduction

### Table of Contents

|     |                                   |     |
|-----|-----------------------------------|-----|
| 1.1 | Principle of a Load Cell.....     | 1-2 |
| 1.2 | Introduction of a Load Cell ..... | 1-2 |
| 1.3 | Functional Specifications .....   | 1-2 |

## 1

Thanks for using the load cell module DVP201/202/211LC-SL. To ensure that the product is correctly installed and operated, users need to read the operation manual carefully before they use DVP201/202/211LC-SL.

- ✓ The operation manual provides functional specifications, and introduces installation, basic operation and setting, and the usage of DVP201/202/211LC-SL.
- ✓ DVP201/202/211LC-SL is an OPEN-TYPE device. It should be installed in a control cabinet free of airborne dust, humidity, electric shock and vibration. To prevent non-maintenance staff from operating DVP201/202/211LC-SL, or to prevent an accident from damaging DVP201/202/211LC-SL, the control cabinet in which DVP201/202/211LC-SL is installed should be equipped with a safeguard. For example, the control cabinet in which DVP201/202/211LC-SL is installed can be unlocked with a special tool or key. DO NOT touch any terminal when DVP201/202/211LC-SL is powered up.
- ✓ In order to prevent the product from being damaged, or prevent staff from being hurt, users need to read the operation manual carefully, and follow the instructions in the manual.

## 1.1 Principle of a Load Cell

If a metallic material undergoes tension or strain, it will become thin, and its electrical impedance will increase. If a metallic material is compressed, its electrical impedance will become small. A strain gauge adopting this principle is called a load cell. Such sensing device is able to convert physical pressure into electrical signals, and therefore it is widely used on occasions on which loads, tension and pressure need to be converted into electrical signals.

## 1.2 Introduction of a Load Cell

A load cell module provides 4-wire or 6-wire load cells with various eigenvalues. Therefore, its response time can be adjusted according to users' requirements. On this basis, the requirements of load application markets can be easily met. Besides, a DVP series PLC\* can read data in a load cell module or write data to a load cell module by means of the instruction FROM/TO.

\*: DVP-SV series PLCs, DVP-EH2-L series PLCs, DVP-SA2 series PLCs, and DVP-SX2 series PLCs support left-side extension modules.

## 1.3 Functional Specifications

| DVP201/202/211LC-SL                        |  |
|--|--|
| Load cell module                           | Voltage output                               |
| Rated supply voltage/Power consumption     | 24 V DC (-15 to +20%)/5 W                    |
| Static minimum/maximum voltage             | 20.4 V/28.8 V DC                             |
| Dynamic minimum/maximum voltage            | 18.5 V/30.2 V DC                             |
| Maximum current consumption                | 150 mA                                       |
| Input signal range                         | ±200 mV DC                                   |
| Sensibility                                | +5 V DC +/-5%                                |
| Resolution                                 | Data output: 32 bits                         |
| Highest precision                          | 0.04%  |
| Communication interface                    | RS-232, RS-485                               |
| Applicable sensor type                     | 4-wire or 6-wire load cell                   |
| Expanding a temperature coefficient        | ≤ ± 20 ppm/K v. E                            |
| Reducing a temperature coefficient to zero | ≤ ± 0.1 μV/K                                 |
| Linearity error                            | ≤ 0.015%                                     |
| Response time                              | 2.5, 10, 16, 20, 50, 60, 100, 200, and 400ms |
| Eigenvalue applicable to a load cell       | 0~1, 0~2, 0~4, 0~6, 0~20, 0~40 and 0~80 mV/V |

| DVP201/202/211LC-SL                          |   |
|--|---|
| Load cell module                             | Voltage output  |
| Maximum distance for connecting a load cell  | 100 meters  |
| Maximum output current                       | 5 V DC * 300 mA   |
| Allowable load                               | 40~4,010 $\Omega$   |
| Averaging weights                            | 100   |
| Common-mode rejection ratio (CMRR @50/60 Hz) | $\geq 100$ dB   |
| Isolation                                    | Between a digital circuit and the ground: 500 V AC<br>Between an analog circuit and the ground: 500 V AC<br>Between an analog circuit and a digital circuit: 500 V AC |
| Connecting to a DVP series PLC               | Load cell modules can be connected to the left side of a PLC. The modules connected to a PLC are numbered from 100 to 107 according to the closeness to the PLC.      |
| Operation/Storage                            | Operation: 0~55°C (temperature), 5~95% (humidity), pollution degree 2<br>Storage: -25~70°C (temperature), 5~95% (humidity)  |
| Vibration/Shock resistance                   | International standards: IEC 61131-2, IEC 68-2-6 (TEST Fc)/IEC 61131-2 & IEC 68-2-27 (TEST Ea)  |

|                          | DVP211LC-SL                                   |  |
|--------------------------|---|--|
|                          | Electrical specifications for input terminals | Electrical specifications for output terminals |
| Input/Output terminal    | X0, X1  | Y0, Y1, Y2, Y3                                 |
| Type                     | Digital input                                 | Transistor                                     |
| Form                     | DC (sinking or sourcing)                      | --   |
| Specifications           | Input current: 24 V DC, 5 mA                  | Voltage specifications: 5~30 V DC #1           |
| Input impedance          | 4.7 K $\Omega$                                | --   |
| Maximum switch frequency | 10 kHz  | 1 kHz  |
| Action level             | Off $\rightarrow$ On                          | > 15 V DC                                      |
|                          | On $\rightarrow$ Off                          | < 5 V DC                                       |
| Response time            | Off $\rightarrow$ On                          | < 20 $\mu$ s                                   |
|                          | On $\rightarrow$ Off                          | < 50 $\mu$ s                                   |
| Maximum load             | Resistive load                                | 0.5 A/output (4 A/COM)#2                       |
|                          | Inductive load                                | 15 W (30 V DC)                                 |
|                          | Bulb  | 2.5 W (30 V DC)                                |

Note: In order to meet DIN 1319-1, an error needs to be less than or equal to 0.05% at 20 °C + 10 K.

#1: UP and ZP should be connected to a 24 V DC power supply. The current that an output terminal consumes is approximately 1 mA.

#2: In an NPN mode, ZP is used. In a PNP mode, UP is used.



**MEMO**

1



# 2


## Chapter 2 Dimensions and Profile

### Table of Contents

|     |                                    |     |
|-----|------------------------------------|-----|
| 2.1 | Dimensions .....                   | 2-2 |
| 2.2 | Profile.....                       | 2-2 |
| 2.3 | Arrangement of the Terminals.....  | 2-3 |
| 2.4 | Description of the Indicators..... | 2-3 |


## 2.1 Dimensions

2



Unit: mm

## 2.2 Profile



- |  |   |
|--|---|
| 1. Mounting hole                                       | 2. Mounting groove (35mm)   |
| 3. Extension port                                      | 4. I/O module clip  |
| 5. Status indicator (refer to section 2.4 for details) | 6. Functional status indicator (refer to section 2.4 for details) |
| 7. I/O terminals                                       | 8. RS-232 port  |
| 9. DIN rail clip                                       | 10. RS-485 port   |
| 11. Power input  |   |

## 2.3 Arrangement of the Terminals

|                    |      |      |      |      |      |     |   |   |
|--------------------|------|------|------|------|------|-----|---|---|
| EXC+               | EXC- | SIG+ | SIG- | SEN+ | SEN- | SHD | • | • |
| <b>DVP201LC-SL</b> |      |      |      |      |      |     |   |   |

|                    |      |      |      |      |      |     |   |   |      |      |      |      |      |      |     |   |   |
|--------------------|------|------|------|------|------|-----|---|---|------|------|------|------|------|------|-----|---|---|
| EXC+               | EXC- | SIG+ | SIG- | SEN+ | SEN- | SHD | • | • | EXC+ | EXC- | SIG+ | SIG- | SEN+ | SEN- | SHD | • | • |
| <b>DVP202LC-SL</b> |      |      |      |      |      |     |   |   |      |      |      |      |      |      |     |   |   |

|                    |      |      |      |      |      |     |     |     |     |    |    |    |    |    |    |    |    |
|--------------------|------|------|------|------|------|-----|-----|-----|-----|----|----|----|----|----|----|----|----|
| EXC+               | EXC- | SIG+ | SIG- | SEN+ | SEN- | SHD | AO+ | AO- | S/S | X0 | X1 | UP | ZP | Y0 | Y1 | Y2 | Y3 |
| <b>DVP211LC-SL</b> |      |      |      |      |      |     |     |     |     |    |    |    |    |    |    |    |    |

## 2.4 Description of the Indicators

| Name                      | Color  | Function  |
|---------------------------|--------|---|
| POWER indicator           | Green  | Displaying power  |
| RUN indicator             | Green  | Displaying the status of the module                                     |
| ERROR indicator           | Red    | Displaying an error   |
| L.V indicator             | Red    | Showing that the voltage of the an external power is low                |
| LOOP indicator            | Green  | Loop control  |
| MOTION indicator          | Orange | Showing that measurement is stable                                      |
| X0 indicator/X1 indicator | Red    | Showing that X0/X1 is On/Off  |
| Y0~3 indicator            | Red    | Showing that Y0/Y1/Y2/Y3 is On/Off                                      |
| NET indicator             | Orange | Net/Gross weight indicator  |
| ZERO indicator            | Orange | Once the weight value is in the zero point range, this indicator is ON. |
| MAX indicator             | Orange | Maximum weight indicator  |

2

**MEMO**

2



# 3

## Chapter 3 Installation and Wiring

### Table of Contents


|       |   |     |
|-------|---|-----|
| 3.1   | Installation .....  | 3-2 |
| 3.1.1 | Connecting a Load Cell Module to a DVP-SV series PLC .....                | 3-2 |
| 3.1.2 | Installing a DVP-SV series PLC and a Load Cell Module on a DIN rail ..... | 3-2 |
| 3.2   | Communication.....  | 3-3 |
| 3.3   | External Wiring .....   | 3-4 |
| 3.4   | Selecting a Load Cell Sensor.....   | 3-6 |

### 3.1 Installation

#### 3.1.1 Connecting a Load Cell Module to a DVP-SV series PLC


- Pull the I/O module clips on a DVP-SV series PLC. Insert the points in the corner of a load cell module into the four holes in the DVP-SV series PLC. Please see step ① in the figure below.
- Press the I/O module clips on the DVP-SV series PLC, and make sure that the load cell module is tightly connected to the DVP-SV series PLC. Please see step ② in the figure below.

3



#### 3.1.2 Installing a DVP-SV series PLC and a Load Cell Module on a DIN rail


- Please use a 35 mm DIN rail.
- Pull the DIN rail clips on a DVP-SV series PLC and a load cell module. Install the DVP-SV series PLC and the load cell module on the DIN rail.
- Press the DIN rail clips on the DVP-SV series PLC. Please see the figure below.



### 3.2 Communication


- Please wire a load cell module according to the definitions of the pins in a communication connector.

| PC COM Port<br>9 PIN D-SUB female |   | ↔ | DVP211LC COM Port<br>8 PIN MINI DIN |     |
|-----------------------------------|---|---|-------------------------------------|-----|
| Rx                                | 2 | ↔ | 5                                   | Tx  |
| Tx                                | 3 | ↔ | 4                                   | Rx  |
| GND                               | 5 | ↔ | 8                                   | GND |
|                                   | 7 |   | 1,2                                 | 5V  |
|                                   | 8 |   |                                     |     |
|                                   | 1 |   |                                     |     |
|                                   | 4 |   |                                     |     |
|                                   | 6 |   |                                     |     |



3


- There are 2 communication interfaces in a load cell module which can communicate with a PC or other devices. COM1 is an RS-232 port, and COM2 is an RS-485 port. Both ports meet the standard MODBUS protocol. A PC can directly communicate with a load cell module through COM1.
- Delta power supply modules are highly recommended.






### 3.3 External Wiring

3



- Multiple load cells connected in parallel are connected to a single load cell module.



Note 1: Please connect  $\oplus$  on a power supply module and  $\oplus$  on the load cell module to a system ground, and then ground the system ground or connect the system ground to a distribution box.

Note 2: If multiple load cells are connected in parallel, the total impedance should be greater than 40  $\Omega$ .

### 3.4 Selecting a Load Cell Sensor

1. Exciting voltage:

An excitation voltage is external power provided for a load cell sensor. The maximum voltage that a sensor can accept is specified in the specifications for the sensor. The exciting voltage that a load cell module provides is +5 V, and therefore a sensor which can accept a voltage greater than 5 V can be used.

2. Eigenvalue

A load cell sensor uses a bridge circuit. If a load cell is under pressure, SIG+ and SIG- will output voltages which are in proportion to force. An eigenvalue determines the characteristics of the output of a load cell sensor. The unit used is mV/V. If a load cell receives external force, it will output low voltage.

Output a sensor:  $(\text{Force}/\text{Maximum rated load}) \times (\text{Exciting voltage} \times \text{Eigenvalue})$

Example: The eigenvalue of a sensor is 2 mV/V, and the maximum rated load of the sensor is 10 kg. The voltage provided by a module is 5 V. The voltage to which the maximum rated load corresponds is 10 mV. If the load of the sensor is 1 kg, the voltage that the sensor outputs will be 1 mV. The eigenvalue that the module can support is 80 mV/V. The sensors whose eigenvalues are less than 80 mV/V can be used.

3. Maximum rated load

When users select a load cell module, they have to consider factors such as loads, tares, vibrations, and shocks. The closer the load on a load cell sensor is to the maximum rated load specified in the specifications for the load cell sensor, the more accurately the load is measured.

4. Four-wire configuration/Six-wire configuration

There are two ways to wire a load cell sensor. They are a four-wire configuration and a six-wire configuration. A load cell module provides power for a load cell sensor by means of EXC+/EXC-. However, there is impedance between the load cell module and the sensor. The voltage that the sensor actually receives is less than the voltage provided by the module. The output terminals SIG+ and SIG- on a sensor have relations with the voltages received. If the distance between a module and a sensor is short, the impedance between the module and the sensor will be small, and a four-wire configuration can be adopted. If the distance between a module and a sensor is long, a six-wire configuration can be used to reduce the error resulting from the impedance between the module and the sensor.

5. Estimating precision

The precision of a load cell module is 0.04%. The maximum rated load of a load cell sensor multiplied by 0.04% is the maximum precision that a load cell module can resolve. (The measurement time set by default is 50 milliseconds.) If the measurement time set is longer, the precision presented will increase. When users select a load cell sensor, they have to check whether the conversion time of the load cell sensor and the precision of the load cell sensor meet their requirements.

3

# 4

## Chapter 4 Control Registers

### Table of Contents

|       |   |      |
|-------|---|------|
| 4.1   | Table of Control Registers.....                         | 4-2  |
| 4.2   | Descriptions of the Control Registers .....             | 4-10 |
| 4.3   | Descriptions of Functions .....                         | 4-15 |
| 4.3.1 | Measuring a Net Weight.....                             | 4-15 |
| 4.3.2 | Stability Check .....                                   | 4-15 |
| 4.3.3 | Determining Zero .....                                  | 4-16 |
| 4.3.4 | Filtering out Weights .....                             | 4-16 |
| 4.3.5 | Correspondence between Current Outputs and Weights..... | 4-17 |
| 4.3.6 | Zero Tracking .....                                     | 4-18 |
| 4.3.7 | Weight Updates .....                                    | 4-18 |
| 4.3.8 | Output Values Set For Y Points .....                    | 4-18 |

## 4.1 Table of Control Registers

4

| CR# | Address | Attribute |     | Register name                        | Explanation  |
|-----|---------|-----------|-----|--------------------------------------|--|
| #0  | H1000   | O         | R   | Model name                           | The model code of a load cell module is defined by the module's system.<br>DVP201LC-SL's model code=H'5106<br>DVP202LC-SL's model code=H'5206<br>DVP211LC-SL's model code=H'5906   |
| #1  | H1001   | O         | R   | Firmware version                     | Hexadecimal value<br>The current firmware version of a load cell module is displayed.  |
| #2  | H1002   | O         | R/W | Characteristic value                 | CH1: Bit 0~bit 7; CH2: Bit 8~bit 15<br>Mode 0: 1 mV/V; Mode 4: 20 mV/V<br>Mode 1: 2 mV/V; Mode 5: 40 mV/V<br>Mode 2: 4 mV/V; Mode 6: 80 mV/V<br>Mode 3: 6 mV/V   |
| #3  | H1003   | O         | R/W | Reaction time for measurement        | CH1: bit0~bit7; CH2: bit8~bit15<br>Mode 0: 2.5ms; Mode 5: 60ms<br>Mode 1: 10ms; Mode 6: 100ms<br>Mode 2: 16ms; Mode 7: 200ms<br>Mode 3: 20ms; Mode 8: 400ms<br>Mode 4: 50ms (factory setting)  |
| #6  | H1006   | X         | R/W | Returning to zero/Subtracting a tare | K1: Subtracting the tare measured by CH1<br>K2: Not subtracting the tare measured by CH1<br>K3: Restoring the weight measured by CH1 to zero<br>K4: Subtracting the tare measured by CH2<br>K5: Not subtracting the tare measured by CH2<br>K6: Restoring the weight measured by CH2 to zero |
| #7  | H1007   | O         | R/W | Displaying a gross weight/net weight | CH1: Bit 0~bit 7; CH2: Bit 8~bit 15<br>K0: Displaying a gross weight<br>K1: Displaying a net weight  |
| #8  | H1008   | X         | R/W | Tare measured by CH1 (Low word)      | Displaying a tare  |
| #9  | H1009   | X         | R/W | Tare measured by CH1                 |  |

| CR# | Address | Attribute |     | Register name   | Explanation  |
|-----|---------|-----------|-----|---|--|
|     |         |           |     | (High word)   |  |
| #10 | H100A   | X         | R/W | Tare measured by CH2<br>(Low word)                              |  |
| #11 | H100B   | X         | R/W | Tare measured by CH2<br>(High word)                             |  |
| #12 | H100C   | X         | R   | Weight measured by CH1<br>(Low word)                            | Displaying a weight  |
| #13 | H100D   | X         | R   | Weight measured by CH1<br>(High word)                           |  |
| #14 | H100E   | X         | R   | Weight measured by C2<br>(Low word)                             |  |
| #15 | H100F   | X         | R   | Weight measured by C2<br>(High word)                            |  |
| #16 | H1010   | O         | R/W | Number of weights<br>measured by CH1 in a<br>stability range    | Setting range: K1~K500 (Factory setting: K5)   |
| #17 | H1011   | O         | R/W | Number of weights<br>measured by CH2 in a<br>stability range    | Setting range: K1~K500 (Factory setting: K5)   |
| #18 | H1012   | O         | R/W | Stability range for CH1   | Setting range: K1~K10000 (Factory setting: K10)  |
| #19 | H1013   | O         | R/W | Stability range for CH2   | Setting range: K1~K10000 (Factory setting: K10)  |
| #20 | H1014   | O         | R/W | Lower limit of the zero<br>return for CH1                       | Once the weight is in this setting range K-1 ~<br>K-32768, the status is on-load on the load cell.<br>(Factory setting: K-10)  |
| #21 | H1015   | O         | R/W | Lower limit of the zero<br>return for CH2                       |  |
| #25 | H1019   | O         | R/W | Total number of points<br>which need to be calibrated           | Setting range: K2~K20 (Factory setting: K2)  |
| #26 | H101A   | X         | R/W | Calibration command   | CH1: K1~K20<br>CH2: K21~K40  |
| #27 | H101B   | O         | R/W | Selecting a calibration point<br>for CH1                        | K1~K19   |
| #28 | H101C   | O         | R/W | Selecting a calibration point<br>for CH2                        | K1~K19   |
| #29 | H101D   | O         | R/W | Raw data given to a<br>calibration point for CH1<br>(Low word)  | The firmware will load the relevant ADC raw data<br>automatically while calibrating.   |
| #30 | H101E   | O         | R/W | Raw data given to a<br>calibration point for CH1<br>(High word) | You can get a similar result of measurement curves<br>by copying the raw data of calibrated points and<br>settings associated to the measurement to other<br>modules, which use the same model of sensors,<br>without calibration.<br><br>Please be noticed that the above acts may cause<br>unpredictable errors and deviation in the result of<br>measurement curves because of different features<br>between sensors and environment. |
| #31 | H101F   | O         | R/W | Raw data given to a<br>calibration point for CH2<br>(Low word)  |  |
| #32 | H1020   | O         | R/W | Raw data given to a<br>calibration point for CH2<br>(High word) |  |

4

| CR# | Address | Attribute |     | Register name  | Explanation  |
|-----|---------|-----------|-----|--|--|
| #33 | H1021   | O         | R/W | Digital value given to a calibration point for CH1 (Low word)  | Digital values (weight values) correspond to calibration points1~19. |
| #34 | H1022   | O         | R/W | Digital value given to a calibration point for CH1 (High word) |  |
| #35 | H1023   | O         | R/W | Digital value given to a calibration point for CH2 (Low word)  |  |
| #36 | H1024   | O         | R/W | Digital value given to a calibration point for CH2 (High word) |  |
| #25 | H1019   | O         | R/W | Total number of calibration points                             | Setting range: K2~K20 (Factory setting: K2)                          |
| #26 | H101A   | X         | R/W | Calibration command  | CH1: K1~K20<br>CH2: K21~K40  |
| #27 | H101B   | X         | R/W | Selecting a calibration point for CH1                          | K1~K19   |
| #28 | H101C   | X         | R/W | Selecting a calibration point for CH2                          | K1~K19   |
| #29 | H101D   | O         | R/W | Digital value given to a calibration point for CH1 (Low word)  | Digital value given to a calibration point                           |
| #30 | H101E   | O         | R/W | Digital value given to a calibration point for CH1 (High word) |  |
| #31 | H101F   | O         | R/W | Digital value given to a calibration point for CH2 (Low word)  | Digital value corresponding to a weight needs to be adjusted         |
| #32 | H1020   | O         | R/W | Digital value given to a calibration point for CH2 (High word) |  |
| #33 | H1021   | O         | R/W | Weight of a calibration point for CH1 (Low word)               | Weight of a weight   |
| #34 | H1022   | O         | R/W | Weight of a calibration point for CH1 (High word)              |  |
| #35 | H1023   | O         | R/W | Weight of a calibration point for CH2 (Low word)               |  |
| #36 | H1024   | O         | R/W | Weight of a calibration point for CH2 (High word)              |  |
| #37 | H1025   | O         | R/W | Maximum which can be   |  |

| CR#  | Address | Attribute |     | Register name   | Explanation  |
|--|---------|-----------|-----|---|--|
|  |         |           |     | measured by CH1 (Low word)                            | Users can specify the maximum weight which can be measured by CH1/CH2. If a weight measured exceeds the maximum weight, an error code will be stored.  |
| #38  | H1026   | O         | R/W | Maximum which can be measured by CH1 (High word)      |  |
| #39  | H1027   | O         | R/W | Maximum which can be measured by CH2 (Low word)       |  |
| #40  | H1028   | O         | R/W | Maximum which can be measured by CH2 (High word)      |  |
| #41  | H1029   | X         | R/W | Storing all setting values (H'5678)                   | Storing all setting values, and writing them to the flash memory in the load cell module used<br>H0: No action (factory setting)<br>H'FFFF: All setting values are stored successfully.<br>H'5678: Writing all setting values to the flash memory in the load cell module used |
| CR#41: If the value in CR#41 is H'5678, all setting values will be stored in the flash memory. After the setting values are stored, the value in CR#41 will become H'FFFF. If the value written to CR#41 is not H'5678, it will automatically become H'0. For example, if H1 is written to CR#41, it will become H1. (After the calibration of points is complete, please use CR#41 to make calibration parameters retentive.) |         |           |     |   |  |
| #42  | H102A   | X         | R/W | Restoring all settings to factory settings            | Restoring all settings to factory settings (H'55AA)  |
| #43  | H102B   | X         | R/W | Way in which weights measured by CH1 are filtered out | K0: Not filtering weights (factory setting)  |
| #44  | H102C   | X         | R/W | Way in which weights measured by CH2 are filtered out | K1: Filtering out the maximum weight measured<br>K2: Averaging weights   |
| #45  | H102D   | X         | R/W | Filter parameter for CH1                              | Filtering out the maximum weight measured:<br>K0~K8  |
| #46  | H102E   | X         | R/W | Filter parameter for CH1                              | Averaging weights: The number of weights which need to be averaged should be in the range of K1 to K100.<br>The averaged numbers in the range of K1 to K400 are supported only by version V1.12 and after.   |
| #48  | H1030   | O         | R/W | Upper limit for determining                           | If the digital value corresponding to a weight   |



| CR#  | Address | Attribute |     | Register name  | Explanation  |
|------|---------|-----------|-----|--|--|
|      |         |           |     | whether the digital value corresponding to a weight measured by CH1 is 0 grams                             | measured by CH1/CH2 is in the range specified, bit 5/bit 10 in CR#51 will be set (the weight measured is will be counted as 0 grams).<br>Default value: K10  |
| #49  | H1031   | O         | R/W | Upper limit for determining whether the digital value corresponding to a weight measured by CH2 is 0 grams | Setting range: K0~K32767   |
| #51  | H1033   | X         | R/W | Status code  | The status of the load cell module used is stored in this register. Please refer to the status table below for more information.<br>Factory setting: H'0000  |
| #52  | H1034   | O         | R/W | RS-232 station address   | The default value in CR#52/CR#54 is K1. The setting values in CR#52 and CR#54 should be in the range of K1 to K255. The default value in CR#53/CR#55 is H'0000 (ASCII, 9600 bps, 7 data bits, even parity bit, one stop bit). Please refer to the communication format table below for more information. |
| #53  | H1035   | O         | R/W | RS-232 communication format  |  |
| #54  | H1036   | O         | R/W | RS-485 station address   |  |
| #55  | H1037   | O         | R/W | RS-485 communication format  |  |
| #95  | H105F   | O         | R/W | Zero point tracking range of CH1   | Setting range: 0 ~ 30000; when set the setting to 0, it indicates zero point tracking is disabled.   |
| #96  | H1060   | O         | R/W | Zero point tracking time of CH1  | Setting range: 5 ~ 1000; unit: 0.1 s   |
| #97  | H1061   | O         | R/W | Zero point tracking range of CH2   | Setting range: 0 ~ 30000; when set the setting to 0, it indicates zero point tracking is disabled.   |
| #98  | H1062   | O         | R/W | Zero point tracking time of CH2  | Setting range: 5 ~ 1000; unit: 0.1 s   |
| #100 | H1064   | O         | R/W | Current output   | Setting range: K0~K4000  |
| #101 | H1065   | X         | R   | Digital input terminal   | Bit 0: X0; Bit 1: X1   |
| #102 | H1066   | X         | R/W | Digital output terminal  | Bit 0: Y0; Bit 1: Y1; Bit 2: Y2; Bit 3: Y3   |
| #103 | H1067   | O         | R/W | Way of outputting a current  | K0: Digital value(CR#100) corresponding to a current output in the range of 0 mA to 20 mA (factory setting)  |

4

| CR#  | Address | Attribute |     | Register name                                  | Explanation  |
|------|---------|-----------|-----|--|--|
|      |         |           |     |  | <p>K1: Digital value(CR#100) corresponding to a current output in the range of 4 mA to 20mA</p> <p>K2: Weight corresponding to a current output in the range of 0 mA to 20mA</p> <p>K3: Weight corresponding to a current output in the range of 4 mA to 20mA</p>  |
| #104 | H1068   | O         | R/W | Way in which a digital input terminal operates | <p>X0: Bit 0~bit 7; X1: Bit 8~bit 15</p> <p>H0: General digital input terminal (factory setting)</p> <p>H1: If a digital input terminal is ON, a weight will be restored to zero,</p> <p>H2: If a digital input terminal is ON, a tare will be measured.</p> <p>H3: If a digital input terminal is ON, a tare will be subtracted.</p> <p>H4: If a digital input terminal is OFF, a net weight will be measured.</p> <p>H6: If a digital input terminal is ON, zero will be adjusted.</p> <p>H7: If a digital input terminal is ON, the first point will be adjusted.</p> <p>H8: rising edge triggered: Y0~Y3 open outputs; falling edge triggered: Y0~Y3 close outputs</p> <p>H9: rising edge triggered: Y0~Y3 close outputs; falling edge triggered: Y0~Y3 open outputs</p> <p>HA: rising edge triggered: Y0~Y3 hold outputs; falling edge triggered: Y0~Y3 open outputs</p> <p>HB: rising edge triggered: Y0~Y3 open outputs; falling edge triggered: Y0~Y3 hold outputs</p> <p>X0 and X1 cannot be set as H4 at the same time.</p> <p>H'A and H'B:</p> <ul style="list-style-type: none"> <li>● Hold state: State remains Hold while changing Y0 ~ Y3 and CR#109 = 2 (HOLD state).</li> <li>● Output enabled state: Outputs would be enabled after changing Y0 ~ Y3.</li> </ul> |



4

| CR#  | Address | Attribute |     | Register name                                   | Explanation  |              |             |             |
|------|---------|-----------|-----|---|--|--------------|-------------|-------------|
|      |         |           |     |   | Bit 15~bit 12  | Bit 11~bit 8 | Bit 7~bit 4 | Bit 3~bit 0 |
|      |         |           |     |   | Y3   | Y2           | Y1          | Y0          |
| #105 | H1069   | O         | R/W | Way in which a digital output terminal operates | H0: General digital output terminal (factory setting)<br>H1: If no weight is measured, a digital output terminal will be ON.<br>H2: If no weight is measured, a digital output terminal will be OFF.<br>H3: If a weight measured is greater than the maximum weight specified, a digital output terminal will be ON.<br>H4: If a weight measured is greater than the maximum weight specified, a digital output terminal will be OFF.<br>H5: If an excitation voltage is abnormal, a digital output terminal will be ON.<br>H6: If an excitation voltage is abnormal, a digital output terminal will be OFF.<br>H7: If a weight measured is in the stability range specified, a digital output terminal will be ON.<br>H8: If a weight measured is in the stability range specified, a digital output terminal will be OFF.<br>H'9: If a weight measured is greater than t the weight value that is set to output, a digital output terminal will be ON.<br>H'A: If a weight measured is greater than t the weight value that is set to output, a digital output terminal will be OFF. |              |             |             |
| #106 | H106A   | O         | R/W | Weight changing of CH1                          | Default: K0; setting range: K0 ~ K32767  |              |             |             |
| #107 | H106B   | O         | R/W | Weight changing of CH2                          | Default: K0; setting range: K0 ~ K32767  |              |             |             |
| #109 | H106D   | X         | R/W | Status of Y point                               | Work with CR#104 and Y points<br>0: Y point output enabled (default)<br>1 : Y point output closed (the status of Y0-Y3 is OFF)   |              |             |             |

| CR#  | Address | Attribute |     | Register name                              | Explanation  |
|------|---------|-----------|-----|--|--|
|      |         |           |     |  | 2: Y point output on hold (the status of Y0-Y3 cannot be changed)  |
| #110 | H106E   | O         | R/W | Y0 weight output setting value (Low word)  | When the weight is greater than the weight value that is set to output, you can set the Y point output to ON or OFF. |
| #111 | H106F   | O         | R/W | Y0 weight output setting value (High word) |  |
| #112 | H1070   | O         | R/W | Y1 weight output setting value (Low word)  |  |
| #113 | H1071   | O         | R/W | Y1 weight output setting value (High word) |  |
| #114 | H1072   | O         | R/W | Y2 weight output setting value (Low word)  |  |
| #115 | H1073   | O         | R/W | Y2 weight output setting value (High word) |  |
| #116 | H1074   | O         | R/W | Y3 weight output setting value (Low word)  |  |
| #117 | H1075   | O         | R/W | Y3 weight output setting value (High word) |  |
| #118 | H1076   | O         | R/W | Y0 delay output time                       | Default: 0; setting range: 0 ~ 300;<br>unit: 10 ms   |
| #119 | H1077   | O         | R/W | Y1 delay output time                       |  |
| #120 | H1078   | O         | R/W | Y2 delay output time                       |  |
| #121 | H1079   | O         | R/W | Y3 delay output time                       |  |

## 4.2 Descriptions of the Control Registers

**CR#0:** Model name

[Description]

DVP201LC-SL's model code=H'5106

DVP202LC-SL's model code=H'5206

DVP211LC-SL's model code=H'5906

**CR#1:** Firmware version

[Description]

High byte: Number at the left side of the decimal point in a version number

Low byte: Number at the right side of the decimal point in a version number

Example: V1.01 → CR#=H'0101

**CR#2:** Eigenvalue

[Description]

The specifications for load cells vary from brand to brand. Users need to set an eigenvalue according to the specification for the load cell used.

| Eigenvalue                                       |                            |                          |
|--|----------------------------|--------------------------|
| Specifications for the eigenvalue in a load cell | Selection of an eigenvalue | Setting value in CR#2    |
| 0 mV/V < Eigenvalue ≤ 1 mV/V                     | 1m V/V                     | H'0000                   |
| 0 mV/V < Eigenvalue ≤ 2 mV/V                     | 2m V/V                     | H'0001 (Default setting) |
| 0 mV/V < Eigenvalue ≤ 4 mV/V                     | 4m V/V                     | H'0002                   |
| 0 mV/V < Eigenvalue ≤ 6 mV/V                     | 6m V/V                     | H'0003                   |
| 0 mV/V < Eigenvalue ≤ 20 mV/V                    | 20m V/V                    | H'0004                   |
| 0 mV/V < Eigenvalue ≤ 40 mV/V                    | 40m V/V                    | H'0005                   |
| 0 mV/V < Eigenvalue ≤ 80 mV/V                    | 80m V/V                    | H'0006                   |
| Eigenvalue > 80 mV/V                             | Not supported              |                          |

**CR#3:** Reaction time for measurement

[Description]

Users can set the time which needs to elapse before a weight is sampled. The shorter the time set is, the shorter the time it takes to filter weights. The weights measured are not in a stability range. If the time set is the maximum time which can be set, the weights measure will be in a stability range.

| Reaction time for measurement |             |
|-------------------------------|-------------|
| Input value                   | Description |
| Mode 0: H'0000                | 2.5 ms      |
| Mode 1: H'0001                | 10 ms       |
| Mode 2: H'0002                | 16 ms       |



|                |                        |
|----------------|------------------------|
| Mode 3: H'0003 | 20 ms                  |
| Mode 4: H'0004 | 50ms (Default setting) |
| Mode 5: H'0005 | 60 ms                  |
| Mode 6: H'0006 | 100 ms                 |
| Mode 7: H'0007 | 200 ms                 |
| Mode 8: H'0008 | 400 ms                 |

**CR#6:** Returning to zero/Subtracting a tare

[Description]

Users can use CR#6 to restore the weight measured to zero.

| Input value | Description  |
|-------------|--|
| K1          | Subtracting the tare measured by CH1, while saving the tare weight in CR#8 and #9 (DWORD).   |
| K2          | Not subtracting the tare measured by CH1   |
| K3          | Restoring the weight measured by CH1 to zero each time the device is rebooted.               |
| K4          | Subtracting the tare measured by CH2, while saving the tare weight in CR#10 and #11 (DWORD). |
| K5          | Not subtracting the tare measured by CH2   |
| K6          | Restoring the weight measured by CH2 to zero each time the device is rebooted.               |



**CR#7:** Displaying a gross weight/net weight

[Description]

Users can choose to display a gross weight or a net weight. The channel which is not used can be disabled.

| Bit 15~bit 8   | Bit 7~bit 0 |
|--|-------------|
| CH2  | CH1         |
| K0: Displaying a gross weight<br>K1: Displaying a net weight |             |

**CR#8~11:** Tare measured by CH1/CH2

[Description]

Tares are displayed in CR#8~CR#11. Users can write tares to CR#8~CR#11, or use CR#8~CR#11 to read tares.

**CR#12~15:** Weight measured by CH1/CH2

[Description]

Weights are displayed in CR#12~CR#15.

**CR#16~17:** Number of weights measured by CH1 in a stability range

[Description]  
 Factory setting: K5  
 Setting range: K1~K500  
 Please refer to section 4.3.2 for more information.

**CR#18~19:** Stability range for CH1/CH2

[Description]  
 Factory setting: K10  
 Setting range: K1~K10,000  
 Please refer to section 4.3.2 for more information.

**CR#25:** Total number of calibration points

[Description]  
 Factory setting: K2  
 Setting range: K2~K20  
 Users generally adjust two points, but they can adjust several points. The maximum number of points which can be adjusted is 20.

**CR#26:** Calibration command

[Description]  
 A calibration command is stored in CR#26.

| Command value | Description of CR#26   |
|---------------|--|
| K1~K20        | K1: The command value is used when no weight is measured by CH1.<br>K2~K20: The command values are used when calibration point 1~point 19 which are measured by CH1 need to be adjusted.   |
| K21~40        | K21: The command value is used when no weight is measured by CH2.<br>K22~K40: The command values are used when calibration point 1~point 19 which are measured by CH2 need to be adjusted. |

**CR#27~28:** Selecting calibration points for CH1/CH2

[Description]  
 Digital and raw values of calibration points displayed in CR#29~36 are determined by the calibration points selected in CR#27~28.

| CR#   | Command value | Description                        |
|-------|---------------|------------------------------------|
| CR#27 | K1~K19        | Selecting point 1~point 19 for CH1 |
| CR#28 | K1~K19        | Selecting point 1~point 19 for CH2 |



**CR#29~32:** Raw value given to calibration points for CH1/CH2

[Description]

The raw values given to calibration points are displayed in CR#29~CR#32.

**CR#33~36:** Digital values given to calibration points for CH1/CH2

[Description]

The digital values of points need to be written to CR#33~CR#36 while calibrating.

**CR#37~40:** Maximum weight which can be measured by CH1/CH2

[Description]

Users can specify the maximum weight which can be measured by CH1/CH2. If the weight measured by CH1/CH2 exceeds the maximum weight specified, bit 4/bit 9 in CR#51 will be set to 1.

**CR#41:** Storing all setting values

[Description]

CR#41 is used to store all setting values, and write them to the flash memory in the load cell module used.

Factory setting: 0

If the value in CR#41 is H'5678, all setting values will be stored in the flash memory in the load cell module used. After the setting values are stored, the value in CR#41 will become H'FFFF. If the value written to CR#41 is not H'5678, it will automatically become H'0. For example, if H'1 is written to CR#41, it will become H'0.

| Description | H'0       | H'FFFF                                      | H'5678  |
|-------------|-----------|---|---|
| Setting     | No action | All setting values are stored successfully. | Writing all setting values to the flash memory in the load cell module used |

**CR#43~44:** Way in which weights measured by CH1/CH2 are filtered out

[Description]

Users can set a way in which weights measured by CH1/CH2 are filtered out according to their requirements.

K0: Not filtering weights (factory setting)

K1: Filtering out the maximum weight measured

K2: Averaging weights

**CR#45~46:** Filter parameter for CH1/CH2

[Description]

Filtering out the maximum weight measured: K0~K8

Averaging weights: The number of weights which need to be averaged should be in the range of K1 to K100.

**CR#48~49:** Range for determining whether the digital value corresponding to a weight measured by CH1/CH2 is 0 grams

**CR#20~21:** Range for determining whether the digital value corresponding to a weight measured by CH1/CH2 is at its lower limit.

[Description]

If the digital value corresponding to a weight measured by CH1/CH2 is in the upper and lower range specified, bit 5/bit 10 in CR#51 will be set to 1.

**CR#51:** Status code

[Description]

| Bit number | Value  | Description    |
|------------|--------|----------------|
| Bit 0      | H'0001 | Abnormal power |



4

| Bit number    | Value    | Description   |
|---------------|----------|---|
| Bit 1         | H'0002   | Hardware failure  |
| Bit 2         | H'0004   | The weight measured by CH1 exceeds the maximum weight which can be measured, or the voltage of SEN is incorrect.  |
| Bit 3         | H'0008   | CH1 is adjusted incorrectly.  |
| Bit 4         | H'0010   | The weight measured by CH1 exceeds the maximum weight which can be measured.                                      |
| Bit 5         | H'0020   | No weight is measured by CH1.   |
| Bit 6         | H'0040   | A weight measured by CH1 is in the stability range specified.   |
| Bit 7         | H'0080   | The conversion of a weight measured by CH2 into a digital value is incorrect, or the voltage of SEN is incorrect. |
| Bit 8         | H'0100   | CH2 is adjusted incorrectly.  |
| Bit 9         | H'0200   | The weight measured by CH2 exceeds the maximum weight which can be measured.                                      |
| Bit 10        | H'0400   | No weight is measured by CH2.   |
| Bit 11        | H'0800   | A weight measured by CH2 is in the stability range specified.   |
| Bit 12~bit 15 | Reserved |   |

**CR#52~55:** Setting RS-232/RS-485 communication

[Description]

| Bit 15      | Bit 14~Bit 8              | Bit 7                     | Bit 6 | Bit 5 | Bit 4       | Bit 3 | Bit 2    | Bit 1      | Bit 0 |
|-------------|---------------------------|---------------------------|-------|-------|-------------|-------|----------|------------|-------|
| ASCII/RTU   | Reserved                  | Serial transmission speed |       |       | Data length |       | Stop bit | Parity bit |       |
| Description |                           |                           |       |       |             |       |          |            |       |
| Bit 15      | ASCII/RTU                 |                           |       | 0     | ASCII       |       | 1        | RTU        |       |
| Bit 7~bit 4 | Serial transmission speed |                           |       | 0     | 9,600 bps   |       | 1        | 19,200 bps |       |
|             |                           |                           |       | 2     | 38,400 bps  |       | 3        | 57,600 bps |       |
|             |                           |                           |       | 4     | 115,200 bps |       | 5        | Reserved   |       |
| Bit 3       | Data length (RTU=8 bits)  |                           |       | 0     | 7           |       | 1        | 8          |       |
| Bit 2       | Stop bit                  |                           |       | 0     | 1 bit       |       | 1        | 2 bits     |       |
| Bit 1~bit 0 | Parity bit                |                           |       | 0     | Even        |       | 1        | Odd        |       |
|             |                           |                           |       | 2     | Reserved    |       | 3        | Reserved   |       |

Example: If RS-232 communication format is "115200, 7, E, 1, ASCII", the value in CR#53 will be H'0400.

## 4.3 Descriptions of Functions

### 4.3.1 Measuring a Net Weight

Users can choose to measure the net weight or the gross weight of an object. A net weight is the weight of a product, that is, the actual weight of a product without its package. The weight of a package is a tare. A gross weight is a total weight, namely a net weight plus a tare.

- Tare: A tare is the weight of a package
- Net weight: A net weight is the weight of a product, that is, the actual weight of a product without its package.
- Gross weight: A gross weight is a total weight, namely the weight of a product itself (a net weight) plus the weight of a package (a tare).

- Gross weight=Net weight+Tare

Example: A product weighs 10 kilograms, and the carton in which the product is packed weighs 0.2 kilograms. The total weight gotten is 10 kilograms.

Net weight=10 kg

Tare=0.2 kg

Gross weight=10.2 kg


- Relevant control registers
  - CR#6: Returning to zero/Subtracting a tare
  - CR#7: Displaying a gross weight/net weight
  - CR#8~11: Tare measured by CH1/CH2

### 4.3.2 Stability Check

When an object is put on a load cell, users can check whether the present weight of the object is in a stability range specified.

- If a weight measured is in a stability range specified by users (CR#18/CR#19), bit 6/bit 11 in CR#51 will be set to 1.
- If a weight measured exceeds a range specified by users (CR#18/CR#19), bit 6/bit 11 in CR#51 will be set to 0. Bit 6/Bit 11 in CR#51 will not be set to 1 until the number of weights measured in a stability range reaches the value in CR#16/CR17.



Example: The measurement time set is 10 milliseconds, the number of weights measured in a stability range is 10, and the stability range set is 1000 grams. If a variation exceeds 1000 grams, bit 6/bit 11 in CR#51 will be set to 0. If the variations in 100 milliseconds (10×10 ms) are within 1000 grams, bit 6/bit 11 in CR#51 will be set to 1. (Users should judge whether the present weight measured is in the stability range set before they perform control.)



- Relevant control registers
  - CR#16/CR#17: Number of weights measured by CH1/CH2 in a stability range
  - CR#18/CR#19: Stability range for CH1/CH2

### 4.3.3 Determining Zero

If an object is removed from the load cell used, bit 6/bit 11 in CR#51 will be set to 1, bit 5/bit 10 in CR#51 will be set to 1, and users can perform the next control. (If a weight measured is in the zero range specified, bit 5/bit 10 in CR#51 will be set to 1.)



- Relevant control registers
  - CR#48/CR#49: Range for determining whether a weight measured by CH1/CH2 is 0 grams


### 4.3.4 Filtering out Weights

There are two ways to filter out weights.

- Filtering out the maximum/minimum weight measured: If there is a maximum weight or a minimum weight, CR#45/CR#46 can be used to filter out the maximum weight or the minimum weight. If the value in CR#45/CR#46 is bigger, more weights will be filtered out. Setting range: K0~K8
- Averaging weights: The values read are averaged so that a steady value is obtained. There may be peak values due to unavoidable external factors, and the average value obtained changes accordingly. The maximum number of values which can be averaged are 100.


### 4.3.5 Correspondence between Current Outputs and Weights

Currents outputs directly correspond to weights. Currents vary with weights. Users can set a current output mode by means of CR#103.




4

Example: 10 kg correspond to 20 mA.




A load cell module is directly connected to the left side of a DVP series PLC. The instruction TO is used to set parameters.

CR#103 is set to K2, and CR#37/CR#38 is set to K10000. Please see the WPLSoft program shown below.



### 4.3.6 Zero Tracking

That is Auto-zero function. Sensor may lose flexibility and accuracy after being used for a long time. In this case, you can set up a range for time and weight that zero tracking is attempted. Please refer to CR#95~CR#98 for relevant information of settings.




4

### 4.3.7 Weight Updates

Weight values would be updated in real time while using control registers. Meanwhile, you are allowed to configure the settings of changes in weight values in CR#106~CR#107 and the weight value would only be updated when the changes is greater than the setting value.

### 4.3.8 Output Values Set For Y Points

When the weight is greater than the weight value that is set to output, you can set the Y point output to ON or OFF. With delay output time, you can prevent multiple Y points from being enabled at the same time. Please refer to CR#110~CR#121 for details of the related settings.




# 5

## Chapter 5 Making Adjustment

### Table of Contents


|     |                                |     |
|-----|--------------------------------|-----|
| 5.1 | Steps in Adjusting Points..... | 5-3 |
| 5.2 | Example 1.....                 | 5-4 |
| 5.3 | Example 2.....                 | 5-5 |

The purpose of making adjustment is to make the weight measured by a cell correspond to the digital value displayed in a load cell module. Generally, two points are adjusted. After a system is set up, users can put no load on the scale. The weight measured is 0 grams when no load is put on the scale. The users can put a given weight on the scale, and set a digital value corresponding to the weight. The two points are adjusted. For example, if a load cell sensor which can measure a maximum weight of 10 kg is used, and 1 kg correspond to K1000, the curve presented will be like the one shown below.



Adjusting two points


In addition to the adjustment of two points, a load cell supports the adjustment of multiple points (20 points at most). A characteristic curve is shown below.



Adjusting multiple points

5

## 5.1 Steps in Adjusting Points






## 5.2 Example 1

Example: One point is adjusted. (A weight which weighs 1 kg corresponds to 1000 lsb.)

A load cell module is directly connected to the left side of a DVP series PLC. The instruction TO is used to make adjustment. The steps in making adjustment are as follows.

Step 1: Write K2 to CR#25. Please see the WPLSoft program shown below.




Step 2: Connect a load cell to a module, and put no load on the load cell.




Step 3: Write H'0001 to CR#26. Please see the WPLSoft program shown below.


5




Step 4: Select point 1 (default setting), and write H1 to CR#27. Please see the WPLSoft program shown below.




Step 5: Put a standard weight which weighs 1000 g on the load cell.




Step 6: Write K1000 (1000 g) to CR#33.



Step 7: Write H2 to CR#26.



Step 8: Make sure that the value displayed is correct, and make the adjustment retentive. Write H'5678 to CR#41. Please see the WPLSoft program shown below.




### 5.3 Example 2

Example: Three points are adjusted.

A load cell module is used independently. The steps in making adjustment are as follows.



Step 1: Select **3** in the **The Num. of Adjustment** box. The weight of the first weight is 500 g. It corresponds to 500 lsb. The weight of the second weight is 1000 g. It corresponds to 1000 lsb. The weight of the third weight is 1500 g. It corresponds to 1500 lsb. Please see the figure below.




5

Step 2: Put no load on the load cell used. Please see the figures below.

5





Step 3: Put a standard weight which weighs 500 g on the load cell used, and click **Next**. Please see the figure below.




5

Step 4: Type "500" in the **Wight value of weights** box, type "500" in the **Digital value of weights** box, and click **Next**. Please see the figures below.


5



Step 5: Put a standard weight which weighs 1000 g on the load cell used. Type "1000" in the **Wight value of weights** box, type "1000" in the **Digital value of weights** box, and click **Next**. Please see the figures below.





5




Step 6: Put a standard weight which weighs 1500 g on the load cell used. Type “1500” in the **Wight value of weights** box, type “1500” in the **Digital value of weights** box, and click **Next**. Please see the figures below.

5



Step 7: The adjustment made is complete, and a curve is displayed. Please see the figures below.



The screenshot shows the LCSoft software interface. The top status bar displays "CH1: 1499 g" and "Firmware Version: 1.02". The menu bar includes "File", "Communication", "Option", and "Help". The left sidebar has "System Settings", "Parameter Settings", "Adjusted Settings", and "Monitor". The main area is titled "Channel 1" and contains an "Adjustment" section. A dropdown menu shows "The Num. of Adjustment" set to 3. Below it is a table with the following data:

| Item | Standard | Digital Value |
|------|----------|---------------|
| 1    | 500      | 500           |
| 2    | 1000     | 1000          |
| 3    | 1500     | 1500          |

To the right of the table is a box labeled "The adjusted value settings" and a "Next>" button. Below the table is a graph titled "Channel 1" showing a linear calibration curve. The y-axis is labeled "g" and ranges from 0 to 1,500. The x-axis is labeled "LSB" and ranges from 0 to 1,400. Three points are marked on the curve: (0, 0), (500, 500), and (1,000, 1,000). A "1,500" label is also present at the end of the curve. The status bar at the bottom shows "Online", "[RS232: COM1]", and "DVP211LC-SL".

5



**MEMO**

5