

# **Industrial Automation Headquarters**

**Taiwan: Delta Electronics, Inc.** Taoyuan Technology Center No.18, Xinglong Rd., Taoyuan District, Taoyuan City 33068, Taiwan TEL: +886-3-362-6301 / FAX: +886-3-371-6301

#### Asia

China: Delta Electronics (Shanghai) Co., Ltd. No.182 Minyu Rd., Pudong Shanghai, P.R.C. Post code : 201209 TEL: +86-21-6872-3988 / FAX: +86-21-6872-3996 Customer Service: 400-820-9595

# Japan: Delta Electronics (Japan), Inc.

Industrial Automation Sales Department 2-1-14 Shibadaimon, Minato-ku Tokyo, Japan 105-0012 TEL: +81-3-5733-1155 / FAX: +81-3-5733-1255

Korea: Delta Electronics (Korea), Inc. 1511, 219, Gasan Digital 1-Ro., Geumcheon-gu, Seoul, 08501 South Korea TEL: +82-2-515-5305 / FAX: +82-2-515-5302

Singapore: Delta Energy Systems (Singapore) Pte Ltd. 4 Kaki Bukit Avenue 1, #05-04, Singapore 417939 TEL: +65-6747-5155 / FAX: +65-6744-9228

India: Delta Electronics (India) Pvt. Ltd. Plot No.43, Sector 35, HSIIDC Gurgaon, PIN 122001, Haryana, India TEL: +91-124-4874900 / FAX: +91-124-4874945

#### Thailand: Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z), Pattana 1 Rd., T.Phraksa, A.Muang, Samutprakarn 10280, Thailand TEL: +66-2709-2800 / FAX: +66-2709-2827

Australia: Delta Electronics (Australia) Pty Ltd. Unit 20-21/45 Normanby Rd., Notting Hill Vic 3168, Australia TEL: +61-3-9543-3720

#### Americas

USA: Delta Electronics (Americas) Ltd. 5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: +1-919-767-3813 / FAX: +1-919-767-3969

#### Brazil: Delta Electronics Brazil

Rua Itapeva, 26 - 3°, andar Edificio Itapeva, One - Bela Vista 01332-000 - São Paulo - SP - Brazil TEL: +55-12-3932-2300 / FAX: +55-12-3932-237

Mexico: Delta Electronics International Mexico S.A. de C.V.

Gustavo Baz No. 309 Edificio E PB 103 Colonia La Loma, CP 54060 Tlalnepantla, Estado de México TEL: +52-55-3603-9200

## DELTA\_IA-MDS\_REG2000\_UM\_EN\_20210519

**EMEA** 

EMEA Headquarters: Delta Electronics (Netherlands) B.V. Sales: Sales.IA.EMEA@deltaww.com Marketing: Marketing.IA.EMEA@deltaww.com Technical Support: iatechnicalsupport@deltaww.com Customer Support: Customer-Support@deltaww.com Service: Service.IA.emea@deltaww.com TEL: +31(0)40 800 3900

BENELUX: Delta Electronics (Netherlands) B.V. Automotive Campus 260, 5708 JZ Helmond, The Netherlands Mail: Sales.IA.Benelux@deltaww.com TEL: +31(0)40 800 3900

#### DACH: Delta Electronics (Netherlands) B.V.

Coesterweg 45, D-59494 Soest, Germany Mail: Sales.IA.DACH@deltaww.com TEL: +49(0)2921 987 0

#### France: Delta Electronics (France) S.A.

ZI du bois Challand 2, 15 rue des Pyrénées, Lisses, 91090 Evry Cedex, France Mail: Sales.IA.FR@deltaww.com TEL: +33(0)1 69 77 82 60

#### Iberia: Delta Electronics Solutions (Spain) S.L.U

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed. Hormigueras – P.I. de Vallecas 28031 Madrid TEL: +34(0)91 223 74 20 Carrer Llacuna 166, 08018 Barcelona, Spain

Carrer Llacuna 166, 08018 Barcelona, Spair Mail: Sales.IA.Iberia@deltaww.com

#### Italy: Delta Electronics (Italy) S.r.I.

Via Meda 2–22060 Novedrate(CO) Piazza Grazioli 18 00186 Roma Italy Mail: Sales.IA.Italy@deltaww.com TEL: +39 039 8900365

#### Russia: Delta Energy System LLC

Vereyskaya Plaza II, office 112 Vereyskaya str. 17 121357 Moscow Russia Mail: Sales.IA.RU@deltaww.com TEL: +7 495 644 3240

#### Turkey: Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Şerifali Mah. Hendem Cad. Kule Sok. No:16-A 34775 Ümraniye – İstanbul Mail: Sales.IA.Turkey@deltaww.com TEL: + 90 216 499 9910

#### MEA: Eltek Dubai (Eltek MEA DMCC)

OFFICE 2504, 25th Floor, Saba Tower 1, Jumeirah Lakes Towers, Dubai, UAE Mail: Sales.IA.MEA@deltaww.com TEL: +971(0)4 2690148



# Delta Power Regenerative Unit REG2000 Series User Manual

Manual



# **Copyright notice**

©Delta Electronics, Inc. All rights reserved.

All information contained in this user manual is the exclusive property of Delta Electronics Inc. (hereinafter referred to as "Delta ") and is protected by copyright law and all other laws. Delta retains the exclusive rights of this user manual in accordance with the copyright law and all other laws. No parts in this manual may be reproduced, transmitted, transcribed, translated or used in any other ways without the prior consent of Delta.

# Limitation of Liability

The contents of this user manual are only for the use of the products manufactured by Delta. Except as defined in special mandatory laws, Delta provides this user manual "as is" and does not offer any kind of warranty through this user manual for using the product, either express or implied, including but not limited to the following: (i) this product will meet your needs or expectations; (ii) the information contained in the product is current and correct; (iii) the product does not infringe any rights of any other person. You shall bear your own risk to use this product.

In no event shall Delta, its subsidiaries, affiliates, managers, employees, agents, partners and licensors be liable for any direct, indirect, incidental, special, derivative or consequential damages ( including but not limited to the damages for loss of profits, goodwill, use or other intangible losses) unless the laws contains special mandatory provisions to the contrary.

Delta reserves the right to make changes to the user manual and the products described in the user manual without prior notice and afterwards.

# Preface

Please read the following installation safety instructions.



- $\blacksquare$  Ensure the power is OFF before wiring or installing the Power Regenerative Unit.
- After the AC power is turned off, do not touch the internal circuits and components until the POWER indicator on the unit (below the digital keypad) turns off, because the Power Regenerative Unit is still charged with a high-voltage current and is very dangerous.
- ☑ The components on the internal circuit board of the Power Regenerative Unit are susceptible to damage from electrostatic discharge. Do not touch the circuit board with bare hands before taking proper antistatic measures. Do not modify components or circuits within the Power Regenerative Unit.
- ☑ The Power Regenerative Unit ⊕ must be properly grounded. The 230V series uses Type 3 grounding; the 460V series uses special grounding.
- ☑ Install the Power Regenerative Unit and its components away from heat sources and flammable objects.



- ☑ The power system voltage rating onto which the Power Regenerative Unit is installed must not be higher than 240 V for the 230V series (480 V for the 460V series), and the current must not be greater than 5000 A RMS [10000 A RMS for models of 40 HP (30 kW) or more].
- ☑ Only a qualified professional electrician shall install, wire, repair and maintain the Power Regenerative Unit.
- Even when the Power Regenerative Unit is in standby mode, its main circuit terminals may still carry dangerously high voltage.
- ☑ If unopened and unused for more than three months, the ambient storage temperature must not be higher than 30°C. The electrolytic capacitors are likely to deteriorate if stored without power at high ambient temperatures. Do not leave the unit without power for more than one year.
- ☑ Notes for the disinfection and disinfestation of packaging materials for transportation and installation (including wooden crates, planks, cardboard boxes, etc.):
  - 1. When sterilizing or deworming packaging materials, such as crates or cartons, do not fumigate to avoid damaging internal components.
  - 2. Use alternative environmental sterilization or deworming methods.
  - Permitted high temperature method: leave the packaging materials at a temperature of over 56°C for 30 minutes or more.
  - 4. Do not fumigate. Any damage caused by fumigation is not covered by warranty.

# 

- The pictures and corresponding descriptions in this manual feature the product with the outer casing or safety shields removed or disassembled to better explain the product in detail. Correctly install the outer casing and wirings in accordance with the rules and regulations, and operate the product following the instructions in the manual to ensure your safety.
- The illustrations in the manual may differ slightly from the actual product for demonstration purposes, but do not affect the rights and interests of the customer.
- You can download the latest updated product documentation from the industrial automation product page on the Delta Electronics website (<u>http://www.delta.com.tw/industrialautomation/</u>).

# Table of Contents

| 01 Product Overview                                     | 1-1  |
|---|------|
| 02 Checking & Recommendations                           | 2-1  |
| 03 Specifications                                       | 3-1  |
| 04 Wiring   | 4-1  |
| 4-1 Wiring Diagram                                      | 4-2  |
| 4-2 Main Circuit Terminals                              | 4-8  |
| 4-3 Control Circuit Terminals                           | 4-16 |
| 4-4 Display Panel Indicators                            | 4-20 |
| 05 Optional Accessories                                 | 5-1  |
| 5-1 Digital Keypad                                      | 5-2  |
| 5-2 USB/RS-485 Communication Interface IFD6500, IFD6530 | 5-6  |
| 5-3 Fuse Specification Chart                            | 5-10 |
| 5-4 EMI Filter  | 5-11 |
| 5-5 External Power Supply Card (24 V) EMC-BPS01         | 5-20 |
| 5-6 Fan Kit   | 5-25 |
| 06 Summary of Parameter Settings                        | 6-1  |
| 07 Descriptions of Parameter Settings                   | 7-1  |
| 08 Warnings and Error Codes                             | 8-1  |
| 09 Usage Recommendations and Troubleshooting            | 9-1  |
| 10 Power Regenerative Unit Selection                    | 10-1 |
|   |      |


# Supported Version Firmware V1.03 and later


# 01 Product Overview

Follow these steps before using the product to ensure safety during use.

- 1) After opening the packaging, first check that the product has not been damaged during shipment. Inspect and ensure that the nameplate labels on the product match the labels on the box.
- 2) Make sure the wiring is suitable for the Power Regenerative Unit voltage range. Follow the instructions in the installation manual when installing the Power Regenerative Unit.
- 3) When wiring the Power Regenerative Unit, be aware of the wiring positions of the main circuit terminals "R/L1, S/L2, T/L3, DC+, DC-", and make sure the terminals are wired correctly to prevent any damage.

# 1-1 Nameplate






# 1-4 Apply for After-sales Service by Mobile Device

## 1-4-1 Location of Service Link Label

#### Frame A–C

Remove the display panel to find the service link label (service label), located in the upper-right corner of the case (see the following drawing).

Space to install keypad on the case



#### 1-4-2 Service Link Label



#### Scan QR Code to apply

- 1. Find the QR code sticker (as shown above).
- 2. Start the QR code reader app on your smartphone.
- 3. Point your camera to the QR Code. Hold your camera steady so that the QR code comes into focus.
- 4. Access the Delta After-Sales Service website.
- 5. Fill in the information into the fields marked with an orange star.
- 6. Enter the CAPTCHA and click **Submit** to complete the application.


#### Cannot find our QR Code?

- 1. Open a web browser on your computer or smartphone.
- 2. Type <u>https://service.deltaww.com/ia/repair</u> into the address bar and press Enter.
- 3. Fill in the information into the fields marked with an orange star.
- 4. Enter the CAPTCHA and click **Submit** to complete the application.

# 1-5 Operating Principle

In a variable-frequency drive system, the motor is in a power generating state due to the high inertia in a drive system such as centrifuges and washing machines, or applications requiring fast braking such as machine tool spindles. In other words, because the rotor is rotated by external forces, the actual motor speed exceeds the drive-controlled synchronous speed, quickly feeding the energy generated by the motor back to the DC BUS. This results in a rapid rise in the DC BUS voltage and endangers the drive. This excess energy must be quickly consumed to keep the DC BUS voltage within a safe range; otherwise, the drive will either malfunction or enter over-voltage protection mode.

The traditional method is to convert the excess energy into heat with a brake resistor. This method has the advantages of simpler wiring and lower total cost, but has the disadvantages of a large brake resistor, requiring additional cooling devices, a limited braking capability, and inefficient energy use. On the other hand, the Power Regenerative Unit (REG2000) converts the power generated by the motor into electric energy, and then returns it to the electrical grid for other electrical applications, thereby conserving energy. Installing the Power Regenerative Unit can increase the motor's braking capability.




Regenerated power: Preg

When you set the DC BUS voltage activation level (Pr.01-08), the Power Regenerative Unit (REG2000) determines the motor drive's DC BUS voltage regenerative trigger point to satisfy the regenerative demands in various industrial applications. When the DC BUS voltage is higher than the voltage activation level, the Power Regenerative Unit (REG2000) starts regenerating power. The capacitance clamping voltage is set as the activation level and the excess energy generated by the motor is converted to three-phase AC current to regenerate the mains power (AC).

The Power Regenerative Unit (REG2000) stops the power regeneration immediately and continues to operate (RUN) when either of the following conditions occurs. The DC BUS voltage triggers the DC-side voltage activation level until the motor brakes for the next time.

- (1) When the DC BUS voltage is lower than the activation voltage level (default value = 10 V) or
- (2) When the output current (A<sub>AC</sub>) of the Power Regenerative Unit (REG2000) is 10% lower than the rated output current for 1 second.




# The Working Principle of Power Regenerative Unit

# 1-6 RFI Jumper

RFI (Radio Frequency Interference): The Power Regenerative Unit generates electrical noise, resulting in frequency interference on the AC power cable.

Frame A–C Screw torque: 6–8 kg-cm (5.2–6.9 lb-in.)

After loosening the screws, remove the RFI jumper (MOV-PLATE/ RFI jumper) as shown in the diagram below. Make sure to tighten the screw again after removing the RFI jumper.




## 1-6-1 Isolating main power from ground

When the Power Regenerative Unit power distribution system is a floating ground system (IT) or an asymmetric ground system (TN), you must remove the RFI jumper when using Delta's EMI filter. Removing the RFI jumper cuts off the internal RFI capacitor (filter capacitor) between the system's ground and the central circuits to avoid damaging the central circuits and reduces the ground leakage current (according to IEC 61800-3).

Important points regarding ground connection:

- ☑ To ensure the safety of personnel, proper operation, and to reduce electromagnetic radiation, the Power Regenerative Unit must be properly grounded during installation.
- ☑ The diameter of the cables must meet the size specified by safety regulations.
- ☑ The shielded cable must be connected to the Power Regenerative Unit ground to meet safety regulations.
- $\square$  The shielded cable can only be used as the ground for equipment when the above points are met.
- ☑ When installing multiple sets of Power Regenerative Units, do not connect the Power Regenerative Units grounds in series, as shown below.



PLC1.ir

01 Product Overview | REG2000

Pay particular attention to the following points:

- After turning on the main power, do not remove the RFI jumper while the power is on.
- ☑ Make sure the main power is turned off before removing the RFI jumper.
- ☑ Removing the RFI jumper also cuts off the capacitor electrical conductivity, the transient voltage surge suppressor, and the common-mode capacitor. The Power Regenerative Unit no longer guarantees that the electromagnetic compatibility conforms to regulations.
- $\square$  Do not remove the RFI jumper if the main power is a grounded power system.
- ☑ Do not remove the RFI jumper while conducting high voltage tests. When conducting a high voltage test to the entire facility, disconnect the main power and the motor if the leakage current is too high.

#### Floating Ground System (IT Systems)


A floating ground system is also called IT system, ungrounded system, or high impedance/resistance (greater than 30  $\Omega$ ) grounding system.

- ☑ Remove the RFI jumper to cut off the transient voltage suppressor and the common-mode capacitance connecting to the ground.
- ☑ When installing an external capacitor or an external EMI filter, you form a circuit through the capacitor/EMI filter common capacitors' grounding. That circuit might damage the capacitor and the EMI filter.
- ☑ In situations where EMC is required, install an EMI filter specially designed for IT Systems. Removing the EMI filter might avoid damage but might also not conform to EMC regulations.
- ☑ In situations where EMC is required, check for excess electromagnetic radiation affecting nearby low-voltage circuits. In some situations, the adapter and cable naturally provide enough suppression. If in doubt, install an extra electrostatic shielded cable on the power supply side between the main circuit and the control terminals to increase security.

## Asymmetric Ground System (Corner Grounded TN Systems)

Caution: Do not remove the RFI jumper while the input terminal of the Power Regenerative Unit carries power.


In the following four situations, you must remove the RFI jumper, because the phase to ground voltage is not symmetrical in the power system. This prevents the Power Regenerative Unit from grounding through the RFI jumper and damaging the Power Regenerative Unit.



# **1-7 Dimensions**

# Frame A

REG075A23A-21; REG110A23A-21; REG075A43A-21; REG110A43A-21; REG150A43A-21




Detail B (Mounting Hole)

Unit: mm [inch]

|   | Frame | W      | Н       | D      | W1     | H1      | H2     | D1     | S1     | Φ1     | Ф2     | Ф3     |
|---|-------|--------|---------|--------|--------|---------|--------|--------|--------|--------|--------|--------|
| ſ | ~     | 130.0  | 370.0   | 190.0  | 116.0  | 357.5   | 236.0  | 183.0  | 7.0    | 22.2   | 28.0   | 34.0   |
|   | A     | [5.12] | [14.56] | [7.48] | [4.57] | [14.07] | [9.29] | [7.20] | [0.28] | [0.87] | [1.10] | [1.34] |

# Frame B

REG150A23A-21; REG185A23A-21; REG220A23A-21; REG185A43A-21; REG220A43A-21; REG300A43A-21




Detail B (Mounting Hole)

Unit: mm [inch]

| Frame | W      | Н       | D      | W1     | H1      | H2      | D1     | S1     | Ф1     | Ф2     | Ф3     | Ф4     |
|-------|--------|---------|--------|--------|---------|---------|--------|--------|--------|--------|--------|--------|
| В     | 190.0  | 500.0   | 205.0  | 172.5  | 482.0   | 302.0   | 190.5  | 9.0    | 22.2   | 28.0   | 34.0   | 43.8   |
| D     | [7.48] | [19.68] | [8.09] | [6.79] | [18.98] | [11.89] | [7.50] | [0.35] | [0.87] | [1.10] | [1.34] | [1.72] |

# Frame C

REG300A23A-21; REG370A23A-21; REG370A43A-21; REG450A43A-21; REG550A43A-21



| Unit: | mm | [inch] |
|-------|----|--------|
|-------|----|--------|

| Frame | W      | Н       | D      | W1     | W2     | W3     | H1      | H2      | S1     | Φ1     | Ф2     | Ф3     | Ф4     | Ф5     |
|-------|--------|---------|--------|--------|--------|--------|---------|---------|--------|--------|--------|--------|--------|--------|
| 6     | 250.0  | 650.0   | 210.0  | 231.0  | 220.0  | 252.5  | 631.5   | 381.0   | 8.5    | 22.2   | 28.0   | 34.0   | 44.0   | 50.1   |
| C     | [9.84] | [25.59] | [8.27] | [9.09] | [8.74] | [9.94] | [24.86] | [15.00] | [0.33] | [0.87] | [1.10] | [1.34] | [1.73] | [1.97] |


# 02 Checking & Recommendations

# Installation Distances & Wiring Description

# 

- ☑ Install this product upright.
- ☑ Do not allow foreign materials such as fibers, paper, wood chips/dust, or scrap metal to enter the Power Regenerative Unit or stick to the cooling fan.
- ☑ Connect the unit to a metallic or other nonflammable control panel to prevent causing a fire.
- ☑ Install the Power Regenerative Unit in an environment that complies with pollution degree 2 with clean circulating air. Clean circulating air is defined as air without polluting substances or electronically contaminated dust.

The following diagrams are for demonstration purposes only, and may differ from the actual product.




Multiple units - Vertical linked setup (Frame A, B, C)

# Frame A, B, C

When setting up multiple units in a vertical standalone setup, install dividers between the levels.

Determine the divider dimensions on the principle that the temperature at the intake fans should be lower than the operating temperature as shown in the diagrams below. Operating temperature is defined as the temperature measured 50 mm in front of the fan inlet.




| Minimum<br>Distance<br>Required<br>(mm)<br>Frame |    | В  | С  | D |
|--|----|----|----|---|
| A, B, C  | 60 | 30 | 10 | 0 |

| Frame A | REG075A23A-21; REG110A23A-21; REG075A43A-21; REG110A43A-21; REG150A43A-21  |
|---------|--|
| Frame B | REG150A23A-21; REG185A23A-21; REG220A23A-21; REG185A43A-21; REG220A43A-21; |
|         | REG300A43A-21  |
| Frame C | REG300A23A-21; REG370A23A-21; REG370A43A-21; REG450A43A-21; REG550A43A-21  |

# 

Frames A–C above are all required minimum distances; any distance less than these values will affect the cooling fan's function.



# 

- \* The specified distances are only applicable in open spaces. As shown in the diagram on the left, if the units are being installed in an enclosed space, such as distribution channel or chassis, install ventilation or air conditioning systems to keep the ambient temperature under the operating temperature.
- The table shows the required airflow rate for each model when installing single units in an enclosed space. For multiple units, multiply the required airflow rate by the number of units installed.
- Refer to the "Airflow Rate for Cooling" table below when selecting and designing ventilation systems.
- Refer to the "Power Dissipation of REG" table below for the design of air conditioning systems.

|               |          | Airflow       | Rate for Coolir | ng                             |          |       |  |  |  |
|---------------|----------|---------------|-----------------|--------------------------------|----------|-------|--|--|--|
| Model No.     | F        | low Rate (cfm |                 | Flow Rate (m <sup>3</sup> /hr) |          |       |  |  |  |
|               | External | Internal      | Total           | External                       | Internal | Total |  |  |  |
| REG075A23A-21 | 44       | -             | 44              | 75                             | -        | 75    |  |  |  |
| REG110A23A-21 | 44       | -             | 44              | 75                             | -        | 75    |  |  |  |
| REG150A23A-21 | 92       | -             | 92              | 155                            | -        | 155   |  |  |  |
| REG185A23A-21 | 92       | -             | 92              | 155                            | -        | 155   |  |  |  |
| REG220A23A-21 | 92       | -             | 92              | 155                            | -        | 155   |  |  |  |
| REG300A23A-21 | 121      | -             | 121             | 206                            | -        | 206   |  |  |  |
| REG370A23A-21 | 118      | 15            | 133             | 201                            | 25       | 226   |  |  |  |
| REG075A43A-21 | 44       | -             | 44              | 75                             | -        | 75    |  |  |  |
| REG110A43A-21 | 44       | -             | 44              | 75                             | -        | 75    |  |  |  |
| REG150A43A-21 | 44       | -             | 44              | 75                             | -        | 75    |  |  |  |
| REG185A43A-21 | 92       | -             | 92              | 155                            | -        | 155   |  |  |  |
| REG220A43A-21 | 92       | -             | 92              | 155                            | -        | 155   |  |  |  |
| REG300A43A-21 | 92       | -             | 92              | 155                            | -        | 155   |  |  |  |
| REG370A43A-21 | 121      | -             | 121             | 206                            | -        | 206   |  |  |  |
| REG450A43A-21 | 118      | 15            | 133             | 201                            | 25       | 226   |  |  |  |
| REG550A43A-21 | 118      | 15            | 133             | 201                            | 25       | 226   |  |  |  |


\* The table shows the required airflow rate for each model when installing single units in an enclosed space.

\* For multiple units, multiply the required airflow rate for single-unit installation by the number of units installed.

|               | Power Dis                 | sipation of REG   |       |  |  |
|---------------|---------------------------|-------------------|-------|--|--|
| Model No.     |                           | Power Dissipation |       |  |  |
|               | Loss External (Heat sink) | Internal          | Total |  |  |
| REG075A23A-21 | 127                       | 86                | 213   |  |  |
| REG110A23A-21 | 203                       | 121               | 324   |  |  |
| REG150A23A-21 | 219                       | 161               | 380   |  |  |
| REG185A23A-21 | 255                       | 184               | 439   |  |  |
| REG220A23A-21 | 336                       | 216               | 552   |  |  |
| REG300A23A-21 | 434                       | 186               | 620   |  |  |
| REG370A23A-21 | 678                       | 220               | 898   |  |  |
| REG075A43A-21 | 128                       | 76                | 204   |  |  |
| REG110A43A-21 | 198                       | 93                | 291   |  |  |
| REG150A43A-21 | 240                       | 122               | 362   |  |  |
| REG185A43A-21 | 291                       | 138               | 429   |  |  |
| REG220A43A-21 | 368                       | 158               | 526   |  |  |
| REG300A43A-21 | 446                       | 211               | 657   |  |  |
| REG370A43A-21 | 508                       | 184               | 692   |  |  |
| REG450A43A-21 | 664                       | 218               | 882   |  |  |
| REG550A43A-21 | 919                       | 257               | 1176  |  |  |

\* The table shows the required heat dissipation rate due to heat loss for each model when installing single units in an enclosed space.

For multiple units, multiply the heat dissipation rate for single units by the number of units installed. The heat dissipation data are calculated based on each model operating under rated voltage, current, and default carrier wave.



# PLC1.ir

# 03 Specifications

## 230V Series


| Frame  | )                                      | A        |        |             | В                                       | С       |              |     |  |  |  |
|--|--|----------|--------|-------------|---|---------|--------------|-----|--|--|--|
| Mode   | REGA23A-21                             | 075      | 110    | 150         | 185                                     | 220     | 300          | 370 |  |  |  |
| Rated  | power (kW)                             | 7.5      | 11     | 15          | 18.5                                    | 22      | 30           | 37  |  |  |  |
| Sl   | Rated input current (A <sub>DC</sub> ) | 24.0     | 39.0   | 46.0        | 59.8                                    | 73.2    | 97.6         | 122 |  |  |  |
| $\begin{array}{c c c c c c c c c c c c c c c c c c c $ |  |          |        |             |   | 1-08)   |              |     |  |  |  |
|  | Output current (A <sub>AC</sub> )      | 20       | 32     | 38          | 49                                      | 60      | 80           | 100 |  |  |  |
| Mains  | Rated voltage / frequency              |          | Thr    | ee-phase 20 | 0–240 Vac (                             | -15%–10 | %), 50/60 Hz |     |  |  |  |
| Ma   | Operation voltage range                |          |        |             | 170–265                                 | Vac     |              |     |  |  |  |
|  | Frequency range                        | 47–63 Hz |        |             |   |         |              |     |  |  |  |
|  | Net weight                             | 7.9 ± 0  | ).5 kg | 16          | 7.9 ± 0.5 kg 16.5 ± 0.5 kg 25.5 ± 0.5 k |         |              |     |  |  |  |

#### 460V Series


| Fram   | е                                      | A B  |           |          |               | С                     |         |           |                  |                  |
|--------|--|--|-----------|----------|---------------|-----------------------|---------|-----------|------------------|------------------|
| Mode   | el REGA43A-21                          | 075  | 110       | 150      | 185           | 220                   | 300     | 370       | 450              | 550              |
| Rate   | d power (kW)                           | 7.5  | 11        | 15       | 18.5          | 22                    | 30      | 37        | 45               | 55               |
| S      | Rated input current (A <sub>DC</sub> ) | 12.8   | 20.7      | 24.4     | 30.5          | 39.0                  | 52.5    | 59.8      | 73.0             | 91.5             |
| DC BUS | Range of voltage activation<br>level   | on 516–780 V <sub>DC</sub> (Specify in Pr.01-08) |           |          |               |                       |         |           |                  |                  |
|        | Output current (A <sub>AC</sub> )      | 10.5   | 17        | 20       | 25            | 32                    | 43      | 49        | 60               | 75               |
| Mains  | Rated voltage / frequency              |  | ٦         | Three-ph | ase 380–      | 480 V <sub>AC</sub> ( | -15%–10 | %), 50/60 | Hz               |                  |
| Ma     | Operation voltage range                |  |           |          |               | 323–528               | Vac     |           |                  |                  |
|        | Frequency range                        |  |           |          |               | 47–63 H               | Ηz      |           |                  |                  |
|        | Net weight                             |  | 5 ± 0.5 I | ٨g       | 17.0 ± 0.5 kg |                       |         |           | 29.0 ±<br>0.5 kg | 29.5 ±<br>0.5 kg |

# **General Specifications**

| Control method        | SVPWM   |  |  |  |  |  |  |  |  |
|-----------------------|---|--|--|--|--|--|--|--|--|
| Brake torque          | 0% rated output current when regenerating continuously; 100% rated output current when generating for 60 seconds at 25% ED. See REG2000 Performance Curve below for more information. |  |  |  |  |  |  |  |  |
| Overload capacity     | 150% rated output current when regenerating for 10 seconds at 10% ED  |  |  |  |  |  |  |  |  |
| Generic input signal  | Five channels of signal terminals, 24 $V_{DC}$ 6 mA   |  |  |  |  |  |  |  |  |
| Generic output signal | Two channels of signal terminals, 48 $V_{DC}$ 50 mA; one channel of signal terminal, relay output   |  |  |  |  |  |  |  |  |
| Cooling method        | Forced air cooling (Fan cooling)  |  |  |  |  |  |  |  |  |
| Certifications        |   |  |  |  |  |  |  |  |  |



- The plots above show the measurement by combining a Power Regenerative Unit with a DC choke.
- Regardless of the ED%, if the Power Regenerative Unit has a regeneration output for more than 400 seconds, the Power Regenerative Unit is performing a continuous regeneration.
- The LED indicators on the standard keypad display the operating status of the Power Regenerative Unit. If you need to set up the unit from a keypad, you can buy an optional keypad. See Chapter 05 Optional Accessories for more information.
- Definition of the brake utilization rate ED%:



# **Operation, Storage and Transportation Environment**

DO NOT expose the Power Regeneration Unit to environmental conditions such as dust, direct sunlight, corrosive/inflammable gasses, oil, humidity, liquid, or vibration. The salt in the air must be less than 0.01 mg/cm<sup>2</sup> every year.


| , ,           |                   |   |   |   |  |  |  |  |  |
|---------------|-------------------|---|---|---|--|--|--|--|--|
|               | Installation      | Location  | IEC60364-1/   | IEC60664-1 Pollution degree 2. Indoor use only. |  |  |  |  |  |
|               |                   | Operation   |   | -10–40°C  |  |  |  |  |  |
|               | Surrounding       | Storage/  |   | -25–70°C  |  |  |  |  |  |
|               | Temperature       | Transportation  |   | -23-70 0  |  |  |  |  |  |
|               |                   |   | Non-condensing, non-freezing  |   |  |  |  |  |  |
|               |                   | Operation   |   | Maximum 90%                                     |  |  |  |  |  |
|               | Rated Humidity    | Storage /   | Maximum 95%   |   |  |  |  |  |  |
|               |                   | Transportation  |   |   |  |  |  |  |  |
|               |                   |   | Non-  | condensing, non-freezing                        |  |  |  |  |  |
|               |                   | Operation /   |   | 86–106 kPa                                      |  |  |  |  |  |
| Environmental | Air Pressure      | Storage   |   |   |  |  |  |  |  |
| Environmontal |                   | Transportation  |   | 70–106 kPa                                      |  |  |  |  |  |
|               | Pollution Level   |   | IEC721-3-3  |   |  |  |  |  |  |
|               |                   | Operation   | Class 3C2; Class 3S2  |   |  |  |  |  |  |
|               |                   | Storage   | Class 2C2; Class 2S2  |   |  |  |  |  |  |
|               |                   | Transportation  | on Class 1C2; Class 1S2   |   |  |  |  |  |  |
|               |                   | No concentrate  |   |   |  |  |  |  |  |
|               |                   |   | If the Power Regeneration Unit is installed at altitude of 0–10         |   |  |  |  |  |  |
|               |                   |   | follow normal operation restrictions. If it is installed at altitude of |   |  |  |  |  |  |
|               | Altitude          | Operation   | 1000–3000 m, decrease the rated current by 2% or lower 0.5°C of         |   |  |  |  |  |  |
|               |                   |   | temperature for every 100 m increase in altitude. Maximum altitude      |   |  |  |  |  |  |
|               |                   |   | for Corner Grounded installation is 2000 m.                             |   |  |  |  |  |  |
| Package Drop  | Storage           | ISTA procedur   | e 1A (based on v  | weight) IEC60068-2-31                           |  |  |  |  |  |
| l donago Brop | Transportation    | io in procouur  |   |   |  |  |  |  |  |
|               | [Frame A & B] 2   | 2–13.2 Hz, 1.0 r  | nm; 13.2–55 Hz,   | 0.7–1.5 G; 55–512 Hz, 1.5 G (Complies with IEC  |  |  |  |  |  |
| Vibration     | 60068-2-6)        |   |   |   |  |  |  |  |  |
| Vibration     | [Frame C] 2–13    | [Frame C] 2–13.2 Hz, 1.0 mm; 13.2–55 Hz, 0.7–1.0 G; 55–512 Hz, 1.0 G (Complies with IEC |   |   |  |  |  |  |  |
|               | 60068-2-6)        |   |   |   |  |  |  |  |  |
| Impact        | IEC/EN 60068-2    | 2-27  |   | 1   |  |  |  |  |  |
| Operating     | Maximum allow     | ed offset angle   | ±10° (under   | 10° <b>⊳</b> ∖ <sub>⊌</sub> /∢10°               |  |  |  |  |  |
| position      | normal installati | -   |   | 10 <sup>°</sup> – 10 <sup>°</sup>               |  |  |  |  |  |
| •             |                   |   |   |   |  |  |  |  |  |


## **Operating Temperature and Protection Level Specifications**

# Dust cover

IP20 UL Open-Type


IP20 NEMA 1





| Dust cover | Protection Level  | Operating Temperature   |
|------------|-------------------|---|
| with       | IP20 NEMA 1       | When operating at rated current, the surrounding temperature must be        |
|            |                   | between -10–40°C. When the surrounding temperature is over +40°C,           |
| without    | IP20 UL Open-Type | decrease the rated current by 2% for every 1°C increase in temperature. The |
|            |                   | maximum allowable surrounding temperature is 60°C.                          |

## Normal Control Ambient Temperature Derating Factor Curve



1. Derating of the Power Regenerative Unit decreases by multiplication.

2. Derating is required not only when there is a continuous regeneration, but in addition the conditions covered by the Performance Curve are required to have the same derating ratio.

Calculation 1:

When the ambient temperature =  $40^{\circ}$ C, ED = 10%, the braking capacity of the Power Regenerative Unit = 150%, 10 seconds (See REG2000 Performance Curve).

When the ambient temperature =  $45^{\circ}$ C, see Normal Control Ambient Temperature Derating Factor Curve, and the Power Regenerative Unit needs a derating of  $10\% = (45^{\circ}$ C -  $40^{\circ}$ C) x 2%. Therefore, when ED is at 10%, the braking capacity of the Power Regenerative Unit = 150% x (100%-10%) = 135%, 10 seconds.

Calculation 2:

When the ambient temperature =  $40^{\circ}$ C and the regeneration is continuous, the braking capacity of the Power Regenerative Unit = 80% of the rated output current.

When the ambient temperature =  $55^{\circ}$ C and the regeneration is continuous, the braking capacity of the Power Regenerative Unit is  $56\% = [80\% \times (100\% - 30\%)]$  of the rated output current.

# 04 Wiring


After removing the front cover, verify that the power and control terminals are clearly noted. Read the following precautions before wiring.

- ☑ Make sure that power is only applied to the R/L1, S/L2, T/L3, DC+, and DC- terminals. Failure to comply may result in damage to the equipment. The voltage and current should be within the specified range on the nameplate (Section 1-1).
- All the units must be grounded directly to a common ground terminal to prevent lightning strike or electric shock and reduce interference.
- Securely tighten the main circuit terminal screws to prevent sparks caused by screws loosened by vibration.
- ☑ If a braking resistor is already installed in the existing system, keep the braking resistor for future use. Set Pr.01-08 to the reasonable power regenerative level when equipping with a braking resistor: (V<sub>AC</sub> Voltage Level x 1.414) < REG DC BUS voltage activation level (Pr.01-08) < braking resistor trigger level. Use a reasonable margin to ensure that DC ripple does not trigger Pr.01-08 setting by mistake.
- ☑ If the Power Regenerative Unit is NOT equipped with a braking resistor, pay attention to the **DFMEA** (Design Failure Mode and Effect Analysis). The Power Regenerative Unit provides full status indication. Signals can be provided by external terminals to ensure system integration reliability.
- ☑ If a Power Regenerative Unit is malfunctioning, it can send signals through communication and MOx terminals.

| DANGER  | N       | It is crucial to turn off the Power Regeneration Unit power before wiring. A charge with hazardous voltages may still remain in the DC BUS capacitors even if the power has been turned off. Always measure the remaining voltage before wiring. For your safety, do not perform any wiring before the voltage drops to a safe level < $25 V_{DC}$ . Wiring while voltage remains can cause sparks and short circuits. Only qualified personnel familiar with the Power Regeneration Unit are allowed to perform installation, wiring and commissioning. Make sure the power is turned off before wiring to prevent electric shock. |
|---------|---------|---|
| CAUTION | <u></u> | <ul> <li>When wiring, use wires that comply with local regulations for your safety.</li> <li>Check following items after finishing the wiring:</li> <li>1. Are all connections correct?</li> <li>2. Are there any loosen wires?</li> <li>3. Are there any short circuits between the terminals or to ground?</li> </ul>   |


# 4-1 Wiring Diagram

# 1. Normal Wiring Diagram




PLC1.ir

- \*1 Select the NFB based on the drive type.
- \*2 If a reactor is connected to the drive, install the reactor here (optional).
- \*3 Refer to 05 Optional Accessories for the selection of fuses.
- \*4 The cable length between REG2000 EMI filter and the Power Regenerative Unit must be less than 10 m, and cannot provide power to other equipment from here. While using the REG2000 EMI filter, remove the RFI jumper on the Power Regenerative Unit.
- \*5 The length of the DC+/DC- wires must be less than 5 m, and twisted wires are highly recommended.
- \*6 There is an attached DC choke shipped with the unit; install it as shown in the above wiring diagram. The P1, P2, N1, N2 in Normal Wiring Diagram is equal to the terminal 1, 2, 3, 4 in the Dimensions of DC Choke (Diagram 2). Installing the included DC choke can increase the regenerative efficiency and prevent electromagnetic interference. The DC choke part numbers in the REG2000 series are in Table 1.
- \*7 If there is no REG2000 EMI filter, we recommend using inductors (without capacitors) as the EMI filter for AC motor drives in order to prevent capacitors from being damaged by current ripples. If you have any concern about phase sequence protection, install Delta's EMI filter.
- \*8 If you need to provide power to other instruments, we recommend using the magnetic contactor (MC) terminals or NFB to connect to other instruments.
- \*9 If there is no keypad for the unit, refer to Pr.02-00–Pr.02-04 for detailed wiring of the multi-function input terminal (MIx, default setting is MI1). Wiring for auto mode is shown below.




\*10 There are two wiring methods of multi-function input terminal (MIx). Refer to the Diagram 1.

Diagram 1: SINK (NPN) /SOURCE (PNP) Mode switching terminal descriptions



# PLC1.ir

## Diagram 2: Dimensions of DC choke




Make sure that P, N terminals (DC BUS) do not short through while installing DC chokes.
 The DC choke wiring sizes are defined in the user manual. See Section 4-10, 4-11, and 4-12 for recommended wire sizes for different frames.

| REG Model Name | Model of DC Choke<br>(standard accessory) | Weight (g/unit) |  |  |
|----------------|---|-----------------|--|--|
| REG075A23A-21  | RG-RC110D2                                | 836             |  |  |
| REG110A23A-21  | KG-KCT10D2                                | 000             |  |  |
| REG150A23A-21  |   |                 |  |  |
| REG185A23A-21  | RG-RC220D2                                | 900             |  |  |
| REG220A23A-21  |   |                 |  |  |
| REG300A23A-21  | RG-RC370D2                                | 1086            |  |  |
| REG370A23A-21  | RG-RC370D2                                | 1000            |  |  |
| REG075A43A-21  |   |                 |  |  |
| REG110A43A-21  | RG-RC150D4                                | 838             |  |  |
| REG150A43A-21  |   |                 |  |  |
| REG185A43A-21  |   |                 |  |  |
| REG220A43A-21  | RG-RC300D4                                | 1058            |  |  |
| REG300A43A-21  |   |                 |  |  |
| REG370A43A-21  |   |                 |  |  |
| REG450A43A-21  | RG-RC550D4                                | 1220            |  |  |
| REG550A43A-21  |   |                 |  |  |

## 2. Multiple AC Motor Drives Wiring

- The following are important points for your attention.
  - A. Refer to the diagram below to wire the unit.
    - 1) Follow the motor drive specifications to choose the appropriate non-fuse breaker (NFB) and the magnetic contactor (MC).
    - 2) Connect an input reactor to a motor drive following the instructions in the user manual. A 3% AC input reactor is recommended. Connect an input reactor to the motor drive with the shortest distance possible.
    - 3) See Section 5-3 to choose an appropriate fuse.
    - 4) The maximum cable length between a REG2000 and an EMI filter cannot be more than 10 m. Remove the RFI jumper before you install an EMI filter.
    - 5) DO NOT install any other Power Regenerative Unit on the common DC BUS.
    - 6) The maximum cable length between DC+ and DC- cannot be more than 5 m. Twisted pair is recommended.
    - 7) Follow the wiring diagram to install the DC reactor (standard accessory) to reduce the electromagnetic interference (EMI) and to increase the work efficiency.
    - 8) Follow the specifications in Section 5-4 to choose an appropriate EMI filter to avoid strong electromagnetic interference (EMI).
  - B. Make sure that your AC motor drives can operate on a common DC BUS at first. Verify that the AC motor drives have the correct specifications.
  - C. In order to choose the proper Power Regenerative Unit, first confirm the maximum regenerative energy while all AC motor drives work at the same time.
  - D. For one-to-many installation, install a fuse (Fuse A/B/C..., as shown in the diagram below) at the DC input side of every drive. Calculate and select a suitable fuse for every drive: Fuse type = (Rated input current of the drive) x 2.5.




Multiple AC Motor Drives Wiring Diagram

3. Multiple REG2000 Wiring in Parallel

The following are important points for your attention.

- A. Install a maximum of four Power Regenerative Units working in parallel at the same time.
  - 1) Follow the motor drive specifications to choose the appropriate non-fuse breaker (NFB) and the magnetic contactor (MC).
  - 2) Connect an input reactor to a motor drive following the instructions in the user manual. A 3% AC input reactor is recommended. Connect an input reactor to the motor drive with the shortest distance possible.
  - 3) See Section 5-3 to choose an appropriate fuse.
  - 4) The maximum cable length between a REG2000 and an EMI filter cannot be more than 10 m. Remove the RFI jumper before you install an EMI filter.
  - 5) DO NOT install any other Power Regenerative Unit on the common DC BUS.
  - 6) The maximum cable length between DC+ and DC- cannot be more than 5 m. Twisted pair is recommended.
  - 7) Follow the wiring diagram to install the DC reactor (standard accessory) to reduce the electromagnetic interference (EMI) and to increase the work efficiency.
  - 8) Follow the specifications in Section 5-4 to choose an appropriate EMI filter to avoid strong electromagnetic interference (EMI).
- B. A DC choke is required. Install the DC choke as close to each Power Regenerative Unit as possible.
- C. Refer to the following diagram for wiring in parallel mode. Note that the wiring that connects to Power Regenerative Unit 2 comes from the AC motor drive DC BUS, and not directly from Power Regenerative Unit 1. Using copper bars for wiring is highly recommended.
- D. The following diagram shows wiring in parallel mode. Refer to Pr.02-00–Pr.02-04 for detailed wiring of multi-function input terminal (MIx, default setting is MI5) to connect to the terminal DCM. Working in parallel, each Power Regenerative Unit reduces its current limit to 80% automatically. If the Power Regenerative Unit is in parallel mode, and continuous regenerative power is required, you can still select the capacity for single units based on 80% of the rated output.




Multiple REG2000 Wiring Diagram in Parallel

# 4-2 Main Circuit Terminals

Remove the top cover before wiring the main circuit terminals.


The unit shown in the figures are for reference only and your drive may look different.

# Removing the outer cover for wiring



Frame C


Frame A, B



# Main Circuit Terminal Specifications

Frame A

Main Circuit Terminals



| REG2000 Frame A |                          |                                 |  |                          |                          |  |  |  |  |
|-----------------|--------------------------|---------------------------------|--|--------------------------|--------------------------|--|--|--|--|
|                 | Terminals: I             | R/L1, S/L2, T/L3,               | -/DC+, +/DC+                                 | Terminals:               |                          |  |  |  |  |
| Model Name      | Maximum<br>Wire<br>Gauge | Minimum<br>Wire<br>Gauge        | Screw Size<br>Tightening<br>Torque<br>(±10%) | Maximum<br>Wire<br>Gauge | Minimum<br>Wire<br>Gauge | Screw Size<br>Tightening<br>Torque<br>(±10%) |  |  |  |
| REG075A23A-21   |                          | 6 mm²<br>[10 AWG]               |  | 6 mm²<br>[10 AWG]        | 6 mm²<br>[10 AWG]        |  |  |  |  |
| REG110A23A-21   | 10 mm²                   | 10 mm²<br>[8 AWG]               | M4<br>12 kg-cm<br>(10.4 lb-in.)              | 10 mm²<br>[8 AWG]        | 10 mm²<br>[8 AWG]        | M4   |  |  |  |
| REG075A43A-21   | [8 AWG]                  | 2.5 mm <sup>2</sup><br>[14 AWG] |  | 2.5 mm²<br>[14 AWG]      | 2.5 mm²<br>[14 AWG]      | 12 kg-cm<br>(10.4 lb-in.)                    |  |  |  |
| REG110A43A-21   |                          | 6 mm²<br>[10 AWG]               | (1.2 N-m)                                    | 6 mm²<br>[10 AWG]        | 6 mm²<br>[10 AWG]        | (1.2 N-m)                                    |  |  |  |
| REG150A43A-21   |                          | 6 mm²<br>[10 AWG]               |  | 6 mm²<br>[10 AWG]        | 6 mm²<br>[10 AWG]        |  |  |  |  |


- □ If you install at Ta 50°C environment, select copper wire with voltage rating of 600 V and temperature resistance of 75°C or 90°C.
- □ If you install at Ta 50°C above environment, select copper wire with voltage rating of 600 V and temperature resistance of 90°C or above.
- □ For UL installation compliance, use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wires.

Unit: mm

| AWG | VENDOR | VENDOR<br>P/N | A<br>(MAX.) | B<br>(MAX.) | C<br>(MIN.) | D<br>(MAX.) | d2<br>(MIN.) | E<br>(MIN.) | F<br>(MIN.) | W<br>(MAX.) | t<br>(MAX.) |
|-----|--------|---------------|-------------|-------------|-------------|-------------|--------------|-------------|-------------|-------------|-------------|
| 14  |        | RNBL2-4       |             |             |             |             |              |             |             |             |             |
| 10  | KST    | RNBL5-4       | 20          | 5           | 5.5         | 9           | 4.3          | 8           | 5.5         | 10          | 1.5         |
| 8   |        | RNBS8-4       |             |             |             |             |              |             |             |             |             |


# 

- Use Figure 1 to choose terminal wire size.
- As shown in Figure 2, use insulated heat shrink tubing that is resistant to at least 600 V<sub>AC</sub> to comply with UL and CSA regulations (600 V<sub>AC</sub>, YDPU2).



# Frame B

Main Circuit Terminals



|               |                          | R                        | EG2000 Frame E                               | 3                        |                          |  |  |
|---------------|--------------------------|--------------------------|--|--------------------------|--------------------------|--|--|
|               | Terminals: I             | R/L1, S/L2, T/L3         | , -/DC+, +/DC+                               | Terminals:               |                          |  |  |
| Model Name    | Maximum<br>Wire<br>Gauge | Minimum<br>Wire<br>Gauge | Screw Size<br>Tightening<br>Torque<br>(±10%) | Maximum<br>Wire<br>Gauge | Minimum<br>Wire<br>Gauge | Screw Size<br>Tightening<br>Torque<br>(±10%) |  |
| REG150A23A-21 |                          | 16 mm²<br>[6 AWG]        |  | 16 mm²<br>[6 AWG]        | 16 mm²<br>[6 AWG]        |  |  |
| REG185A23A-21 | 25 mm²<br>[4 AWG]        | 25 mm²<br>[4 AWG]        | M6   | 25 mm²<br>[4 AWG]        | 16 mm²<br>[6 AWG]        | M6   |  |
| REG220A43A-21 |                          | 25 mm²<br>[4 AWG]        | 31 kg-cm<br>(26.9 lb-in.)                    | 25 mm²<br>[4 AWG]        | 16 mm²<br>[6 AWG]        | 31 kg-cm<br>(26.9 lb-in.)                    |  |
| REG185A43A-21 |                          | 10 mm²<br>[8 AWG]        | `(3.0 N-m)´                                  | 10 mm²<br>[8 AWG]        | 10 mm²<br>[8 AWG]        | `(3.0 N-m)´                                  |  |
| REG220A43A-21 |                          | 10 mm²<br>[8 AWG]        |  | 10 mm²<br>[8 AWG]        | 10 mm²<br>[8 AWG]        |  |  |
| REG300A43A-21 |                          | 16 mm²<br>[6 AWG]        |  | 16 mm²<br>[6 AWG]        | 16 mm²<br>[6 AWG]        |  |  |

- □ If you install at Ta 50°C environment, select copper wire with voltage rating of 600 V and temperature resistance of 75°C or 90°C.
- □ If you install at Ta 50°C above environment, select copper wire with voltage rating of 600 V and temperature resistance of 90°C or above.
- For UL installation compliance, use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wires.

Unit: mm

| AWG | VENDOR | VENDOR<br>P/N | A<br>(MAX.) | B<br>(MAX.) | C<br>(MIN.) | D (MAX.) | d2<br>(MIN.) | E<br>(MIN.) | F<br>(MIN.) | W<br>(MAX.) | t<br>(MAX.) |
|-----|--------|---------------|-------------|-------------|-------------|----------|--------------|-------------|-------------|-------------|-------------|
| 8   |        | RNBL8-6       |             |             |             |          |              |             |             |             |             |
| 6   | KST    | RNBS14-6      | 25.5        | 7.5         | 8.5         | 13       | 6.2          | 13          | 10          | 15          | 1.5         |
| 4   |        | RNBS22-6      |             |             |             |          |              |             |             |             |             |

# 

- Use Figure 1 to choose terminal wire size.
- As shown in Figure 2, use insulated heat shrink tubing that is resistant to at least 600 V<sub>AC</sub> to comply with UL and CSA regulations (600 V<sub>AC</sub>, YDPU2).






Figure 1.



# Frame C

Main Circuit Terminals



|               | REG2000 Frame C                           |                          |  |                          |                          |  |  |  |
|---------------|---|--------------------------|--|--------------------------|--------------------------|--|--|--|
|               | Terminals: R/L1, S/L2, T/L3, -/DC+, +/DC+ |                          |  | Terminals:               |                          |  |  |  |
| Model Name    | Maximum<br>Wire<br>Gauge                  | Minimum<br>Wire<br>Gauge | Screw Size<br>Tightening<br>Torque<br>(±10%) | Maximum<br>Wire<br>Gauge | Minimum<br>Wire<br>Gauge | Screw Size<br>Tightening<br>Torque<br>(±10%) |  |  |
| REG300A23A-21 |   | 35 mm²<br>[2 AWG]        |  | 35 mm²<br>[2 AWG         | 16 mm²<br>[6 AWG]        |  |  |  |
| REG370A23A-21 | 50  | 50 mm²<br>[1/0 AWG]      | M8   | 50 mm²<br>[1/0 AWG]      | 25 mm²<br>[4 AWG]        | M8   |  |  |
| REG370A43A-21 | 50 mm²<br>[1/0 AWG]                       | 25 mm²<br>[4 AWG]        | 81.5 kg-cm<br>(70.8 lb-in.)                  | 25 mm²<br>[4 AWG]        | 16 mm²<br>[6 AWG]        | 81.5 kg-cm<br>(70.8 lb-in.)                  |  |  |
| REG450A43A-21 |   | 25 mm²<br>[4 AWG]        | (8 N-m)                                      | 25 mm²<br>[4 AWG]        | 16 mm²<br>[6 AWG]        | (8 N-m)                                      |  |  |
| REG550A43A-21 |   | 35 mm²<br>[2 AWG]        |  | 35 mm²<br>[2 AWG]        | 16 mm²<br>[6 AWG]        |  |  |  |


- □ If you install at Ta 50°C environment, select copper wire with voltage rating of 600 V and temperature resistance of 75°C or 90°C.
- □ If you install at Ta 50°C above environment, select copper wire with voltage rating of 600 V and temperature resistance of 90°C or above.
- For UL installation compliance, use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wires.

| Unit: | mm |
|-------|----|
| Onit. |    |

| AWG | VENDOR | VENDOR<br>P/N | A<br>(MAX.) | B<br>(MAX.) | C<br>(MIN.) | D<br>(MAX.) | d2<br>(MIN.) | E<br>(MIN.) | F<br>(MIN.) | W<br>(MAX.) | t<br>(MAX.) |
|-----|--------|---------------|-------------|-------------|-------------|-------------|--------------|-------------|-------------|-------------|-------------|
| 6   |        | RNB14-8       |             |             |             |             |              |             |             |             |             |
| 4   | кѕт    | RNB22-8       | 40.0        | 11.0        | 9.5         | 22.0        | 8.3          | 13.0        | 11.0        | 24.0        | 2.5         |
| 2   |        | RNBS38-8      |             |             |             |             |              |             |             |             |             |
| 1/0 |        | RNB60-8       |             |             |             |             |              |             |             |             |             |

# 

- Use Figure 1 to choose terminal wire size.
- As shown in Figure 2, use insulated heat shrink tubing that is resistant to at least 600 V<sub>AC</sub> to comply with UL and CSA regulations (600 V<sub>AC</sub>, YDPU2).



# 

#### Main circuit power input terminals

- ☑ Do not connect a three-phase model to single-phase power. R/L1, S/L2 and T/L3 have no phase-sequence requirement.
- ☑ Normally, based on local regulations, installing a non-fuse breaker as system protection on the connection between three-phase input power and main circuit terminal (R/L1, S/L2 and T/L3) is required. However, it is recommended to add a magnetic contactor (MC) to the power input wiring to cut off power quickly and reduce malfunction when activating the Power Regeneration Unit protection function. (Both ends of the MC should have an R-C surge absorber to prevent abnormal voltage surge caused by sudden current breakdown, further causing flashover to damage the equipment.)
- ☑ Tighten the screws in the main circuit terminal to prevent sparks caused by screws loosened by vibration.
- ☑ Use specified voltage and current and pay attention to the maximum allowance.
- ☑ When using a general GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200 mA or above and not less than 0.1-second operation time to avoid nuisance tripping.
- ☑ Use shielded wire or conduit for the power wiring and ground the two ends of the shielded wire or conduit.

# 4-3 Control Circuit Terminals


Remove the top cover before wiring the multi-function input and output terminals.

The units shown in the figures are for reference only and your drive may look different.


# Removing the outer cover for wiring

1) Screw torque: 14–16 kg-cm [12.15–13.88 lb-in.] (1.37–1.57 Nm).

Loosen the screws for the wiring top cover as shown in the diagrams below.



# PLC1.ir



# PLC1.ir

| (A)<br>SG- M01 M02 MI2 MI4 COM DCM<br>SG+ MCM MI1 MI3 MI5 E24V (B) |  |
|--|--|

# **Control Terminal Specifications**

|          |       | Tightening   |                     |                       |                       |   |
|----------|-------|--------------|---------------------|-----------------------|-----------------------|---|
| Function | Group | Conductor    | Stripping<br>Length | Minimum<br>Wire Gauge | Maximum<br>Wire Gauge | Torque<br>(±10%)                        |
| Control  | A     | Solid/Strand | 6                   | 0.2 mm²               | 1.5 mm²               | 5.1 kg-cm<br>[4.42 lb-in.]<br>[0.5 Nm]  |
| Terminal | В     | Solid/Strand | 6 mm                | [26 AWG]              | [16 AWG]              | 5.6 kg-cm<br>[4.86 lb-in.]<br>[0.55 Nm] |

To set to auto-mode without a keypad, wire the Power Regenerative Unit to go through a multi-function input terminal (MIx, default setting is MI1) to connect to the terminal DCM.

Wiring notes:

 The default for E24V-COM is short circuit and SINK mode (NPN). Refer to Diagram 1 in Section 4-1 Wiring Diagram.

| Terminal        | Function Description   | Default (NPN mode)  |
|-----------------|--|---|
| E24V            | The default for +24 V-COM is short circuit and SINK mode (NPN) (Source). | +24 V ± 5% 200 mA   |
| СОМ             | Common terminal for digital control signals (Sink)                       | Common terminal for multi-function inputs   |
| MI1<br>_<br>MI5 | Multi-function input 1–5   | Refer to Pr.02-00–Pr.02-04 to program the<br>multi-function inputs MI1–MI5.<br>ON: the activation current is 6.5 mA $\ge$ 11 V <sub>DC</sub> ;<br>OFF: leakage current tolerance is 10 µA $\le$ 5 V <sub>DC</sub> |
| DCM             | Common terminal for digital control signals (Sink)                       | Common terminal for multi-function inputs   |
| MO1             | Multi-function output 1 (photo coupler)                                  | The Power Regeneration Unit releases various monitor signals, using a transistor (open collector).  |

| Terminal | Function Description                          | Default (NPN mode)                            |
|----------|---|---|
| MO2      | Multi-function output 2 (photo coupler)       | MO1<br>MO2<br>MCM                             |
| МСМ      | Common terminal for<br>multi-function outputs | Max 48 V <sub>DC</sub> 50 mA                  |
| RA1      | Multi-function relay output 1                 | Resistive load                                |
|          | (N.O.) a                                      | 5 A (N.O.)/3 A (N.C.) 250 V <sub>AC</sub>     |
| RB1      | Multi-function relay output 1                 | 5 A (N.O.)/3 A (N.C.) 30 V <sub>DC</sub>      |
| RDI      | (N.C.) b                                      | N.O. minimum load: 5 V/0.1 A; 24 V/ 3 mA      |
|          |   | N.C. minimum load: 5 V/ 0.1 A; 24 V/ 3 mA     |
|          |   | Inductive load (COS 0.4)                      |
| RC1      | Common terminal for                           | 2.0 A (N.O.)/1.2 A (N.C.) 250 V <sub>AC</sub> |
| RUI      | multi-function relays                         | 2.0 A (N.O.)/1.2 A (N.C.) 30 V <sub>DC</sub>  |
|          |   | Outputs various monitoring signals.           |
|          |   | N.O. minimum load: 5 V/ 0.1 A; 24 V/3 mA      |
|          |   | N.C. minimum load: 5 V/ 0.1 A; 24 V/3 mA      |
| SG+      | Modbus RS-485                                 |   |
| <u></u>  | PIN 1, 2, 7, 8: Reserved PIN                  | N 3, 6: GND                                   |
| SG-      | PIN 4: SG- PIN 5                              | 5: SG+  |

NOTE: Analog control signals wire size: 18 AWG (0.75 mm<sup>2</sup>) with shielded wire

#### Contact Input Terminals (MI1–MI5, COM)

When using contacts or switches to control the input terminals, use high quality components to prevent contact bounce.

#### Transistor Output Terminals (MO1, MO2, MCM)

- Make sure to connect the digital outputs to the correct polarity.
- When connecting a relay to the digital outputs, connect a surge absorber across the coil and check the polarity.

# 4-4 Display Panel Indicators

# **Display Panel**

| ««REG  | IENERA                       | TE                       |
|--|------------------------------|--------------------------|
|  |                              |                          |
| ◇ 红灯长亮 / RG  | d ON: -\${- R                |                          |
| 。 绿灯长亮 / Gr  | een ON: -> - G</td <td></td> |                          |
|  | d Blinking: 🔆                | $\mathbb{R}$             |
| ◇绿灯闪烁/Gr   | een Blinking:                | ¢G () ()                 |
| ◇ 熄灭/ OFF: (   | $\supset$                    | ALARM POWER              |
| 警报(ALARM)  | 电源(POWER)                    | 状态描述(status description) |
| $\bigcirc$   | ÷.R                          | 准备完成 (READY)             |
| 0  | -):- G                       | 运转 (RUN)                 |
| 0  | )¢ G                         | 回生 (REGENERATE)          |
| -ò∳- R   | )¢ R                         | 过电压(OV)                  |
| ÷ķ-R   | ) G                          | 外部错误 (EF)                |
| -<br>K<br>R  | -¢f-R                        | 过负载 (OL)                 |
| Þ. R   | -¢f:R                        | 温度异常 (OH)                |
| - Provense in the second secon | 0                            | <b>过电流 (</b> 0C)         |
| þ. R   | )k R                         | <b>通讯异常 (</b> Comm.Err.) |
| )<br>K R   | 0                            | 电源异常(MAINS Err.)         |
|  | ) G                          | 硬件/内存异常(HW Err.)         |

# Power & Alarm Indicator Status Descriptions

| ALARM                          | POWER                          | Description                                  | Note  |
|--------------------------------|--------------------------------|--|---|
| Blinking red + green<br>lights | Blinking red + green<br>lights | Prepare*                                     | Once the Power<br>Regenerative Unit is<br>powered on, it performs<br>auto-system checking.  |
| OFF                            | Constant red light ON          | Ready**                                      | Once the Power<br>Regenerative Unit is<br>powered on, if there are no<br>faults or warnings and<br>phase lock is completed,<br>you can now send the RUN<br>command. |
| OFF                            | Constant green light ON        | RUN**  | Once you send the RUN<br>command, the Power<br>Regenerative Unit runs<br>smoothly and waits for the<br>conditions to regenerate<br>energy.                          |
| OFF                            | Blinking green light           | REGENERATE**                                 | Power Regenerative Unit regenerates AC current to the mains power.  |
| ALARM                          | POWER                          | Description                                  | Fault/Warning Name<br>Corresponds to the Keypad   |
| Constant red light ON          | Blinking red light             | OV (Over-voltage)                            | ovn, ovs  |
| Constant red light ON          | Blinking green light           | EF (External fault)                          | EF  |
| Constant red light ON          | Constant red light ON          | OL (Overload)                                | oL  |
| Blinking red light             | Constant red light ON          | OH (Overheat)                                | oH1, oH2, tH1o, tH2o  |
| Constant red light ON          | OFF                            | OC (Over-current)                            | ocn, ocs  |
| Blinking red light             | Blinking red light             | Comm. Err.<br>(Communication<br>fault)       | Pco, CE1, CE2, CE3, CE4,<br>CE10, SE1, SE2, SE3   |
| Blinking red light             | OFF                            | Mains Err.<br>(Mains power<br>error)         | Phase loss (OrP), phase<br>lock (PLE) and low direct<br>voltage (LvS) warning at<br>input.  |
| Blinking green light           | Blinking green light           | HW Err.<br>(Hardware fault/<br>memory fault) | cd1, cd2, cd3, Hd1, Hd2,<br>5VF, RYF, cF1, cF2  |

\*The start-up time is too short, so there is no message on the keypad.

\*\*Different regeneration statuses are defined in Diagram 3 below.




Diagram 3: The Definition of Different Working Status of Power Regeneration

# **05 Optional Accessories**

The optional accessories listed in this chapter are available upon request. These accessories can improve your Power Regeneration Unit's performance. Select the accessories you need or contact your local distributor for suggestions.

**Optional Accessories:** 

- 5-1 Digital Keypad
- 5-2 USB/RS-485 Communication Interface IFD6500, IFD6530
- **5-3 Fuse Specification Chart**
- 5-4 EMI Filter
- 5-5 External Power Supply Card (24 V) EMC-BPS01
- 5-6 Fan Kit

# 5-1 Digital Keypad

#### KPC-CC01 **KPC-CE01** VFD-Cx VFD·Cx ERR RUN CAN-F1 F2 F3 F4 MENU ESC CAN EF ^ ESC ^ MENU < ENTER > ENTER < > HAND Αυτο HAND Αυτο RUN FWD STO RUN

Communication interface RJ45 (socket), RS-485 interface

#### Installation Method

- ✓ The embedded type can be installed flat on the surface of the control box. The front cover is waterproof.
- Buy a MKC-KPPK model for wall mounting or embedded mounting. Its protection level is IP56.

| Keys       | Description  |  |  |  |  |  |
|------------|--|--|--|--|--|--|
| ESC        | ESC Key  |  |  |  |  |  |
|            | Return to the previous page. This also returns you to the last category in the sub-menu.   |  |  |  |  |  |
| MENU       | Menu Key   |  |  |  |  |  |
|            | Return to the main MENU.   |  |  |  |  |  |
|            | Menu content:  |  |  |  |  |  |
|            | 1. Parameter Detail 3. Keypad Locked 5. PLC copy   |  |  |  |  |  |
|            | 2. Copy Parameter 4. PLC function 6. Fault Record  |  |  |  |  |  |
|            |  |  |  |  |  |  |
|            | REG does not support menu item 4 and 5 (PLC functions).  |  |  |  |  |  |
| ENTER      | ENTER Key  |  |  |  |  |  |
|            | Go to the next level. If it is the last level, then press ENTER to execute the command.  |  |  |  |  |  |
| HAND       | No assigned function   |  |  |  |  |  |
| AUTO       | No assigned function   |  |  |  |  |  |
| FWD/REV    | No assigned function   |  |  |  |  |  |
| RUN        | Start Operation Key  |  |  |  |  |  |
|            | It is only valid when you issue the operation command from the keypad.   |  |  |  |  |  |
|            | The drive runs according to the function setting and the RUN LED is ON.  |  |  |  |  |  |
|            | ✓ You can press the RUN key many times during the Power Regeneration Unit's stop   |  |  |  |  |  |
|            | process.   |  |  |  |  |  |
| STOP/RESET |  |  |  |  |  |  |
|            | The STOP key has the highest priority in command. With the STOP key has the STOP key the Description like the term of the store start in the store |  |  |  |  |  |
|            | When you press the STOP key, the Power Regenerative Unit stops under any condition.  |  |  |  |  |  |
|            | ☑ Use the RESET key to reset the Power Regenerative Unit when faults occur.  |  |  |  |  |  |
|            | If the RESET key is not responding, check MENU $\rightarrow$ Fault Record for the most recent  |  |  |  |  |  |
|            | fault.   |  |  |  |  |  |
|            |  |  |  |  |  |  |


| RUN         | STOP        | Description | Note  |
|-------------|-------------|-------------|---|
| Constant ON | Blinking    | Prepare     | Once the Power<br>Regenerative Unit is<br>powered on, it performs<br>auto-system checking.  |
| OFF         | Constant ON | Ready*      | Once the Power<br>Regenerative Unit is<br>powered on, if there are no<br>faults or warnings and<br>phase lock is completed,<br>you can now send the RUN<br>command. |
| Blinking    | Constant ON | RUN*        | Once you send the RUN<br>command, the Power<br>Regenerative Unit runs<br>smoothly and waits for the<br>conditions to regenerate<br>energy.                          |
| Constant ON | OFF         | REGENERATE* | Power Regenerative Unit regenerates AC current to the mains power.  |

# Digital keypad LED status description


\*See Diagram 3 in Section 4-4 for the definition of different working status of power regeneration.

# **KPC-CC01 & KPC-CE01 Dimensions**

Unit: mm [inch]




# Optional digital keypad RJ45 extension cable




| No.  | Part No.      |       | L     |
|------|---------------|-------|-------|
| INU. | Fait No.      | mm    | inch  |
| 1    | UC-CMC003-01A | 300   | 11.8  |
| 2    | UC-CMC005-01A | 500   | 19.6  |
| 3    | UC-CMC010-01A | 1000  | 39    |
| 4    | UC-CMC015-01A | 1500  | 59    |
| 5    | UC-CMC020-01A | 2000  | 78.7  |
| 6    | UC-CMC030-01A | 3000  | 118.1 |
| 7    | UC-CMC050-01A | 5000  | 196.8 |
| 8    | UC-CMC100-01A | 10000 | 393.7 |
| 9    | UC-CMC200-01A | 20000 | 787.4 |

- The Power Regenerative Unit is controlled by an external terminal MIx by default. You can also control the Power Regenerative Unit from the keypad.
  - Control from the digital keypad: Set Pr.01-04 = 2 to change to the digital keypad as the operation command source.
  - Control by an external terminal (default: MI1): Set Pr.01-04 = 1 to change to the external terminals as the operation command source. The Power Regenerative Unit activation level is <u>determined by the voltage level. It is not</u> <u>necessary to unplug and reconnect the external terminals.</u>

B How to remove the plastic cap?



1. Press the pin on top of the keypad.



2. Pull forward to remove the keypad.

# 5-2 USB/RS-485 Communication Interface IFD6500, IFD6530

# Caution

 $\checkmark$  Read this instruction sheet thoroughly before installation and operation.


✓ The contents of this instruction sheet and the driver file may be revised without prior notice. Consult our distributors or download the most updated instruction/driver version at http://www.delta.com.tw/product/em/control/cm/control\_cm\_main.asp

# Introduction

The IFD6530 is a convenient RS-485-to-USB converter, and does not require external power-supply or complex set up. It supports baud rates from 75–115.2 kbps and auto-switching of the direction of data transmission. It uses RJ45 in an RS-485 connectors for convenient wiring. Its tiny dimensions, use of plug-and-play and hot swapping make it easy to connect all DELTA IABU products to your PC.

Applicable Models: All DELTA IABU products.


Applications and Dimensions



# Specifications

| Power supply         | No external power is needed   |
|----------------------|---|
| Power consumption    | 1.5 W   |
| Isolation<br>voltage | 2,500 V <sub>DC</sub>   |
| Baud rate            | 75; 150; 300; 600; 1,200; 2,400; 4,800; 9,600; 19,200; 38,400; 57,600; 115,200 kbps |
| RS-485<br>connector  | RJ45  |
| USB connector        | A type (plug)   |
| Compatibility        | Full compliance with USB V2.0 specification   |
| Maximum cable length | RS-485 Communication Port: 100 m  |
| Supports RS-485      | half-duplex transmission  |

**RJ45** 



| PIN | Description |
|-----|-------------|
| 1   | Reserved    |
| 2   | Reserved    |
| 3   | GND         |
| 4   | SG-         |

| PIN    | Description     |
|--------|-----------------|
| 5      | SG+             |
| 6      | GND             |
| 7      | Reserved        |
| 8      | +9V             |
| 6<br>7 | GND<br>Reserved |


# Preparing for Driver Installation

Extract the driver file (IFD6530\_Drivers.exe) with following steps. You can find the driver file (IFD6530\_Drivers.exe) on the CD supplied with the IFD6530.

Note: DO NOT connect the IFD6530 to your PC before extracting the driver file.


#### STEP 1

#### STEP 2



# STEP 3

STEP 4





# STEP 5

You should now have a folder marked SiLabs under drive C (C:\ SiLabs).

# **Driver Installation**

After connecting the IFD6530 to your PC, install the driver by following these steps.





# LED Display

- 1. Steady green LED ON: power is ON.
- 2. Blinking orange LED: data is transmitting.

# 5-3 Fuse Specification Chart

- ☑ Use UL certified fuses for short circuit protection. For installation in the United States, branch circuit protection must be provided in accordance with the National Electrical Code (NEC) and any applicable local codes. Use UL classified fuses to fulfill this requirement.
- For installation in Canada, branch circuit protection must be provided in accordance with Canadian Electrical Code and any applicable provincial codes. Use UL classified fuses to fulfill this requirement.
- ☑ See Section 4-1 Wiring Diagram for fuse installation.

| Frame A       |        |  |  |  |  |  |
|---------------|--------|--|--|--|--|--|
| Model No.     | Ampere |  |  |  |  |  |
| REG075A23A-21 | 50     |  |  |  |  |  |
| REG110A23A-21 | 80     |  |  |  |  |  |
| REG075A43A-21 | 25     |  |  |  |  |  |
| REG110A43A-21 | 45     |  |  |  |  |  |
| REG150A43A-21 | 50     |  |  |  |  |  |
|               |        |  |  |  |  |  |

| Frame B       |        |  |  |  |  |  |
|---------------|--------|--|--|--|--|--|
| Model No.     | Ampere |  |  |  |  |  |
| REG150A23A-21 | 100    |  |  |  |  |  |
| REG185A23A-21 | 125    |  |  |  |  |  |
| REG220A23A-21 | 150    |  |  |  |  |  |
| REG185A43A-21 | 60     |  |  |  |  |  |
| REG220A43A-21 | 80     |  |  |  |  |  |
| REG300A43A-21 | 100    |  |  |  |  |  |
|               |        |  |  |  |  |  |

| Frame C       |        |  |  |  |  |  |
|---------------|--------|--|--|--|--|--|
| Model No.     | Ampere |  |  |  |  |  |
| REG300A23A-21 | 200    |  |  |  |  |  |
| REG370A23A-21 | 250    |  |  |  |  |  |
| REG370A43A-21 | 125    |  |  |  |  |  |
| REG450A43A-21 | 150    |  |  |  |  |  |
| REG550A43A-21 | 200    |  |  |  |  |  |

# 5-4 EMI Filter

# Cautions

In order to make sure that the EMI filter can bring out the maximum effect on suppressing the interference of the motor drive, apart from following the installation and wiring instructions in the user manual (Chapter 4 Wiring), pay attention to the following points should be noted:

# Marnings

 $\checkmark$  Before you use this product, please follow the **regular inspection and recommended steps** to make sure the normal operation of the product.

✓ After you have used this product, you have to do regular inspections according to the **regular** 

inspections and recommendations every six months. .

# **Precautions on Function**

After you install the Power Regenerative Unit, install an EMI filter on the power system to suppress high frequency interference.

Installing the EMI filter [suppressing electromagnetic interference and radio frequency interference

(CLASS A/3m)] makes the Power Regenerative Unit compliant with EN55011 regulations.

# **Specifications**

Input Voltage 230V series: 170–265  $V_{AC}$ , input from main circuit terminals L1, L2, and L3. 460V series: 323–528  $V_{AC}$ , input from main circuit terminals L1, L2, and L3.

Input Frequency 50 Hz (47–53) / 60 Hz (57–63)

#### Input Current

| Model      | Rated Current<br>when Running<br>Continuously<br>(Arms) |
|------------|---|
| RG-EF110A2 | 25.6  |
| RG-EF220A2 | 48  |
| RG-EF370A2 | 80  |
| RG-EF150A4 | 16  |
| RG-EF300A4 | 34.4  |
| RG-EF550A4 | 60  |

With variation in ED%, a Power Regenerative Unit can still function normally when overloaded. The rated output current of the EMI filter corresponds to that of the Power Regenerative Unit. Follow the table below to select an EMI filter. Delta ensures that all EMI filters are within output current specifications. Since there are many conditions and changes at the installation site of a Power Regenerative Unit and temperature rise during continuous operation is the harshest environment for the electronic components, only the rated current during continuous regeneration is listed in the table below.

#### **EMI Filter Specifications**

| Frame | REG2000 Model | REG EMI Filter | Weight(kg) |  |
|-------|---------------|----------------|------------|--|
| А     | REG075A23A-21 | RG-EF110A2     | 3.0±0.5    |  |
| A     | REG110A23A-21 | KG-EF HUAZ     | 5.0±0.5    |  |
|       | REG150A23A-21 |                |            |  |
| В     | REG185A23A-21 | RG-EF220A2     | 4.7±0.5    |  |
|       | REG220A23A-21 |                |            |  |
| С     | REG300A23A-21 | RG-EF370A2     | 6.2±0.5    |  |
| C     | REG370A23A-21 | KG-EF370AZ     |            |  |
|       | REG075A43A-21 |                | 3.1±0.5    |  |
| А     | REG110A43A-21 | RG-EF150A4     |            |  |
|       | REG150A43A-21 |                |            |  |
|       | REG185A43A-21 |                |            |  |
| В     | REG220A43A-21 | RG-EF300A4     | 5.0±0.5    |  |
|       | REG300A43A-21 |                |            |  |
|       | REG370A43A-21 |                |            |  |
| С     | REG450A43A-21 | RG-EF550A4     | 6.5±0.5    |  |
|       | REG550A43A-21 |                |            |  |

# **Terminal Specifications**

- Refer to Section 4-1 Wiring Diagram for details on EMI filter wiring.
- To avoid any interference, install the EMI filter on the Power Regenerative Unit for different applications as well as at the installation site.
- Frame A

|            | Main Circuit Terminals<br>R/L1 \ S/L2 \ T/L3 |                       |                               |                                     | Grounding Terminal          |                               |                               |                                     |
|------------|--|-----------------------|-------------------------------|-------------------------------------|-----------------------------|-------------------------------|-------------------------------|-------------------------------------|
| Model Name | Stripping<br>Length<br>(mm)                  | Max.<br>Wire<br>Gauge | Min. Wire<br>Gauge            | Screw Spec.<br>and Torque<br>(±10%) | Stripping<br>Length<br>(mm) | Max. Wire<br>Gauge            | Min. Wire<br>Gauge            | Screw Spec.<br>and Torque<br>(±10%) |
| RG-EF110A2 | 10   | 10 mm <sup>2</sup>    | 10 mm²<br>[8 AWG]             | 18 kg-cm                            | 10                          | 10 mm <sup>2</sup><br>[8 AWG] | 10 mm <sup>2</sup><br>[8 AWG] | 18 kg-cm                            |
| RG-EF150A4 | 10   | [8 AWG]               | 6 mm <sup>2</sup><br>[10 AWG] | [15.62 lb-in.]<br>[1.77 Nm]         | 10                          | 6 mm <sup>2</sup><br>[10 AWG] | 6 mm <sup>2</sup><br>[10 AWG] | [15.62 lb-in.]<br>[1.77 Nm]         |

1. Tighten the wiring with a Philips screwdriver. Specification of this Philips screwdriver: PH1

2. When wiring bare wires, ensure that they are perfectly arranged to go through the wiring holes.

3. If you install at Ta 40°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.

4. If you install at Ta 40°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.

5. To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire

# • Frame B

| Madal Nama |                             |                       | cuit Terminal<br>S/L2 ` T/L3 | S                                   | Grounding Terminal          |                    |                    |                                     |
|------------|-----------------------------|-----------------------|------------------------------|-------------------------------------|-----------------------------|--------------------|--------------------|-------------------------------------|
| Model Name | Stripping<br>Length<br>(mm) | Max.<br>Wire<br>Gauge | Min. Wire<br>Gauge           | Screw Spec.<br>and Torque<br>(±10%) | Stripping<br>Length<br>(mm) | Max. Wire<br>Gauge | Min. Wire<br>Gauge | Screw Spec.<br>and Torque<br>(±10%) |
| RG-EF200A2 | 13~15                       | 25 mm <sup>2</sup>    | 25 mm <sup>2</sup>           | 30.59 kg-cm<br>[26.55 lb-in.]       | 13~15                       | 25 mm <sup>2</sup> | 16 mm <sup>2</sup> | 30.59 kg-cm<br>[26.55 lb-in.]       |
| RG-EF300A4 | 15,215                      | [4 AWG]               | [4 AWG]                      | [3.0 Nm]                            | 15,915                      | [4 AWG]            | [6 AWG]            | [3.0 Nm]                            |

1. Tighten the wiring with a slotted screwdriver: Specification of the slotted screwdriver: the width of the blade

should be 5.5mm and the thickness of the blade should be 1.0mm.

- 2. When wiring bare wires, ensure that they are perfectly arranged to go through the wiring holes.
- 3. If you install at Ta 40°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.
- 4. If you install at Ta 40°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- 5. To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire

## • Frame C

|            | Main Circuit Terminals<br>R/L1 \ S/L2 \ T/L3 |                    |                                 |                                      | Grounding Terminal      |                                 |                               |                                      |
|------------|--|--------------------|---------------------------------|--------------------------------------|-------------------------|---------------------------------|-------------------------------|--------------------------------------|
| Model Name | Stripping<br>Length<br>(mm)                  | Max. Wire<br>Gauge | Min. Wire<br>Gauge              | Screw Spec.<br>and Torque<br>(±10%)) | Stripping<br>Length(mm) | Max. Wire<br>Gauge              | Min. Wire<br>Gauge            | Screw Spec.<br>and Torque<br>(±10%)) |
| RG-EF370A2 | 16~18  | 50 mm <sup>2</sup> | 50 mm <sup>2</sup><br>[1/0 AWG] | 61.18 kg-cm                          | 16, 19                  | 50 mm <sup>2</sup><br>[1/0 AWG] | 25 mm <sup>2</sup><br>[4 AWG] | 61.18 kg-cm                          |
| RG-EF550A4 | 10~18  | [1/0 AWG]          | 35 mm <sup>2</sup><br>[2 AWG]   | [53.10 lb-in.]<br>[6.0 Nm]           | 16~18                   | 35 mm <sup>2</sup><br>[2 AWG]   | 16 mm <sup>2</sup><br>[6 AWG] | [53.10 lb-in.]<br>[6.0 Nm]           |

1. Tighten the wiring with a slotted screwdriver: Specification of the slotted screwdriver: the width of the blade should be 5.5mm

and the thickness of the blade should be 1.0mm.

2. When wiring bare wires, ensure that they are perfectly arranged to go through the wiring holes.

 If you install at Ta 40°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.

 If you install at Ta 40°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.

5. To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire

#### 05 Optional Accessories | REG2000

# • Temperature Signal Terminal

| Terminal Name   |  | Cable Specifications |                      |                       |                |  |  |  |  |
|---|--|----------------------|----------------------|-----------------------|----------------|--|--|--|--|
| and Function  | Type of Conductor  | Stripping Length     | Max. Wire Gauge      | Min. Wire Gauge       | Torque (±10%)) |  |  |  |  |
| Tomporatura   | Hard Cable   |                      |                      |                       |                |  |  |  |  |
| Temperature<br>Signal   | Soft Cable   |                      | 2.5 mm <sup>2</sup>  | 0.2 mm <sup>2</sup>   | 5.10 kg-cm     |  |  |  |  |
| Terminal  | Soft cable with  | 7~8 mm               | [14 AWG]             | [24 AWG]              | [4.43 lb-in.]  |  |  |  |  |
| (TH)  | tube pre-insulating  |                      |                      |                       | [0.5 Nm]       |  |  |  |  |
|   | terminal   |                      |                      |                       |                |  |  |  |  |
| 1. Tighten tl   | 1. Tighten the wiring with a slotted screwdriver: Specification of the slotted screwdriver: the width of the |                      |                      |                       |                |  |  |  |  |
| blade should be 3.5mm and the thickness of the blade should be 0.6mm. |  |                      |                      |                       |                |  |  |  |  |
| 2. When wir   | ing bare wires, en   | sure that they ar    | e perfectly arranged | to go through the wir | ing holes.     |  |  |  |  |

# Ring Terminals of Temperature Signal Terminal specification:

|                      |        | Recommende | ed Ring Terminal | s Part# and Size |         |         |         |       |  |
|----------------------|--------|------------|------------------|------------------|---------|---------|---------|-------|--|
| AWG                  | VENDOR | VENDOR P/N | A (MAX)          | B (MAX)          | D (MAX) | W (MAX) |         |       |  |
| 0.2 mm <sup>2</sup>  |        | E0308      |                  |                  |         |         |         |       |  |
| [24 AWG]             |        | E0308      |                  |                  |         |         |         |       |  |
| 0.34 mm <sup>2</sup> |        | E0508      |                  |                  |         |         |         |       |  |
| [22 AWG]             |        | E0508      |                  |                  | 4.5mm   | 2.5mm   |         |       |  |
| 0.5 mm <sup>2</sup>  |        | E7508      |                  | 8mm              |         |         |         |       |  |
| [20 AWG]             | K.S.T  | E7508      | 15mm             |                  |         |         |         |       |  |
| 0.75 mm <sup>2</sup> | N.O.1  | E1008      | E1008            | E1008            | romm    | omm     | 4.01111 | 2.500 |  |
| [18 AWG]             |        | E1008      |                  |                  |         |         |         |       |  |
| 1.5 mm <sup>2</sup>  |        | E4500      | F4500            | E1500            | F1509   |         |         |       |  |
| [16 AWG]             |        | E1306      | E1508            |                  |         |         |         |       |  |
| 2.5 mm <sup>2</sup>  |        | E2508      |                  |                  |         |         |         |       |  |
| [14 AWG]             |        | E2306      |                  |                  |         |         |         |       |  |


#### NOTE:

#### **Definition of Size:**

**Size A :** It depends on the actual wiring space. **Size B :** It depends on the allowable depth of the terminal block


**Size D** : It depends on the distance between terminal blocks.

Size W : It depends on the allowable width.




## **EMI Filter Dimensions**

# [Frame A] RG-EF110A2; RG-EF150A4




| Frame | W      | W1     | Н       | H1      | H2      | S1     | S2     | S3     | D      | D1     | D2     |
|-------|--------|--------|---------|---------|---------|--------|--------|--------|--------|--------|--------|
| ~     | 130.0  | 90.0   | 310.0   | 298.0   | 298.0   | 5.5    | 5.5    | 5.5    | 80.0   | 33.0   | 61.0   |
| A     | [5.12] | [3.54] | [12.20] | [11.73] | [11.73] | [0.22] | [0.22] | [0.22] | [3.15] | [1.30] | [2.40] |

# [Frame B] RG-EF220A2; RG-EF300A4



| Frame | W      | W1     | Н       | H1      | H2      | S1     | S2     | S3     | D      | D1     | D2     |
|-------|--------|--------|---------|---------|---------|--------|--------|--------|--------|--------|--------|
| В     | 155.0  | 110.0  | 390.0   | 375.0   | 375.0   | 5.5    | 5.5    | 5.5    | 80.0   | 33.0   | 61.0   |
| В     | [6.10] | [4.33] | [15.35] | [14.76] | [14.76] | [0.22] | [0.22] | [0.22] | [3.15] | [1.30] | [2.40] |

# [Frame C] RG-EF370A2; RG-EF550A4



| Frame | W      | W1     | Н       | H1      | H2      | S1     | S2     | S3     | D      | D1     | D2     |
|-------|--------|--------|---------|---------|---------|--------|--------|--------|--------|--------|--------|
| 6     | 175.0  | 110.0  | 390.0   | 375.0   | 375.0   | 5.5    | 5.5    | 5.5    | 80.0   | 33.0   | 61.0   |
| C     | [6.89] | [4.33] | [15.35] | [14.76] | [14.76] | [0.22] | [0.22] | [0.22] | [3.15] | [1.30] | [2.40] |

# **Regular inspections and recommendations**

Long-term storage or long-term usage of capacitors lead to capacitor decay and cause product defects. So for your safety, we recommend that you follow the steps below to verify if the capacitors' condition is within the standard value before you use this product or every six months after the product has been used to make sure that this product can operate normally.

Tools required for inspection: a slotted screwdriver, a Phillips screwdriver, a multimeter (models which support measuring capacitance).

Inspection steps:

1. Disconnect the supply mains first

2. After confirming that all the related machinery/equipment have stopped running, disconnect REG and EMI filter. Then disconnect the supply mains terminal and the EMI filter, as shown in images 1 and 2.

#### NOTE:

After the disconnection, do NOT short-circuit the wires.





Image 1






# PLC1.ir

## Measuring the capacitance between the phases of EMI filers on REG2000.

Use a multimeter to measure the capacitance between the phases (R'-S' phase, S'-T' phase, T'-R' phase): **Capacitance Measurement** 

- 1. Connect the BLACK test lead to the COM terminal and the RED test lead to the V/ $\Omega$  terminal.
- 2. Set the rotary switch to position. Select measurement using the function key.
- 3. Observe polarity when measuring polarized capacitors.
- 4. Connect the test leads across the capacitor under measurement.





RG-EF110A2 and RG-EF150A4 don't have terminal blocks, but they have outgoing cords, so you only need to measure R'S'T' cords.

# Standard Rate of Capacitor (failure rate)

If two of three capacitances (R'-S' phase, S'-T' phase and T'-R' phase) are under their failure rate, you need to replace a new EMI filter right away. The table below lists the standard rates (in blue color) and the failure rates (in red color) with unit uF.


| Product Serial # |                           | After xxxxxxxx2110xxxx<br>21: year of production 2021<br>10 : week of productionw10 |  |  |  |  |
|------------------|---------------------------|---|--|--|--|--|
| RG-EF110A2       | 11.65 (10.3)              |   |  |  |  |  |
| RG-EF150A4       | 4.6 (4.0)                 |   |  |  |  |  |
| RG-EF220A2       | 22.35 ( <b>19.8</b> )     |   |  |  |  |  |
| RG-EF300A4       | 9.15 ( <mark>8.0</mark> ) |   |  |  |  |  |
| RG-EF370A2       | 31.65 (28.3)              |   |  |  |  |  |
| RG-EF550A4       | 14.85 (13.1)              | 12.35 (10.8)  |  |  |  |  |

Estimation by the failure rate: There are three capacitors in the EMI filter, when one of the capacitor's failure rate is over 15%, that means this capacitor is decaying. A decaying capacitor might cause malfunction of the REG2000 and even cause safety hazards.

# 5-5 External Power Supply Card (24 V) EMC-BPS01


Installing the EMC-BPS01

# **Installation**




## Removing the EMC-BPS01

# Removing As shown in the figure on the left, remove the two screws.



Twist to open the card clip, insert a slot type screwdriver into the hollow to prize the PCB off the card clip.



Twist to open the card clip to remove the PCB.


# PLC1.ir

#### EMC-BPS01

|                | Terminals   | Descriptions   |  |  |  |  |
|----------------|-------------|--|--|--|--|--|
|                |             | Input power: 24 V ± 5%   |  |  |  |  |
|                |             | Maximum input current: 0.5 A   |  |  |  |  |
|                |             | Note:  |  |  |  |  |
|                |             | 1) Do not connect any control circuit terminal on the Power Regenerative |  |  |  |  |
|                |             | Unit to this +24 V power terminal.                                       |  |  |  |  |
|                |             | 2) Do not connect DCM terminal on the Power Regenerative Unit to         |  |  |  |  |
|                | 24 V<br>GND | the EMC-BPS01 input terminal GND to keep insulation effective.           |  |  |  |  |
| External Power |             | Functions: When the EMC-BPS01 is the only Power Regenerative Unit        |  |  |  |  |
| Supply Card    |             | power supply, the communication works normally and the following         |  |  |  |  |
|                |             | functions are supported:   |  |  |  |  |
|                |             | Read/ Write parameters   |  |  |  |  |
|                |             | Keypad display   |  |  |  |  |
|                |             | All keys except the RUN key can be operated                              |  |  |  |  |
|                |             | Effective analog input   |  |  |  |  |
|                |             |  |  |  |  |  |
|                |             | The following functions are not supported:                               |  |  |  |  |
|                |             | (1) Relay output (RA1, RB1, RC1); (2) hot swapping                       |  |  |  |  |

Once you install the EMC-BPS01, set Pr.03-05 =1 to enable this external power supply card.


Multi-Input terminals (MI1– MI5) need an external power supply to function.




#### 05 Optional Accessories | REG2000

|           |              | Wire Size             | Screw Size            |                                     |
|-----------|--------------|-----------------------|-----------------------|-------------------------------------|
| Function  | Conductor    | Maximum<br>Wire Gauge | Minimum<br>Wire Gauge | Tightening Torque<br>(±10%)         |
| EMC-BPS01 | Solid/Strand | 0.5 mm²<br>[20 AWG]   | 0.2 mm²<br>[24 AWG]   | 5 kg-cm<br>[4.4 lb-in.]<br>[0.5 Nm] |

# 5-6 Fan Kit






Removing the Cooling Fan

#### Frame A

Cooling fan model: 『RG-FK00AAN』

Applicable models

REG075A23A-21, REG075A43A-21, REG110A23A-21, REG110A43A-21, REG150A43A-21







Cooling fan model: 『RG-FK00BAN』

Applicable models

REG150A23A-21, REG185A23A-21, REG185A43A-21,

REG220A23A-21, REG220A43A-21, REG300A43A-21






Frame C

Cooling fan model: 『RG-FK00CAN』

Applicable models

REG300A23A-21, REG370A23A-21, REG370A43A-21, REG450A43A-21, REG550A43A-21

Disconnect the fan's power and take out the fan by using a slotted screwdriver, as shown in the partially enlarged view below.



## 06 Summary of Parameter Settings

You can quickly look up the range and default for each parameter when you are setting parameter values. You can set, change, or reset parameter values using the digital keypad (optional) or through the

communications.

### 

- 1) Means you can set the parameter during operation.
- 2) For complete parameter descriptions, refer to Chapter 07 Descriptions of Parameter Settings.
- 3) When a Power Regenerative Unit is at <STOP>, which means it is not performing energy regeneration.

### **00 Display Parameters**

| Parameter codes | Parameter names         | Setting range     | Default   |
|-----------------|-------------------------|-------------------|-----------|
|                 |                         | 0: 230 V, 7.5 kW  |           |
|                 |                         | 1: 460 V, 7.5 kW  |           |
|                 |                         | 2: 230 V, 11 kW   |           |
|                 |                         | 3: 460 V, 11 kW   |           |
|                 |                         | 4: 230 V, 15 kW   |           |
|                 |                         | 5: 460 V, 15 kW   |           |
|                 |                         | 6: 230 V, 18.5 kW |           |
|                 | Power Regenerative Unit | 7: 460 V, 18.5 kW |           |
| 00-00           | Identity code           | 8: 230 V, 22 kW   | Read Only |
|                 |                         | 9: 460 V, 22 kW   |           |
|                 |                         | 10: 230 V, 30 kW  |           |
|                 |                         | 11: 460 V, 30 kW  |           |
|                 |                         | 12: 230 V, 37 kW  |           |
|                 |                         | 13: 460 V, 37 kW  |           |
|                 |                         | 15: 460 V, 45 kW  |           |
|                 |                         | 17: 460 V, 55 kW  |           |
|                 |                         | 0: 20 A           |           |
|                 |                         | 1: 10.5 A         |           |
|                 |                         | 2: 32 A           |           |
|                 |                         | 3: 17 A           |           |
|                 |                         | 4: 38 A           |           |
|                 | Power Regenerative Unit | 5: 20 A           |           |
| 00-01           | rated current display   | 6: 49 A           | Read Only |
|                 | Taled current display   | 7: 25 A           |           |
|                 |                         | 8: 60 A           |           |
|                 |                         | 9: 32 A           |           |
|                 |                         | 10: 80 A          |           |
|                 |                         | 11: 43 A          |           |
|                 |                         | 12: 100 A         |           |

### PLC1.ir

| Parameter<br>codes | Parameter names                       | Setting range                                    | Default   |
|--------------------|---------------------------------------|--|-----------|
|                    |                                       | 13: 49 A   |           |
|                    |                                       | 15: 60 A   |           |
|                    |                                       | 17: 75 A   |           |
| 00-02              | Software version                      | Read Only (Display according to shipped version) | Read Only |
| 00-03              | Display Power Regenerative            | Read Only  | Read Only |
|                    | Unit input current (A <sub>AC</sub> ) |  |           |
| 00-04              | Display mains frequency               | Read Only  | Read Only |
|                    | (Hz)                                  |  |           |
| 00-05              | Display DC BUS voltage                | Read Only  | Read Only |
|                    | (Vdc)                                 |  |           |
| 00-06              | Display power (kW)                    | -300.0–300.0                                     | Read Only |
| 00-07              | Reserved                              |  |           |
| 00-08              | Reserved                              |  |           |
| 00-09              | Display the low word of the           | 0.0–999.9  | Read Only |
|                    | kilowatt hours (kWh)                  |  |           |
|                    | regenerated by REG2000                |  |           |
| 00-10              | Display the high word of the          | 0–9999   | Read Only |
|                    | kilowatt hours (kWh)                  |  |           |
|                    | regenerated by REG2000                |  |           |
| 00-11              | Display the highest internal          | Read Only  | Read Only |
|                    | ambient temperature (°C)              |  |           |
|                    | (air outlet)                          |  |           |
| 00-12              | Display the highest power             | Read Only  | Read Only |
|                    | module's temperature (°C)             |  |           |
| 00-13              | Display internal ambient              | Read Only  | Read Only |
|                    | temperature (°C) (air outlet)         |  |           |
| 00-14              | Display power module's                | Read Only  | Read Only |
|                    | temperature (°C)                      |  |           |
| 00-15              | Display digital input ON/OFF          | Read Only  | Read Only |
|                    | status                                |  |           |
| 00-16              | Display digital output                | Read Only  | Read Only |
|                    | ON/OFF status                         |  |           |
| 00-17              | DC BUS voltage during a               | Read Only  | Read Only |
|                    | malfunction (V <sub>DC</sub> )        |  |           |
| 00-18              | Mains frequency during a              | Read Only  | Read Only |
|                    | malfunction (Hz)                      |  |           |
| 00-19              | Current during a malfunction          | Read Only  | Read Only |
|                    | (A)                                   |  |           |
| 00-20              | Fault record 1                        | 0: no error record                               | 0         |

| Parameter codes | Parameter names                                | Setting range                                       | Default   |
|-----------------|--|---|-----------|
| 00-21           | Fault record 2                                 | 3: ocn over-current during regeneration             | 0         |
| 00-22           | Fault record 3                                 | 6: ocs over-current at stop                         | 0         |
| 00-23           | Fault record 4                                 | 9: ovn over-voltage during regeneration             | 0         |
| 00-24           | Fault record 5                                 | 10: ovs over-voltage at stop                        | 0         |
| 00-25           | Fault record 6                                 | 15: OrP phase loss in output                        | 0         |
|                 |  | 16: oH1 power module overheated                     |           |
|                 |  | 17: oH2 internal ambient temperature overheated     |           |
|                 |  | (air outlet)  |           |
|                 |  | 18: tHo1 power module overheated protection         |           |
|                 |  | circuit error                                       |           |
|                 |  | 19: tHo2 internal ambient temperature overheated    |           |
|                 |  | protection circuit error                            |           |
|                 |  | 21: oL overload                                     |           |
|                 |  | 30: cF1 memory writing error                        |           |
|                 |  | 31: cF2 memory read error                           |           |
|                 |  | 37: Hd1 current detection error when powering on    |           |
|                 |  | 38: Hd2 voltage detection error when powering on    |           |
|                 |  | 42: 5VF 5 V control board error (firmware v.1.02    |           |
|                 |  | (included) and later)                               |           |
|                 |  | 43: RYF relay error (firmware v.1.02 (included) and |           |
|                 |  | later)  |           |
|                 |  | 49: EF external signal input fault                  |           |
|                 |  | 52: Pcod wrong password                             |           |
|                 |  | 54: cE1 communication error                         |           |
|                 |  | 55: cE2 communication error                         |           |
|                 |  | 56: cE3 communication error                         |           |
|                 |  | 57: cE4 communication error                         |           |
|                 |  | 58: cE10 communication time-out                     |           |
|                 |  | 66: PLE phase lock error                            |           |
| 00-26           | Low word in electricity bill                   |   | Read Only |
| 00-27           | High word in electricity bill                  |   | Read Only |
| 00-28           | Display input AC voltage<br>(V <sub>AC</sub> ) |   | Read Only |

### **01 Basic Parameters**

| Parameter<br>codes | Parameter names               | Setting range  | Default |
|--------------------|-------------------------------|--|---------|
| 01-00              | Reset parameters              | 0: no function                                       | 0       |
|                    |                               | 1: parameter cannot be written                       |         |
|                    |                               | 10: parameter reset                                  |         |
| <b>№</b> 01-01     | Select start-up display       | 0: mains frequency                                   | 0       |
|                    |                               | 1: DC BUS voltage (V <sub>DC</sub> )                 |         |
|                    |                               | 2: Output current (A <sub>AC</sub> )                 |         |
| <b>№</b> 01-02     | Enter parameter protection    | 1–9998,10000–65535                                   | 0       |
|                    | password                      | 0–2: number of incorrect passwords entered           |         |
| <b>№</b> 01-03     |                               | 1–9998,10000–65535                                   | 0       |
|                    | Set parameter protection      | 0: password not set or password entered successfully |         |
|                    | password                      | in Pr.01-02  |         |
|                    |                               | 1: parameters locked                                 |         |
| <b>№</b> 01-04     | Operation command source      | 1: controlled by external terminals                  | 1       |
|                    |                               | 2: controlled through the communication interface or |         |
|                    |                               | the digital keypad (KPC-CE01/ KPC-CC01)              |         |
| 01-05              | Reserved                      |  |         |
| 01-06              | Reserved                      |  |         |
| 01-07              | Reserved                      |  |         |
| 01-08              | DC BUS voltage activation     | 230V series: 30–100 V                                | 40      |
|                    | level (offset value)          | 460V series: 60–200 V                                | 80      |
| 01-09              | Reserved                      |  |         |
| <b>№</b> 01-10     | DC BUS voltage control P gain | 0–1000%  | 100     |
| <b>№</b> 01-11     | DC BUS voltage control I gain | 0–1000%  | 100     |
| <b>№</b> 01-12     | DC BUS voltage control        | 1–100 Hz   | 40      |
|                    | bandwidth                     |  |         |
| 01-13              | Reserved                      |  |         |
| <b>№</b> 01-14     | Select multi-function display | 0: display DC BUS voltage (v)                        | 0       |
|                    |                               | 1: display mains frequency (H)                       |         |
|                    |                               | 2: display output current (A)                        |         |
|                    |                               | 3: display output AC voltage (E)                     |         |
|                    |                               | 7: display power (P)                                 |         |
|                    |                               | 8: display current limit (p)                         |         |

### 02 Digital Input/Output Parameters

| Parameter codes | Parameter names                         | Setting range           | Default |
|-----------------|---|-------------------------|---------|
| 02-00           | Multi-function input command<br>1 (MI1) | 0: No function          | 1       |
| 02-01           | Multi-function input command 2 (MI2)    | 1: Automatic mode       | 0       |
| 02-02           | Multi-function input command 3 (MI3)    | 2: Reserved             | 3       |
| 02-03           | Multi-function input command<br>4 (MI4) | 3: External Fault (EF)  | 4       |
| 02-04           | Multi-function input command            | 4: RESET                | 5       |
|                 | 5 (MI5)                                 | 5: Parallel mode        |         |
|                 |   | 6: No function          |         |
| <b>≠</b> 02-05  | Digital input response time             | 0.001–30.000 sec.       | 0.005   |
| <b>≠</b> 02-06  | Digital input direction                 | 0–65535                 | 0       |
| ₩ 02-07         | Multi-function output 1<br>(Relay1)     | 0: No function          | 4       |
| € 02-08         | Multi-function output 2 (MO1)           | 1: Regenerate indicator | 3       |
| <b>№</b> 02-09  | Multi-function output 3 (MO2)           | 2: RUN indicator        | 0       |
|                 |   | 3: Ready indicator      |         |
|                 |   | 4: Error indicator      |         |
|                 |   | 5: No function          |         |
|                 |   | 6: Warn indicator       |         |
|                 |   | 7: No function          |         |
| <b>≠</b> 02-10  | Multi-function output direction         | 0–65535                 | 0       |

### **03 Special Protection Parameters**

| Parameter      | Deveneter nemes                | Catting range                                    | Default |
|----------------|--------------------------------|--|---------|
| codes          | Parameter names                | Setting range                                    | Default |
| <b>≠</b> 03-00 | Low voltage level              | 230V series:160.0–220.0 V                        | 180.0   |
|                |                                | 460V series:320.0–440.0 V                        | 360.0   |
| <b>≠</b> 03-01 | Current limit                  | 0–150%   | 150     |
| <b>≠</b> 03-02 | Reserved                       |  |         |
| <b>№</b> 03-03 | Reserved                       |  |         |
| <b>№</b> 03-04 | Phase lock frequency           | 0–1000 ms  | 150     |
|                | deviation time                 |  |         |
| <b>№</b> 03-05 | External power supply card     | 0: EMC-BPS01 disabled                            | 0       |
|                | 24 V (EMC-BPS01) enabled       | 1: EMC-BPS01 enabled                             |         |
| <b>№</b> 03-06 | Reserved                       |  |         |
| <b>№</b> 03-07 | Number of times of             | 0–10   | 0       |
|                | auto-restart after fault       |  |         |
| <b>≠</b> 03-08 | Auto-restart interval of fault | 0.1–6000.0 sec.                                  | 60.0    |
| <b>№</b> 03-09 | Cooling fan control mode       | 0: fan runs always                               | 3       |
|                |                                | 1: runs for one minute after stop and then stops |         |
|                |                                | 2: runs and stops as the Power Regenerative Unit |         |
|                |                                | regenerates and stops                            |         |
|                |                                | 3: runs according to the power module's          |         |
|                |                                | temperature                                      |         |
|                |                                | 4: always off                                    |         |
| 03-10          | Reserved                       |  |         |
| 03-11          | Reserved                       |  |         |
| <b>№</b> 03-12 | Erase the energy regenerated   | 0: parameter reset                               | 0       |
|                | record                         | 1: erase   |         |
| <b>№</b> 03-13 | Electricity rate               | 0–6553.5 \$ / kWh                                | 3.0     |

### **04 Communication Parameters**

| Parameter codes | Parameter names                      | Setting range                  | Default |  |  |  |
|-----------------|--------------------------------------|--------------------------------|---------|--|--|--|
| <b>№</b> 04-00  | Communication address                | 1–254                          | 1       |  |  |  |
| <b>≠</b> 04-01  | COM1 transmission speed              | sion speed 4.8–115.2 Kbps      |         |  |  |  |
| <b>№</b> 04-02  | COM1 transmission fault              | 0: Warn and continue operation | 3       |  |  |  |
|                 | treatment                            | 1: Warn and ramp to stop       |         |  |  |  |
|                 |                                      | 2: Reserved                    |         |  |  |  |
|                 |                                      | 3: No action and no display    |         |  |  |  |
| <b>№</b> 04-03  | COM1 time-out detection              | 0.0–100.0 sec.                 | 0       |  |  |  |
| <b>№</b> 04-04  | COM1 communication protocol          | 0: 7, N, 1 (ASCII)             | 1       |  |  |  |
|                 |                                      | 1: 7, N, 2 (ASCII)             |         |  |  |  |
|                 |                                      | 2: 7, E, 1 (ASCII)             |         |  |  |  |
|                 |                                      | 3: 7, O, 1 (ASCII)             |         |  |  |  |
|                 |                                      | 4: 7, E, 2 (ASCII)             |         |  |  |  |
|                 |                                      | 5: 7, O, 2 (ASCII)             |         |  |  |  |
|                 |                                      | 6: 8, N, 1 (ASCII)             |         |  |  |  |
|                 |                                      | 7: 8, N, 2 (ASCII)             |         |  |  |  |
|                 |                                      | 8: 8, E, 1 (ASCII)             |         |  |  |  |
|                 |                                      | 9: 8, O, 1 (ASCII)             |         |  |  |  |
|                 |                                      | 10: 8, E, 2 (ASCII)            |         |  |  |  |
|                 |                                      | 11: 8, O, 2 (ASCII)            |         |  |  |  |
|                 |                                      | 12: 8, N, 1 (RTU)              |         |  |  |  |
|                 |                                      | 13: 8, N, 2 (RTU)              |         |  |  |  |
|                 |                                      | 14: 8, E, 1 (RTU)              |         |  |  |  |
|                 |                                      | 15: 8, O, 1 (RTU)              |         |  |  |  |
|                 |                                      | 16: 8, E, 2 (RTU)              |         |  |  |  |
|                 |                                      | 17: 8, O, 2 (RTU)              |         |  |  |  |
| <b>№</b> 04-05  | Communication response<br>delay time | 0.0–200.0 ms                   | 2.0     |  |  |  |
| 04-06           | Reserved                             |                                |         |  |  |  |
| 04-06           | Reserved                             |                                |         |  |  |  |

### **05 Application Parameters**

| Parameter codes | Parameter names             | Setting range     | Default |
|-----------------|-----------------------------|-------------------|---------|
| <b>≠</b> 05-00  | DC BUS voltage filter time  | 0.000–65.535 sec. | 0.000   |
| ≠ 05-01         | Mains frequency filter time | 0.000–65.535 sec. | 0.010   |
| 05-02           |                             |                   |         |
| -               | Reserved                    |                   |         |
| 05-20           |                             |                   |         |

# 07 Descriptions of Parameter Settings

00 Display Parameters

✓ You can set this parameter during operation.

**GG - GG** Power Regenerative Unit identity code Power Regenerative Unit rated current display

Default: read-only

Settings Read-only (Display by model)

Pr.00-00 determines the capacity of the Power Regenerative Unit and is a default setting parameter. Also, the rated current for that model is in the read-only parameter Pr.00-01. Pr.00-00 corresponds to the current displayed in Pr.00-01.

|                     | REG2000 Identity Code |    |    |      |    |    |     |      |    |    |      |      |    |    |    |    |
|---------------------|-----------------------|----|----|------|----|----|-----|------|----|----|------|------|----|----|----|----|
| Input voltage       |                       |    |    | 230V |    |    |     |      |    |    |      | 460V |    |    |    |    |
| Model code          | 0                     | 2  | 4  | 6    | 8  | 10 | 12  | 1    | 3  | 5  | 7    | 9    | 11 | 13 | 15 | 17 |
| Power               |                       |    |    |      |    |    |     |      |    |    |      |      |    |    |    |    |
| Regenerative Unit   |                       |    |    |      |    |    |     |      |    |    |      |      |    |    |    |    |
| corresponding       | 7.5                   | 11 | 15 | 18.5 | 22 | 30 | 37  | 7.5  | 11 | 15 | 18.5 | 22   | 30 | 37 | 45 | 55 |
| capacity            |                       |    |    |      |    |    |     |      |    |    |      |      |    |    |    |    |
| (kW)                |                       |    |    |      |    |    |     |      |    |    |      |      |    |    |    |    |
| Rated input current | 20                    | 32 | 38 | 49   | 60 | 80 | 100 | 10.5 | 17 | 20 | 25   | 32   | 43 | 49 | 60 | 75 |
| (A)                 |                       |    |    |      |    |    |     |      |    |    |      |      |    |    |    |    |

### **Software version**

|       |  | Default: #.## |
|-------|--|---------------|
|       | Settings Read-only (Display according to shipped version)        |               |
| 00-03 | Display Power Regenerative Unit input current (A <sub>AC</sub> ) |               |
| 00-04 | Display mains frequency (Hz) (line frequency)                    |               |
|       |  | Default: #.## |
|       | Settings Read-only   |               |
|       |  |               |
| 00-05 | Display DC BUS voltage (V <sub>DC</sub> )                        |               |
|       |  | Default: #.#  |
|       | Settings Read-only   |               |
| 00-06 | Display power (kW)   |               |
|       |  | Default: #.#  |
|       | Settings -300.0-300.0  |               |
|       |  |               |
| 00-07 | Reserved   |               |
| 00-08 | Reserved   |               |

| <u></u>                | Display the low word of the kilowatt hours (kWh) regen             |                     |
|------------------------|--|---------------------|
|                        | Settings 0.0–999.9   | Default: ###.#      |
| 00- H                  |  | enerated by REG2000 |
|                        |  | Default: ####       |
|                        | Settings 0–9999  |                     |
| When                   | Pr.03-12 = 1, Pr.00-09 and Pr.00-10 are reset to 0 and Pr.03-12 re | turns to 0.         |
| After y                | ou set Pr.00-09 and Pr.00-10, the REG starts to run and the count  | ing begins.         |
| 🔋 It disp              | ays by Pr.00-10 * 1000 + Pr.00-09.                                 |                     |
| 00-;                   | Display highest internal ambient temperature (°C) (air             | outlet)             |
| <u>00-  </u>           | Display highest power module's temperature (°C)                    |                     |
|                        |  | Default: ##.#       |
|                        | Settings Read-only   |                     |
|                        |  |                     |
| <u> 00-1</u>           | Display internal ambient temperature (°C) (air outlet)             |                     |
| UU- /                  | Display power module's temperature (°C)                            |                     |
|                        | Settings Read-only   | Default: ##.#       |
|                        | Settings Read-only   |                     |
| 00-1                   | Display digital input ON/OFF status                                |                     |
| <u>00-1</u>            |  |                     |
|                        |  | Default: ###        |
|                        | Settings Read-only   |                     |
|                        |  |                     |
| <u> 88 - 8</u>         | DC BUS voltage during a malfunction (V <sub>DC</sub> )             |                     |
|                        | Settings Read only   | Default: ##.#       |
| 00-11                  | Settings Read-only<br>Mains frequency during a malfunction (Hz)    |                     |
| <u>00 10</u><br>00- 11 | Current during a malfunction (A)                                   |                     |
|                        |  | Default: #.##       |
|                        | Settings Read-only   |                     |
|                        |  |                     |
| <u> 80 - 80</u>        | Fault record 1   |                     |
| 00-2                   | Fault record 2   |                     |
| <u>00-2</u> 0          | Fault record 3   |                     |
| <u>00-2</u>            | Fault record 4   |                     |
| <u>00-2</u><br>00-2    | Fault record 5   |                     |
| <u>00-</u> 21          | Fault record 6   | Default: 0          |
|                        |  | Default: 0          |

Settings

0: no error record

- 3: ocn over-current during regeneration
- 6: ocs over-current at stop
- 9: ovn over-voltage during regeneration
- 10: ovs over-voltage at stop
- 15: OrP phase loss in output
- 16: oH1 power module overheated
- 17: oH2 internal ambient temperature overheated (air outlet)
- 18: tHo1 power module overheated protection circuit error
- 19: tHo2 internal ambient temperature overheated protection circuit error
- 21: oL overload
- 30: cF1 memory writing error
- 31: cF2 memory read error
- 37: Hd1 current detection error when powering on
- 38: Hd2 voltage detection error when powering on
- 42: 5VF 5V control board error (firmware v.1.02 (included) and later)
- 43: RYF relay error (firmware v.1.02 (included) and later)
- 49: EF external signal input fault
- 52: Pcod wrong password
- 54: cE1 communication error
- 55: cE2 communication error
- 56: cE3 communication error
- 57: cE4 communication error
- 58: cE10 communication time-out
- 66: PLE phase lock error
- PLE and OrP errors are recorded as errors only in power regeneration status; otherwise, they are warnings in Ready and Run status.
- OH1 Level

| Model      | Default |
|------------|---------|
| REG075A23A | 100     |
| REG110A23A | 110     |
| REG150A23A | 100     |
| REG185A23A | 100     |
| REG220A23A | 100     |
| REG300A23A | 95      |
| REG370A23A | 105     |
|            |         |

| Model      | Default |
|------------|---------|
| REG075A43A | 100     |
| REG110A43A | 105     |
| REG150A43A | 110     |
| REG185A43A | 100     |
| REG220A43A | 90      |
| REG300A43A | 90      |
| REG370A43A | 95      |
| REG450A43A | 115     |
| REG550A43A | 115     |



**GG-25** Low word in electricity bill **High word in electricity bill** 

Default: ###

#### Settings Read only

- When Pr.03-12 =1, Pr.00-26 and Pr.00-27 are reset to 0 and Pr.03-12 returns to 0.
- Display the dollar amount saved on electricity expense. The settings of the related parameters are shown below.

The kW/hr regenerated (Pr.00-09–Pr.00-10) \* electricity expense (Pr.03-13). It displays by Pr.00-27 \* 1000 + Pr.00-26.

Display input AC voltage (V<sub>AC</sub>)

Default: ##.#

Settings Read only

### **01 Basic Parameters** ✓You can set this parameter during operation. **Reset** parameters Default: 0 Settings 0: no function 1: parameter cannot be written 10: parameter reset 1: You can only adjust Pr.01-00-Pr.01-03, and the other parameters are read-only. In combination with the password parameters, this prevents the parameters from being altered by mistake. 10: Restores the parameters to the defaults. If a password is set, you must enter it before restoring the parameter settings, and the password is cleared at the same time. Select start-up display Default: 0 Settings 0: mains frequency 1: DC BUS voltage ( $V_{DC}$ ) 2: Output current $(A_{AC})$ **G ! - G Z** Enter parameter protection password Default: 0 Settings 1-9998,10000-65535 Display 0-2: number of incorrect passwords entered value Enter the password set in Pr.01-03 into Pr.01-02 to unlock all the password protected parameters. After setting this parameter, write down the setting to avoid being locked out in the future. Using parameters Pr.01-02 and Pr.01-03 prevents non-technicians from accidently altering other parameters. If you lose or forget the password, you can reset it by entering 9999 and pressing the "ENTER" key, enter 9999 and press "ENTER" again (this sequence must be completed within 10 seconds; otherwise, you have to do it again). This also restores all parameters back to the defaults. Set parameter protection password

Default: 0 Settings 1–9998,10000–65535 Display value 0: password not set or password entered successfully in Pr.01-02 1: parameters locked


□ This parameter sets the password protection, which you can enter directly the first time. After you set the password, this parameter value becomes 1, meaning that password protection is enabled. To make changes to any parameter, first enter the correct password in Pr.01-02. After you unlock the password protection, the Pr.01-02 is reset to 0, and you can set all parameters.

- After password protection is enabled, all parameter values except for Pr.01-03 display 0.
- You can disable password protection by unlocking the password protection in Pr.01-02 and setting this parameter to 0. Password protection remains off after a system reboot.
- Otherwise, the password remains permanently active. After you turn on the system, you must first unlock the password protection in Pr.01-02 before changing any parameters.
- □ To reactivate password protection:

Method 1: Reenter the password in Pr.01-03.

Method 2: Reboot the system to immediately restore the password protection.

Method 3: Enter any value other than the password in Pr.01-02.



### 

Default:1

Settings 1: controlled by external terminals

2: controlled through the communication interface or the digital keypad (KPC-CE01/KPC-CC01)

- The standard REG package does not contain the digital keypad and you must control operation with external terminals. Confirm that the wiring between multi-function input terminals is correct before using.
- To operate using the communication interface, you must purchase a digital keypad KPC-CC01 or KPC-CE01 before you can set the operation command source to the communication interface.


### PLC1.ir



#### **B I** - **B B D** C BUS voltage activation level (offset value)

| Settings | 230V series: 30–100 V | Default: 40 |
|----------|-----------------------|-------------|
|          | 460V series: 60–200 V | Default: 80 |

- In the regenerative activating voltage is set to the mains AC voltage (Pr.00-28) \*  $\sqrt{2}$  + Pr.01-08.
- The Power Regenerative Unit stops output when (1) DC BUS voltage < (DC BUS voltage + Pr.01-08</li>
   10 V) and (2) the Power Regenerative Unit output current (A<sub>AC</sub>) is 10% lower than the rated output for more than one second.
- There is an absolute upper limit and an absolute lower limit in the DC BUS voltage activation level. For example, the absolute upper limit of the DC BUS voltage activation level for 440V models is 780 V. That means even when the input voltage is 528 V<sub>AC</sub> and the Pr.01-08 = 200 V, the DC BUS voltage activation level should be 528 \* 1.414 + 200 = 947 V<sub>DC</sub>. However, the design of the Power Regenerative Unit forces the trigger upper limit to stay under 780 V<sub>DC</sub>.



### 

Image: Image control P gainImage: Image control P gainImage: Image control P gainImage: Image control P gainImage control P gainImage control P gain


Default: 100

Settings 0-1000%

- Pr.01-10 is the parameter that decides the P function response speed on the DC BUS voltage bias. With higher gain, the response is faster while the DC BUS voltage bias becomes smaller. If the gain is too high, there will be an oscillation. With lower gain, the response is slower while the DC BUS voltage bias becomes larger. It is scaled to correspond 100% to the Kp value of auto-calculated DC BUS voltage control bandwidth (Pr.01-12).
- Pr.01-11 is an integral controller to eliminate the steady-state error caused by the DC BUS voltage bias. The higher the integral gain, the faster the response to the external disturbance, and the oscillation easily occurs. But the lower the integral gain, the slower the response to the external disturbance. It is scaled to correspond 100% to the Ki value of auto-calculated DC BUS voltage

Default: 40

control bandwidth (Pr.01-12).



Settings 1–100 Hz

Generation Controls the DC BUS voltage response speed. The higher the value, the faster the response.

[] ;- ; ] Reserved

×

| 🗡 🚺 : - : : : Select multi-function display  |            |
|--|------------|
|  | Default: 0 |
| Settings 0: display DC BUS voltage (v)       |            |
| 1: display mains frequency (H)               |            |
| 2: display output current (A <sub>AC</sub> ) |            |
| 3: display output AC voltage (E)             |            |
| 4: reserved                                  |            |
| 5: reserved                                  |            |
| 6: reserved                                  |            |
| 7: display power (P)                         |            |
| 8: display current limit (p)                 |            |

| 02 Digital Input/Output Parameters   |            |
|--|------------|
| <b>G2-GG</b> Multi-function input command 1 (MI1)  |            |
|  | Default: 1 |
| <b><i>G</i> - <i>G</i> ;</b> Multi-function input command 2 (MI2)  |            |
|  | Default: 0 |
| <b><i>C C</i> <b><i>C C</i> <b><i>C C C C C</i> <b><i>C C C C</i> <b><i>C C C C C</i> <b><i>C C C</i> <b><i>C C C</i> <b><i>C C C C</i> <b><i>C C C C C</i> <b><i>C C C C</i> <b><i>C C C C C</i> <b><i>C C C C C</i> <b><i>C C C</i> <b><i>C C C C C</i> <b><i>C C C C</i> <b><i>C C C</i> <b><i>C C C</i> <b><i>C C C C C</i> <b><i>C C C C</i> <b><i>C C</i> <b><i>C C C C</i> <b><i>C C C</i> <b><i>C C</i> <b><i>C C</i> <b><i>C C</i> <b><i>C C</i> <b><i>C C C</i> <b><i>C C</i> <b><i>C C C</i> <b><i>C C</i> <b><i>C C C</i> <b><i>C C C C C C</i> <b><i>C C</i> <b><i>C C C</i> <b><i>C C</i> <b><i>C C</i> <b><i>C C C</i> <b><i>C C C</i> <b><i>C C C</i> <b><i>C C</i> <b><i>C C C C</i> <b><i>C C</i> <b><i>C</i></b> <i>C C C C C C C C C C C C C C C</i></b> <i>C C C</i></b> <i>C C</i></b> <i>C C</i></b> </b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b></b> |            |
|  | Default: 3 |
| <b>G2-G3</b> Multi-function input command4 (MI4)   |            |
|  | Default: 4 |
| <b>C</b> - <b>C</b> +       Multi-function input command 5 (MI5)   |            |
|  | Default: 5 |
| Settings 0: No function  |            |
| 1: Automatic mode  |            |
| 2: Reserved  |            |
| 3: External Fault (EF)   |            |
| 4: RESET   |            |
| 5: Parallel mode   |            |
| 6: No function   |            |

□ Includes the necessary external terminal input functions as required.

The following table lists the multi-function input terminal functions.

| Setting | Function                         | Description   |  |
|---------|----------------------------------|---|--|
| 0       | No function                      | The input terminal does not have any function.  |  |
|         |                                  | This terminal setting is effective only when you set Pr.01-04 to 1<br>"controlled by external terminals".<br>When the automatic mode is ON and the Power Regenerative Unit<br>detects that DC BUS voltage reaches the setting in Pr.01-08, the DC<br>BUS voltage automatically regenerates to the electrical grid.<br>The following diagram shows the default wiring between the<br>multi-function input terminals for each Power Regenerative Unit.<br>Verify that the wiring is correct before using. Refer to Chapter 04 |  |
| 1       | (the default terminal<br>is MI1) | Wiring for more details about automatic mode.<br>REG2000<br>R/L1<br>S/L2<br>T/L3<br>E24V<br>COM<br>Mil1 Auto Mode<br>DCM  |  |
| 2       | Reserved                         | The input terminal function is reserved.  |  |

| Setting | Function              | Description   |  |
|---------|-----------------------|---|--|
|         |                       | While installing an EMI filter, connect one TH terminal to MI3 and  |  |
|         |                       | another TH terminal (both TH terminals have the same polarity) to   |  |
|         |                       | DCM to do temperature protection detection. The wiring method is  |  |
|         |                       | as shown in the image below. See Chapter 4 for more information   |  |
|         |                       | wiring.   |  |
| 3       | External Fault (EF)   | EMI<br>supply<br>mains<br>TH<br>EMI<br>filter<br>TH<br>TH<br>EMI<br>Filter<br>T/L3<br>T/L3<br>E24V<br>COM<br>MI3 (EF)                   |  |
| 4       | RESET                 | You can reset the Power Regenerative Unit after clearing the fault only with this terminal function.                                    |  |
|         |                       | This terminal setting is effective only when you set Pr.01-04 to 1  |  |
|         |                       | "controlled by external terminals."   |  |
|         |                       | Before setting to parallel mode, select Automatic as the control  |  |
|         |                       | mode.   |  |
|         |                       | When working in parallel mode, each Power Regenerative Unit   |  |
|         |                       | automatically reduces its current limit to 80%.   |  |
|         |                       | The following diagram shows the default wiring between the  |  |
|         | Parallel mode         | multi-function input terminals for each Power Regenerative Unit.<br>Verify that the wiring is correct before using. Refer to Chapter 04 |  |
| 5       | (the default terminal | Wiring for more details about parallel mode.  |  |
|         | is MI5)               | REG2000<br>R/L1<br>S/L2<br>T/L3<br>E24V   |  |
|         |                       | MI1 Auto Mode<br>MI5 Parallel Mode<br>DCM   |  |
| 6       | No function           | The input terminal does not have any function.  |  |


Default: 0.005

Settings 0.001-30.000 sec.

Adds a delay and confirms process to digital input terminal signals. The delay time is the confirmation time. This prevents unknown interference from causing the digital input terminals

status.

(MI1–5) to malfunction (except counting inputs). This parameter significantly improves these situations, but response time is slightly delayed.



- □ bits 0–4 correspond to MI1–MI5, respectively.
- Benter corresponding values through communications to alter the ON/OFF status of the terminals.

| ✓ 32 - 3 → Multi-function output 1 (Relay 1) |            |
|--|------------|
|  | Default:4  |
| ✓ 32 - 38 Multi-function output 2 (MO1)      |            |
|  | Default:3  |
| ✓ 32 - 33 Multi-function output 3 (MO2)      |            |
|  | Default: 0 |
| Settings                                     |            |
| O. N. function                               |            |

- 0: No function
- 1: Regenerate indicator
- 2: Run indicator
- 3: Ready indicator
- 4: Error indicator
- 5: No function
- 6: Warn indicator
- 7: No function

Includes the necessary external terminal output functions as required.

The following table lists the multi-function output terminal functions.

| Setting | Function             | Description   |  |
|---------|----------------------|---|--|
| 0       | No function          | The output terminal does not have any function.   |  |
| 1       | Regenerate indicator | When the Power Regenerative Unit is in Regenerate status, the contacts are in ON status.  |  |
| 2       | Run indicator        | After powering on and sending the RUN command, the Power<br>Regenerative Unit is in normal operation (including standby<br>and regenerate) and the contacts are in ON status. |  |
| 3       | Ready indicator      | The contacts are ON when there are no Power Regenerative<br>Unit errors or warnings. (When the phase lock is completed,<br>you can now send the RUN command.)                 |  |
| 4       | Error indicator      | The contacts are ON when the Power Regenerative Unit detects an error.  |  |
| 5       | No function          | The output terminal does not have any function  |  |

### PLC1.ir

| 6 Warn indicator | The contacts are ON when the Power Regenerative Unit |  |
|------------------|--|--|
| 0                | 6 vvarn indicator                                    | detects a warning.                             |
| 7                | No function  | The output terminal does not have any function |

See Diagram 3 in Section 4-4 for more information on the definition of different working status of power regeneration.


#### ✓ 32 - 18 Multi-function output direction

Default: 0

#### Settings 0-65535

□ The setting of this function is binary. If you set a bit to 1, the multi-function output direction is reversed. For example, when you set Pr.02-07 to 1 (Regenerate indicator), if the output direction is forward or you set the bit to 0, Relay 1 activates (ON) only when the Power Regenerative Unit regenerates. When the Power Regenerative Unit is stopped, Relay 1 is OFF. In contrast, if the output direction is reverse and you set the bit to 1, Relay 1 is OFF when the Power Regenerative Unit regenerates, and ON when it stops.

| Bit 2 | Bit 1 | Bit 0 |
|-------|-------|-------|
| MO2   | MO1   | RY1   |



### **03 Special Protection Parameters**


✓You can set this parameter during operation.

A B B B B Low voltage level

Default: 180.0/360.0

Settings 230V series: 160.0–220.0 V 460V series: 320.0–440.0 V

- Description: This parameter sets the LV voltage level.
- When the Power Regenerative Unit voltage drops below the parameter low voltage level, the system sends a warning.







Settings 0-150%

Limits the Power Regenerative Unit maximum current output.

 () 3 - () 2
 Reserved


 () 3 - () 3
 Reserved

### ✓ ☐ 3 - ☐ 4 Phase lock frequency deviation time

Default: 150

Settings 0–1000 ms

□ When a frequency is detected to be outside of 47–63 Hz and the duration is longer than the value set in this parameter, the system generates a PLE phase lock signal.



### ✓ ⑦ 3 - ⑦ 7 Number of times of auto-restart after fault

Default: 0

#### Settings 0-10


Sets the number of times the Power Regenerative Unit can automatically reset/restart after a fault (acceptable errors: only over-current during regeneration and at stop, over-voltage during regeneration and at stop, phase lock) at a maximum of ten times. If you set this parameter to 0, then the system does not automatically reset/restart after a fault.

### ✓ ☐ 3 - ☐ 8 Auto-restart interval of fault

Default: 60.0

#### Settings 0.1-6000.0 sec.

When a restart after fault occurs, the Power Regenerative Unit starts a count-down according to this parameter. Within the Pr.03-08 setting time, the Power Regenerative Unit stops only when the count-down reaches the number of times set in Pr.03-07 (and the faults are recorded). If the count-down does not reach the number of times set in Pr.03-07 within Pr.03-08 setting time, the unit resets Pr.03-07 to the initial value before starting another counting.



Default: 3

Settings 0: fan runs always

- 1: runs for one minute after stop and then stops
- 2: runs and stops as the Power Regenerative Unit regenerates and stops
- 3: runs according to the power module's temperature
- 4: always off
- Determines the cooling fan mode setting.
- 0: The cooling fan starts running as soon as the Power Regenerative Unit starts transmitting power.
- 1: The cooling fan runs when the Power Regenerative Unit runs and stops one minute after the Power Regenerative Unit stops.
- 2: The cooling fan runs when the Power Regenerative Unit runs and stops as soon as the Power Regenerative Unit stops.
- 3: The cooling fan adjusts its speed according to the power module's temperature. When the temperature is high, the cooling fan starts running; the higher the temperature the faster the fan runs. When temperature drops into the normal range, as shown in the following table, the cooling fan stops.
- 4: The cooling fan is always off.

| Model      | Operating temperature range of fans (RUN→STOP) |
|------------|--|
| REG075A23A | 50→40  |
| REG110A23A | 60→50  |
| REG150A23A | 50→40  |
| REG185A23A | 50→40  |
| REG220A23A | 50→40  |
| REG300A23A | 45→35  |
| REG370A23A | 65→55  |
| REG075A43A | 50→40  |
| REG110A43A | 55→45  |

 []]
 !]
 Reserved

 []]
 !
 !
 Reserved

### ✓ ③ 3 - ↓ 2 Erase the energy regenerated record

Default: 0

Default: 3.0

Settings 0: parameter reset

1: erase

Setting this parameter to 1 clears Pr.00-09 and Pr.00-10 to 0, and the system resets this parameter to 0.



Settings 0-6553.5 \$ / kWh

Sets the calculation for the local electricity bill. Unit: \$/kWh.

✓You can set this parameter during operation.

## 04 Communication Parameters

When using the communication interface, the diagram on the right shows the communication port pin definitions. We recommend that you connect the Power Regenerative Unit to your PC by using Delta IFD6530 or IFD6500 as a communication converter.

✓ 〇 년 - 〇 〇 Communication address

Settings 1-254

When the system uses the RS-485 serial communication interface for control or monitoring, every Power Regenerative Unit must have its own communication address and every address in the network must be unique.

🗡 📴 Ч - 🕃 🕴 COM1 transmission speed

Settings 4.8–115.2 Kbps

Sets the transmission speed between the Power Regenerative Unit and computers.

#### X [] Y - [] Z COM1 transmission fault treatment

Settings 0: Warn and continue operation

- 1: Warn and ramp to stop
- 2: Reserved
- 3: No actions and no display
- Decifies how the Power Regenerative Unit handles a transmission time-out error (such as a broken line) during communications.

✓ 🔐 - 🕃 3 COM1 time-out detection

Settings 0.0-100.0 sec.

0.0: No detection

Bets the duration for a transmission time-out between communication ports and COM1.

✓ ☐ Ч - ☐ Ч COM1 communication protocol

Settings 0: 7, N, 1 for ASCII 1: 7, N, 2 for ASCII 2: 7, E, 1 for ASCII 3: 7, O, 1 for ASCII 4: 7, E, 2 for ASCII 5: 7, O, 2 for ASCII 6: 8, N, 1 for ASCII

PLC1.ir

Default: 1

8 ← 1 RS-485

Modbus RS-485 Pin 1, 2, 7, 8: Reserved Pin 3, 6: GND Pin 4: SG-Pin 5: SG+

Default: 1

Default: 3

Default: 9.6

Default: 0.0

07 Descriptions of Parameter Settings | REG2000

7: 8, N, 2 for ASCII 8: 8, E, 1 for ASCII 9: 8, O, 1 for ASCII 10: 8, E, 2 for ASCII 11: 8, O, 2 for ASCII 12: 8, N, 1 for RTU 13: 8, N, 2 for RTU 14: 8, E, 1 for RTU 15: 8, O, 1 for RTU 16: 8, E, 2 for RTU 17: 8, O, 2 for RTU

Control by PC (Computer Link)

When using the RS-485 serial communication interface, you must first specify a communication address to every Power Regenerative Unit in Pr.04-00. The computer then controls the units based on their individual addresses.

Modbus ASCII (American Standard Code for Information Interchange): Each byte of data is the combination of two ASCII characters. For example, one byte of data: 64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex).

#### 1. Code Description


The communication protocol is in hexadecimal, ASCII: "0" ... "9", "A" ... "F", every hexadecimal value represents an ASCII code. The following table shows some examples.

| Character  | '0' | '1' | '2' | '3' | '4' | '5' | '6' | '7' |
|------------|-----|-----|-----|-----|-----|-----|-----|-----|
| ASCII code | 30H | 31H | 32H | 33H | 34H | 35H | 36H | 37H |
| Character  | '8' | ʻ9' | 'A' | 'B' | 'C' | 'D' | 'E' | 'F' |
| ASCII code | 38H | 39H | 41H | 42H | 43H | 44H | 45H | 46H |


#### 2. Character structure

10-bit character frame (for ASCII)


(Data format 7, N, 2)



(Data format 7, E, 1)




(Data format 7, O, 1)




11-bit character frame (For RTU)


(Data format 8, N, 2)



(Data format 8, E, 1)



(Data format 8, O, 1)



#### 3. Communication data structure

Data format frame

#### ASCII mode:

| STX         | Start character = ':' (3AH)                              |
|-------------|--|
| Address Hi  | Communication address:                                   |
| Address Lo  | one 8-bit address consists of 2 ASCII codes              |
| Function Hi | Function code:   |
| Function Lo | one 8-bit function code consists of 2 ASCII codes        |
| DATA (n-1)  | Contents of data:  |
|             | N x 8-bit data consists of 2n ASCII codes                |
| DATA 0      | $N \le 16$ , maximum of 32 ASCII codes (20 sets of data) |
| LRC CHK Hi  | LRC checksum:  |
| LRC CHK Lo  | one 8-bit checksum consists of 2 ASCII codes             |
| END Hi      | End characters:  |
| END Lo      | END Hi = CR (0DH), END Lo = $LF(0AH)$                    |

#### RTU mode:

| START        | Maintains no input signal for at least 10 ms               |
|--------------|--|
| Address      | Communication address: 8-bit binary address                |
| Function     | Function code: 8-bit binary address                        |
| DATA (n-1)   | Contents of data:  |
|              |  |
| DATA 0       | −N × 8-bit data, N ≤ 16                                    |
| CRC CHK Low  | CRC checksum:  |
| CRC CHK High | one 16-bit CRC checksum consists of two 8-bit binary codes |
| END          | Maintains no input signal for at least 10 ms               |

Communication address (Address)

00H: broadcasts to all Power Regenerative Units

01H: targets the Power Regenerative Unit at address 01

0FH: targets the Power Regenerative Unit at address 15

10H: targets the Power Regenerative Unit at address 16

... to the maximum of 254 (FEH)

Function code and data characters 03H: reads data from the register 06H: writes one set of data to the register

For example, reading two continuous data from register address 2102H. The Power Regenerative Unit address is 01H.

ASCII mode:

| Inquiry message string format |       | Response message string format |             |
|-------------------------------|-------|--------------------------------|-------------|
| STX                           | · · · | STX                            | · . ,       |
| Address                       | ·0'   | A dalaa aa                     | '0'         |
| Address                       | '1'   | Address                        | <b>'1'</b>  |
| Function                      | ·0'   | Function                       | '0'         |
| Function                      | '3'   | Function                       | '3'         |
|                               | '2'   | Number of data                 | <b>'</b> 0' |
| Starting address              | '1'   | (count by byte)                | '4'         |
| Starting address              | ·0'   |                                | <b>'1'</b>  |
|                               | '2'   | Content of starting            | '7'         |
|                               | ·0'   | address 2102H                  | '7'         |
| Number of data                | ·0'   |                                | <b>'</b> 0' |
| (count by word)               | ·0'   |                                | '0'         |
|                               | '2'   | Content of address 2103H       | '0'         |
| LRC Check                     | 'D'   | Content of address 210511      | '0'         |
|                               | '7'   |                                | '0'         |
| END                           | CR    | LRC Check                      | '7'         |
|                               | LF    |                                | '1'         |
|                               |       | END                            | CR          |
|                               |       | LIND                           | LF          |

#### RTU mode:

| ring format | Response message                       | string format  |
|-------------|--|--|
| 01H         | Address                                | 01H  |
| 03H         | Function                               | 03H  |
| 21H         | Number of data                         | 04H  |
| 02H         | (count by byte)                        | 040  |
| 00H         | Content of data                        | 17H  |
| 02H         | address 2102H                          | 70H  |
| 6FH         | Content of data                        | 00H  |
| F7H         | address 2103H                          | 00H  |
|             | CRC CHK Low                            | FEH  |
|             | 03H<br>21H<br>02H<br>00H<br>02H<br>6FH | 01HAddress03HFunction21HNumber of data02H(count by byte)00HContent of data02Haddress 2102H6FHContent of dataF7Haddress 2103H |

### PLC1.ir

CRC CHK High 5CH

06H: single write, write single data to a register. (The system can write up to 20 sets of data simultaneously.)

For example, writing data 6000 (1770H) to register 0100H. The Power Regenerative Unit address is 01H.

ASCII mode:

| Inquiry message s | tring format | Response message string format |          |  |
|-------------------|--------------|--------------------------------|----------|--|
| STX               | (_)<br>-     | STX                            | (_)<br>- |  |
| Address           | ·0'          | Address                        | ·0'      |  |
| Address           | '1'          | Address                        | '1'      |  |
| Function          | ·0'          | Function                       | ·0'      |  |
| Function          | '6'          | Function                       | '6'      |  |
|                   | ·0'          |                                | ʻ0'      |  |
| Data address      | '1'          | Data address                   | '1'      |  |
| Data address      | ·0'          | Data address                   | ·0'      |  |
|                   | ·0'          |                                | ·0'      |  |
|                   | '1'          |                                | '1'      |  |
| Data content      | '7'          | Data content                   | '7'      |  |
| Data content      | '7'          | Data content                   | '7'      |  |
|                   | ·0'          |                                | ·0'      |  |
| LRC Check         | '7'          | LRC Check                      | '7'      |  |
|                   | '1'          |                                | '1'      |  |
| END               | CR           | END                            | CR       |  |
|                   | LF           |                                | LF       |  |

#### RTU mode:

| Inquiry message st | ring format | Response message string format |     |  |
|--------------------|-------------|--------------------------------|-----|--|
| Address            | 01H         | Address                        | 01H |  |
| Function           | 06H         | Function                       | 06H |  |
| Data address       | 01H         | Data address                   | 01H |  |
| Data address       | 00H         | Data address                   | 00H |  |
| Data content       | 17H         | Data content                   | 17H |  |
| Data content       | 70H         | Data content                   | 70H |  |
| CRC CHK Low        | 86H         | CRC CHK Low                    | 86H |  |
| CRC CHK High       | 22H         | CRC CHK High                   | 22H |  |

10H: write multiple registers (write multiple data to registers).Checksum in ASCII mode (LRC Check)

Checksum (LRC Check) is the sum from Address to Data Content. For example, the checksum of the inquiry message above: 01H + 03H + 21H + 02H + 00H + 02H = 29H, and then take the 2's complement = D7H.

Checksum in RTU mode (CRC Check)

Checksum starts from Address and ends at Data content. The calculation is shown below.

Step 1: Set the 16-bit register (CRC register) = FFFFH.

- Step 2: Exclusive OR the first 8-bit byte message and the low bit 16-bit CRC register, create Exclusive OR, and store the results in CRC register.
- Step 3: Shift one CRC register to the right, and fill in 0 high bit position.
- Step 4: Check the shifted value. If it is 0, store the new value from Step 3 in the CRC register; otherwise, Exclusive OR A001H and the CRC register store the results in the CRC

register.

Step 5: Repeat Steps 3–4, until all eight bits are complete.

Step 6: Repeat Step 2–5, and take the message command from the next 8-bit byte until all message commands are computed. Finally, the acquired value in the CRC register is the CRC checksum. Note that the CRC checksum must alternate places within the message command checksum.

The following is an example of computing the CRC checksum using C language.

```
unsigned char* data \leftarrow // message command index
```

```
unsigned char length \epsilon // length of message command
```

```
unsigned int crc_chk(unsigned char* data, unsigned char length)
```

```
{
int j;
unsigned int reg_crc=0Xffff;
while(length--){
   reg_crc ^= *data++;
   for(j=0;j<8;j++){
    if(reg_crc & 0x01){ /* LSB(b0)=1 */
      reg_crc=(reg_crc>>1) ^ 0Xa001;
   }else{
      reg_crc=reg_crc >>1;
   }
}
```

return reg\_crc;

}

// final value returned to CRC register

#### 4. Definition of parameter addresses in the communication protocol

| Definition of<br>REG2000<br>parameters | Parameter<br>address<br>(GGnnH) | GG stands   | Function Description<br>GG stands for the parameter group and nn stands for the parameter<br>number. For example: Pr.04-01 is shown as 0401H. |     |
|--|---------------------------------|-------------|---|-----|
| Command/<br>Write only                 | 2000H                           | bit 1–0     | 00: No function (operation command remains unchanged)   | W   |
|  |                                 |             | 01: Stop  | W   |
|  |                                 |             | 10: Start   | W   |
|  |                                 | bit 15–3    | No function   | N/A |
|  | 2001H                           | No function |   | N/A |
|  | 2002H                           | bit 0       | 1: Enable the external fault (E.F.)   | W   |
|  |                                 | bit1        | 2: Reset Command  | W   |
|  |                                 | bit 5–2     | No function   | N/A |
| Status                                 | 2100H                           | bit7–0      | High Byte: Error Code   | R   |
| monitor/<br>Read only                  |                                 | bit15–8     | Low Byte: Warning Code  | R   |
|  | 2110H                           | bit7–0      | Identity code of the Power Regenerative Unit (same as Pr.00-00)   | R   |
|  |                                 | bit15–8     | Product model ID (REG2000 code: 14)   | R   |
|  | 2112H                           | bit15–0     | Firmware version (high word, SX.XX)<br>S: 0–9, Defined by Delta<br>X.XX: 0.00–9.99, REG firmware version #                                    | R   |

| Definition of                   |         |          | Function Description   | Read/ |
|---------------------------------|---------|----------|--|-------|
| REG2000                         | address |          | s for the parameter group and nn stands for the parameter  | Write |
| parameters                      | (GGnnH) | nı       | mber. For example: Pr.04-01 is shown as 0401H.   | WIIto |
|                                 |         |          | 00: Ready  |       |
|                                 | 044014  |          | 01: Run  |       |
|                                 | 2119H   | bit 1–0  | 10: Prepare  | R     |
|                                 |         |          | 11: Regenerate   |       |
|                                 |         | bit 9–2  | Reserved   | N/A   |
|                                 |         | bit10    | REG operation command source<br>1: Operation commands come from the external terminals<br>2: Control commands come from the communication<br>interface or the digital keypad (KPC-CC01). | R     |
|                                 |         | bit11    | Unlock or lock the parameters<br>0: Unlock the parameters<br>1: Lock the parameters  | R     |
|                                 |         | bit15–12 | Reserved   | N/A   |
| Status<br>monitor/<br>Read only | 2102H   | bit15–0  | Mains electricity frequency (Hz)   | R     |
|                                 | 2116H   | bit15–0  | Select multi-function display (Pr.01-14)   | R     |
|                                 | 2200H   | bit15–0  | Output current (A <sub>AC</sub> )  | R     |
|                                 | 2203H   | bit15–0  | DC BUS voltage (V <sub>DC</sub> )  | R     |
|                                 | 2204H   | bit15–0  | Output voltage (V <sub>AC</sub> )  | R     |
|                                 | 2206H   | bit15–0  | Output power (kW)  | R     |
|                                 | 220EH   | bit15–0  | Internal temperature (air outlet) (°C)   | R     |
|                                 | 220FH   | bit15–0  | Power module's temperature (°C)  | R     |
|                                 | 2210H   | bit15–0  | Digital input ON/OFF status, see Pr.02-06  | R     |
|                                 | 2211H   | bit15–0  | Digital output ON/OFF status, see Pr.02-10   | R     |
|                                 | 2222H   | bit15–0  | Cooling fan rotation speed (%)   | R     |
|                                 | 2229H   | bit15–0  | Display REG2000 regenerated kWh in low word.   | R     |
|                                 | 222AH   | bit15-0  | Display REG2000 regenerated kWh in high word.  | R     |
|                                 | 2237H   | bit15–0  | Display current upper limit (p)  | R     |

#### 5. Additional response in communication errors

If an error occurs when the Power Regenerative Unit is making communication connections, the Power Regenerative Unit sends an error code to the main control system and sets the highest bit (bit 7) to 1 (that is, Function code AND 80H) to make the main control system aware of the error. The Power Regenerative Unit keypad displays a warning message CE-XX, where XX is the error code. Refer to the error code definitions in communication errors in the table below. For example

| ASCII mo       | ASCII mode |                | )   |
|----------------|------------|----------------|-----|
| STX            | ·          | Address        | 01H |
| Address        | ·0'        | Function       | 86H |
|                | '1'        | Exception code | 02H |
| Function       | '8'        | CRC CHK Low    | C3H |
| Function       | '6'        | CRC CHK High   | A1H |
| Exception code | ·0'        |                |     |

|         | '2' |
|---------|-----|
| LRC CHK | '7' |
|         | '7' |
| END     | CR  |
| END     | LF  |

#### Error code definitions

| Error code | Description  |
|------------|--|
| 1          | Data character value error: the value is too large and is not recognized by the Power Regenerative Unit. |
| 2          | Parameter address error: parameter address is not recognized by the Power<br>Regenerative Unit.          |
| 3          | Password locked: cannot edit the parameters  |
| 4          | Parameters cannot be edited in operation   |
| 10         | Transmission time-out  |

### ✓ 34-35 Communication response delay time

Default: 2.0

#### Settings 0.0-200.0 ms

Sets the delay for the Power Regenerative Unit response time in situations where the host machine has not completed the transition (transmission–reception).



### 34-35 Reserved

### **05 Application Parameters**

✓You can set this parameter during operation.

### ✓ 05-00 DC BUS voltage filter time

Default: 0.000

Settings 0.000-65.535 sec.

Description: Sets the filter time to adjust DC BUS voltage. The higher the value, the better the filter result. This may affect control performance, so it normally does not need adjustment.



✓ 89 - 8 + Mains frequency filter time

Default: 0.010

Settings 0.000-65.535 sec.

Description Sets the mains frequency filter time which normally does not need adjustment.



## 08 Warnings and Error Codes

This chapter contains information on the optional digital keypad display (KPC-CC01/KPC-CE01). If you did not purchase the optional digital keypad, you can find out about error signals through the RS-485 communication interface.

- When a Power Regenerative Unit is at STOP, it is between the Ready status and the Run status (see Section 4-4 Display Panel Indicators for the definition of different working status of power regeneration).
- \* This chapter helps on-site technicians with troubleshooting. If the warning/error remains after following the corrective actions, contact a local dealer near you or Delta to return this product.

#### Warnings Codes

|   | HAND          |   |
|---|---------------|---|
| 1 | Warning       | ① Display error type  |
|   | Warning       | Display error code (abbreviation)   |
| 2 | CE01          | This error code is the same as displayed on the digital controller (KPC-CE01) |
| 3 | Comm. Error 1 | ③ Display error description   |

| ID # | LCM panel display                      | Description   |
|------|--|---|
|      |  | Communication Warning 1: Illegal communication command  |
| 1    | HAND<br>Warning<br>CE1<br>Comm. Error1 | <ul> <li>Corrective Action</li> <li>☑ Verify that the communication wring is correct (see Section 4-3).</li> <li>☑ Verify that the related parameter settings are in the correct setting ranges (see Chapter 07 Descriptions of Parameter Settings).</li> </ul> |
|      | Comm. Error                            | Press the RESET button after verifying the above items. If the warning  |
|      |  | message still appears, contact a local dealer near you or Delta to return   |
|      |  | this product.   |
|      |  | Communication Warning 2: Illegal communication data address   |
| 2    | Warning<br>CE2                         | Corrective Action☑☑Verify that the communication wring is correct.☑☑Verify that the communication command is correct.   |
|      | Comm. Error 2                          | Press the RESET button after verifying the above items. If the warning  |
|      |  | message still appears, contact a local dealer near you or Delta to return   |
|      |  | this product.   |
|      | Warning<br>CE3                         | Communication Warning 3: Illegal communication data value   |
| 3    |  | Corrective Action         ☑       Verify that the communication wiring is correct.         ☑       Verify that the communication command is correct.  |
|      | Comm. Error 3                          | Press the RESET button after verifying the above items. If the warning  |
|      |  | message still appears, contact a local dealer near you or Delta to return   |
|      |  | this product  |

|    |   | Communication Warning 4: Data written to read-only addresses  |
|----|---|---|
| 4  | HAND<br>Warning<br>CE4<br>Comm. Error 4   | Corrective Action         ☑ Verify that the communication wiring is correct.         ☑ Verify that the communication command is correct         Press the RESET button after verifying the above items. If the warning message still appears, contact a local dealer near you or Delta to return this product.  |
| 5  | HAND<br>Warning<br>CE10<br>Comm. Error 10 | Communication Warning 10: Modbus transmission time-out         Corrective Action         ☑ Verify that the communication wiring is correct.         ☑ Verify that there is any noise interference.         Press the RESET button after verifying the above items. If the warning message still appears, contact a local dealer near you or Delta to return this product.   |
| 7  | Warning<br>SE1<br>Save Error 1            | <ul> <li>Keypad copy parameter warning 1: Errors during copying which include communication delay, communication error and parameter value error.</li> <li>Corrective Action <ul> <li>Verify that the communication wiring is correct.</li> </ul> </li> <li>Press the RESET button after verifying the above item. If the warning message still appears, contact a local dealer near you or Delta to return this product.</li> </ul>                                    |
| 8  | Warning<br>SE2<br>Save Error 2            | <ul> <li>Keypad copy parameter warning 2: Keypad copy completes but there is still a parameter writing error.</li> <li>Corrective Action <ul> <li>Verify that the communication wiring is correct.</li> </ul> </li> <li>Press the RESET button after verifying the above item. If the warning message still appears, contact a local dealer near you or Delta to return this product.</li> </ul>  |
| 11 | HAND<br>Warning<br>SE3<br>Copy Model Err  | <ul> <li>Keypad copy parameter warning 3: The copied parameters do not match the Power Regenerative Unit model.</li> <li>Corrective Action</li> <li>✓ Verify that the model number and model name saved in the keypad match the model number and model name in the copied parameters.</li> <li>Press the RESET button after verifying the above item. If the warning message still appears, contact a local dealer near you or Delta to return this product.</li> </ul> |
| 12 | Warning<br>LvS<br>Lv at Stop              | Low DC voltage warning: In either the Ready status or the Run status, the<br>Power Regenerative Unit DC BUS voltage ( $V_{DC}$ ) is lower than the setting<br>value in Pr.03-00.<br>For 440V series when $V_{DC} \le 360$ V and for 220 series when $V_{DC} \le 180$ V,<br>this warning message appears.  |

|    |                    | Corrective Action   |
|----|--------------------|---|
|    |                    | <ul> <li>Verify that the mains voltage is normal</li> <li>Verify that the mains three-phase wiring is correct.</li> </ul> |
|    |                    |   |
|    |                    | When the $V_{DC}$ is greater than the setting in Pr.03-00 (+30/60 V), this  |
|    |                    | warning message appears and the system automatically resets.  |
|    |                    | If the warning message still appears after verifying the above items,   |
|    |                    | contact a local dealer near you or Delta to return this product.  |
|    |                    | Phase lock warning: In either the Ready status or the Run status, the   |
|    |                    | mains electricity frequency is not between 47–63 Hz (see Mains  |
|    |                    | Frequency Range in Chapter 03 Specification) and the deviation time is  |
|    |                    | longer than the setting in Pr.03-04.  |
|    | HAND               | Corrective Action   |
| 13 | Warning            | $\blacksquare$ Verify that the mains frequency is normal.   |
| 10 | PLE                | Verify that the mains three-phase wiring is correct.  |
|    | Phase Lock Warning |   |
|    |                    | When the Power Regenerative Unit executes the phase-lock again, the   |
|    |                    | system automatically resets. If the warning message still appears after   |
|    |                    | verifying the above items, contact a local dealer near you or Delta to return   |
|    |                    | this product.   |
|    |                    | Phase loss warning: In the Ready status or the Run status, the  |
|    |                    | three-phase mains power loses one or two phases.  |
|    |                    | Os mas stirus Astism  |
|    | HAND               | Corrective Action<br>☑ Verify that the mains three-phase voltages are similar.  |
|    | Warning            | $\square$ Verify that the mains three-phase wiring is correct.  |
| 14 | OrP                |   |
|    | Phase Lock Warning | When the voltage of the mains is back to normal, the system automatically   |
|    |                    | resets. If the warning message still appears after verifying the above items,   |
|    |                    | contact a local dealer near you or Delta to return this product.  |
|    |                    |   |

#### 08 Warnings and Error Codes | REG2000

#### Error Codes

|   |             | H |
|---|-------------|---|
| 1 | Fault       |   |
| 2 | ocA         |   |
| 3 | Oc at accel |   |

- ① Display error type
- Display error code (abbreviation)
   This error code is the same as displayed on the digital controller (KPC-CE01)
- ③ Display error description

\*: In accordance with the setting value in Pr.00-20-Pr.00-25

| ID # | LCM panel display                | Description  |
|------|----------------------------------|--|
|      |                                  | Over-current during regeneration; input current exceeds 2.4 times the  |
|      |                                  | Power Regenerative Unit rated current.   |
| 3    | Fault<br>ocn<br>oc at normal SPD | <ul> <li>Corrective Action</li> <li>☑ Check for any poor wiring insulation.</li> <li>☑ Increase the DC BUS voltage operating level (see Pr.01-08)</li> <li>☑ Verify that you chose the right Power Regenerative Unit. See Chapter 10 Power Regenerative Unit Selection for more information.</li> <li>☑ Check for any unusual voltage surge or phase loss at the mains side.</li> </ul>  |
|      |                                  | Press the RESET button after verifying the above items. If the error   |
|      |                                  | message still appears, contact a local dealer near you or Delta to return this   |
|      |                                  | product.   |
|      |                                  | Over-current occurs in the Ready status or the Run status, or hardware   |
|      |                                  | circuit error occurs in output current detection.  |
| 6    | Fault<br>ocS                     | <ul> <li>Corrective Action</li> <li>☑ Check for any poor wiring insulation.</li> <li>☑ Check for any unusual voltage surge or phase loss at the mains side.</li> </ul>   |
|      | oc at stop                       | Press the RESET button after verifying the above items. If the error   |
|      |                                  | message still appears, contact a local dealer near you or Delta to return this   |
|      |                                  | product.   |
|      |                                  | While regenerating, the Power Regenerating Unit detects over-voltage on  |
|      |                                  | the high-voltage end of the internal DC voltage.   |
|      |                                  | For 440V series when $V_{DC} \ge 820$ V and for 220 series when $V_{DC} \ge 410$ V,  |
|      |                                  | this warning message appears.  |
| 9    | Fault<br>ovn<br>ov at normal SPD | <ul> <li>Corrective Action</li> <li>Check the power supply wiring between terminals R, S, T for poor insulation or phase loss.</li> <li>Check that the input voltage is in the Power Regenerative Unit voltage rated range, and monitor for voltage surges.</li> <li>Lower the DC BUS voltage activation level (Pr.01-08) or increase the current limit (Pr.03-01).</li> <li>If there is a voltage surge, there may be a phase lead capacitor switch in the same power supply system that causes an abnormal rise in input voltage.</li> <li>Press the RESET button after verifying the above items. If the error</li> </ul> |
|      |                                  | message still appears, contact a local dealer near you or Delta to return this   |
|      |                                  | product.   |
|      |                                  |  |
|      |                                  |  |

|    |                 | Over-voltage occurs in the Ready status or the Run status, or hardware   |
|----|-----------------|--|
|    |                 | circuit error occurs in voltage detection.   |
|    |                 | Corrective Action<br>☑ Check that the input voltage is in the Power Regenerative Unit voltage  |
|    | Fault           | rated range, and monitor for voltage surges.   |
| 10 | ovS             | If there is a voltage surge, there may be a phase lead capacitor switch in the same power supply system that causes an abnormal rise in input voltage.   |
|    | ov at stop      | same power supply system that causes an abhormai rise in input voltage.  |
|    |                 | Press the RESET button after verifying the above items. If the error   |
|    |                 | message still appears, contact a local dealer near you or Delta to return this   |
|    |                 | product.   |
|    |                 | While regenerating, the three-phase main power loses one or two phases.  |
|    |                 |  |
|    | HAND            | Corrective Action  |
| 15 | Fault           | <ul> <li>Verify that the mains three-phase voltages are similar.</li> <li>Verify that the mains three-phase wiring is correct.</li> </ul>  |
|    | OrP             |  |
|    | AC Phase lacked | Press the RESET button after verifying the above items. If the error   |
|    |                 | message still appears, contact a local dealer near you or Delta to return this   |
|    |                 | product.   |
|    |                 | The Power Regenerative Unit detects a temperature higher than the  |
|    |                 | protection level in the power module (see Pr.00-25 in Chapter 07).   |
|    |                 | Corrective Action  |
|    | HAND            | Check if the ambient temperature is too high.  |
| 16 | Fault<br>oH1    | <ul> <li>Check for foreign objects in the heat sink, and if the fan is operating.</li> <li>Check that there is enough ventilation space near the Power</li> </ul>  |
|    | GBT over heat   | Regenerative Unit.   |
|    |                 | After verifying the above items, stop running the unit, wait for ten minutes,  |
|    |                 | and then press the RESET button. If the error message still appears,   |
|    |                 | contact a local dealer near you or Delta to return this product.   |
|    |                 | The Power Regenerative Unit detects an internal (air outlet) overheat  |
|    |                 | higher than the protection level.  |
|    |                 | (This error message appears only when the air outlet temperature for the   |
|    |                 | REG370A23A/REG450A43A/REG550A43A models is higher than 80°C.)  |
|    | HAND            | Corrective Action<br>☑ Check if the ambient temperature is too high.   |
| 17 | Fault           | $\square$ Check for foreign objects in the heat sink, and if the fan is operating.   |
|    | oH2             | <ul> <li>Check that there is enough ventilation space near the Power<br/>Regenerative Unit.</li> </ul>   |
|    | HS over heat    | Regenerative Onit.   |
|    |                 | After verifying the above items, stop running the unit, wait for ten minutes,  |
|    |                 | and then press the RESET button. If the error message still appears,   |
|    |                 | contact a local dealer near you or Delta to return this product.   |
|    |                 | The Power Regenerative Unit detects a temperature lower than normal  |
|    | HAND<br>Fault   | (lower than -30°C) at the power module or a circuit error in temperature.  |
| 18 | tH1o            | Corrective Action  |
|    |                 | I BE THE ALL AND A REPORT I AND A REPORT |
|    | Thermo 1 open   | Increase the temperature and press the RESET button after verifying the above items. If the error message still appears, contact a local dealer near   |

|    |                                  | you or Delta to return this product.  |
|----|----------------------------------|---|
| 19 | Fault<br>tH2o<br>Thermo 2 open   | The Power Regenerative Unit detects a temperature lower than normal<br>(lower than -30°C) at the power module or a circuit error in temperature.Corrective ActionIncrease the temperature and press the RESET button after verifying the<br>above items. If the error message still appears, contact a local dealer near<br>you or Delta to return this product.  |
| 21 | Fault<br>oL<br>Over load         | <ul> <li>Output current (AC) exceeds the Power Regenerative Unit allowed rated current. (See REG2000 Performance Curve in Chapter 03 for the duration (seconds) of output current in the allowable range.)</li> <li>Corrective Action</li> <li>✓ Verify that you chose the right Power Regenerative Unit. See Chapter 10 Power Regenerative Unit Selection for more information.</li> <li>Press the RESET button after verifying the above items. If the error message still appears, contact a local dealer near you or Delta to return this product.</li> </ul> |
| 30 | Fault<br>cF1<br>EEPROM write Err | Memory write error Corrective Action Press the RESET button to restore the system to the default setting. If the error message still appears, contact a local dealer near you or Delta to return this product.  |
| 31 | Fault<br>cF2<br>EEPROM read Err  | Memory read error         Corrective Action         Press the RESET button to restore the system to the default setting. If the error message still appears, contact a local dealer near you or Delta to return this product.   |
| 37 | Fault<br>Hd1<br>oc HW error      | OC protection hardware circuit error         Corrective Action         Current detection error at first power-on. This error cannot be reset.         Shut down the system and then turn the power back on. If the error         message still appears, contact a local dealer near you or Delta to return this         product.  |
| 38 | Fault<br>Hd2<br>Ov HW error      | OV protection hardware circuit error         Corrective Action         Voltage detection error at first power-on. This error cannot be reset.         Shut down the system and then turn the power back on. If the error         message still appears, contact a local dealer near you or Delta to return this         product.  |

|    |                 | Power supply (5V) on control board error<br>Corrective Action   |
|----|-----------------|---|
|    | Fault           | Shut down the system and then turn the power back on. Wait for at least   |
| 42 | 5VF             | five seconds, make sure the supply power is normal, and then reset this   |
|    | 5V fault Err    |   |
|    |                 | error. If the error message still appears, contact a local dealer near you or   |
|    |                 | Delta to return this product.   |
|    | HAND            | Relay error   |
|    | Fault           | Corrective Action   |
| 43 | RYF             | Press the RESET button to return the system to the default setting. If the  |
|    | Relay fault Err | error message still appears, contact a local dealer near you or Delta to  |
|    |                 | return the product.   |
|    |                 | External command causes external fault (EF) and closes terminal (MOx).  |
|    | Fault           | The Power Regenerative Unit stops output.   |
| 49 | EF              | Corrective Action   |
|    | External fault  | Press the RESET button after clearing the faults. If the error message still  |
|    |                 | appears, contact a local dealer near you or Delta to return the product.  |
|    |                 | Password entered incorrectly for three consecutive times  |
|    | Fault           |   |
| 52 | Pco             | Corrective Action<br>☑ See Pr.01-02 and Pr.01-03.   |
|    | Password error  | Shut down the system and then turn the power back on to enter the   |
|    |                 | correct password.   |
|    |                 | Illegal communication command   |
|    |                 | Corrective Action   |
|    |                 | Conective Action  |
|    | Fault           | <ul> <li>Verify that the communication wring is correct.</li> <li>Check if communication commands are correct (communication</li> </ul> |
| 54 | CE1             | commands must be 03, 06, 10, 63).   |
|    | PC Err command  |   |
|    |                 | Press the RESET button after verifying the above items. If the error  |
|    |                 | message still appears, contact a local dealer near you or Delta to return the   |
|    |                 | product.  |
|    |                 | Illegal communication address (00H–254H)  |
|    |                 |   |
|    | HAND            | Corrective Action<br>☑ Verify that the communication wring is correct.  |
| 55 | Fault           | $\square$ Check if the address of communication data is correct.  |
| 55 | CE2             |   |
|    | PC Err address  | Press the RESET button after verifying the above items. If the error  |
|    |                 | message still appears, contact a local dealer near you or Delta to return the   |
|    |                 | product.  |
|    |                 | Illegal communication data value  |
|    | HAND            |   |
| 56 | Fault           | Corrective Action<br>☑ Verify that the communication wring is correct.  |
| 50 | CE3             | <ul> <li>Check if the communication data value exceeds the maximum /</li> </ul>   |
|    | PC Err data     | minimum values (see Chapter 07).  |
|    |                 | Press the RESET button after verifying the above items. If the error  |
| J  |                 |   |

|    |                                | message still appears, contact a local dealer near you or Delta to return the product.  |
|----|--------------------------------|---|
| 57 | Fault<br>CE4<br>PC slave fault | Data written to read-only addresses         Corrective Action         ☑ Verify that the communication wring is correct.         ☑ Check that the communication address is correct.         Press the RESET button after verifying the above items. If the error message still appears, contact a local dealer near you or Delta to return the product.  |
| 58 | Fault<br>CE10<br>PC time out   | Modbus transmission time-out         Corrective Action         ☑       Verify that the communication wring is correct.         Press the RESET button after verifying the above item. If the error         message still appears, contact a local dealer near you or Delta to return the product.   |
| 66 | Fault<br>PLE<br>Phase Lock Err | <ul> <li>While regenerating, the mains electricity frequency is not between 47–63</li> <li>Hz (see Mains Frequency Range in Chapter 03 Specification) and the deviation time is longer than the setting in Pr.03-04.</li> <li>Corrective Action <ul> <li>✓ Verify that the mains frequency is normal.</li> <li>✓ Verify that the mains three-phase wiring is correct.</li> </ul> </li> <li>Press the RESET button after verifying the above items. If the error message still appears, contact a local dealer near you or Delta to return the product.</li> </ul> |


# 09 Usage Recommendations and Troubleshooting

9-1 Regular Maintenance
9-2 Greasy Dirt Problems
9-3 Fiber Dust Problems
9-4 Corrosion Problems
9-5 Industrial Dust Problems
9-6 Installation and Wiring Problems
9-7 Multi-function Input/Output Terminal Application Problems

The Power Regenerative Unit has various warnings and protections against errors such as over-voltage, low voltage, or over-current. Once an error occurs, the protections activate, the Power Regenerative Unit stops output and activates the error contacts. Please refer to the error display from the Power Regenerative Unit and look up the corresponding causes and solutions. The fault record is stored in the Power Regenerative Unit internal memory and can store the six most recent error messages. You can read it from the digital keypad or through the communications by accessing the parameters.

The Power Regenerative Unit includes a large number of electronic components, including ICs, resistors, capacitors, transistors, cooling fans and relays. These components do not last forever. Even under normal circumstances, they will eventually become error-prone if used past their lifespans. Therefore, you must perform periodic preventive maintenance to identify defective and worn out parts, and eliminate the causes of malfunctions in the Power Regenerative Unit at an early stage. At the same time, parts that have exceeded their product life should be replaced whenever possible to ensure safe operation.

Visual checks should be done regularly to monitor the unit's operation, and to make sure nothing unusual happens. Check the situations listed in the following table.



☑ The performance and the surrounding environment should meet the standard specifications. There should be no abnormal noise, vibration, or odor.

### 9-1 Regular Maintenance

For regular maintenance, first stop operation, then turn off the power, and then take off the outer cover. Even after turning off the power supply, charging voltages remaining in the filter capacitor require some time to discharge. To avoid danger, operation must not start until the charging indicator goes off, and you confirm the voltage with a voltmeter to be below the safety value ( $\leq 25 V_{DC}$ ).

### Ambient environment

|   |   | Maintenance Period |              |             |  |
|---|---|--------------------|--------------|-------------|--|
| Items to Check  | Methods and Criterion                       | Daily              | Half<br>Year | One<br>Year |  |
| Check the ambient temperature, humidity,<br>vibration, and check for any dust, gas, oil, water<br>drops, and so on. | Visual inspection and measuring instruments | 0                  |              |             |  |
| Are dangerous or abnormal objects such as tools in the surrounding area?  | Visual inspection                           | 0                  |              |             |  |

### Voltage

| Items to Check                                    | Methods and Criterion     | Maintenance Period |      |      |  |
|---|---------------------------|--------------------|------|------|--|
|   |                           | Daily              | Half | One  |  |
|   |                           | Daily              | Year | Year |  |
| Are the main circuit and control circuit voltages | Measure with a multimeter | 0                  |      |      |  |
| normal?   |                           |                    |      |      |  |

### Keypad display panel

| Items to Check                      | Methods and Criterion | Maintenance Period |      |      |
|-------------------------------------|-----------------------|--------------------|------|------|
|                                     |                       | Daily              | Half | One  |
|                                     |                       |                    | Year | Year |
| Are the displays clear for reading? | Visual inspection     | 0                  |      |      |
| Are there any missing characters?   | Visual inspection     | 0                  |      |      |

### **Mechanical parts**

|  |                       | Maintenance Period |      |             |  |
|--|-----------------------|--------------------|------|-------------|--|
| Items to Check                                   | Methods and Criterion | Daily              | Half | One<br>Year |  |
| Are there abnormal sounds or vibrations?         | Visual and auditory   | 0                  | 0    |             |  |
|  | inspection            |                    |      |             |  |
| Are any bolts (or other fastening pieces) loose? | Securely tighten      | 0                  | 0    |             |  |
| Are any parts deformed or damaged?               | Visual inspection     | 0                  | 0    |             |  |
| Is there any discoloration due to overheating?   | Visual inspection     | 0                  | 0    |             |  |
| Is there any dust or dirt?                       | Visual inspection     | 0                  | 0    |             |  |

### Main circuit

|  |                       | Maintenance Period |              |             |  |
|--|-----------------------|--------------------|--------------|-------------|--|
| Items to Check                                 | Methods and Criterion | Daily              | Half<br>Year | One<br>Year |  |
| Are any bolts loose or missing?                | Securely tighten      | 0                  |              |             |  |
| Is the machine or insulator deformed, cracked, |                       |                    |              |             |  |
| damaged, or discolored due to overheating and  | Visual inspection     |                    | 0            |             |  |
| aging?   |                       |                    |              |             |  |
| Is there any dust or dirt?                     | Visual inspection     |                    | 0            |             |  |

### Main circuit terminal and wiring

|   |                       |       | Maintenance Period |             |  |  |
|---|-----------------------|-------|--------------------|-------------|--|--|
| Items to Check                                  | Methods and Criterion | Daily | Half<br>Year       | One<br>Year |  |  |
| Are the terminals and copper plates deformed or | Visual inspection     |       | 0                  |             |  |  |
| discolored due to overheating?                  |                       |       |                    |             |  |  |
| Is any wire insulation damaged or discolored?   | Visual inspection     |       | 0                  |             |  |  |

### Main circuit terminal block

|                      |                       | Maintenance Period |              |             |  |
|----------------------|-----------------------|--------------------|--------------|-------------|--|
| Items to Check       | Methods and Criterion | Daily              | Half<br>Year | One<br>Year |  |
| Is there any damage? | Visual inspection     | 0                  |              |             |  |

### Main circuit filter capacitor

|  |                       | Maintenance Period |              |             |  |  |
|--|-----------------------|--------------------|--------------|-------------|--|--|
| Items to Check                                     | Methods and Criterion | Daily              | Half<br>Year | One<br>Year |  |  |
| Are there any liquid leaks, discoloration, cracks, | Visual inspection     | 0                  |              |             |  |  |
| or shell expansions?                               |                       |                    |              |             |  |  |
| Are the safety valves released? Are the valve      | Visual inspection     | 0                  |              |             |  |  |
| bodies significantly expanded?                     |                       |                    |              |             |  |  |
| Measure electrostatic capacity as required         |                       | 0                  |              |             |  |  |

### Main circuit resistor

|   |                          | Maintenance Period |              |             |  |
|---|--------------------------|--------------------|--------------|-------------|--|
| Items to Check                            | Methods and Criterion    | Daily              | Half<br>Year | One<br>Year |  |
| Are there abnormal odors or cracks in the | Visual inspection, smell | 0                  |              |             |  |
| insulator due to overheating?             |                          |                    |              |             |  |
| Are there broken wires?                   | Visual inspection        | 0                  |              |             |  |
| Are the connection joints damaged?        | Measure the resistance   | 0                  |              |             |  |
|   | with a multimeter        |                    |              |             |  |

### Main circuit transformer and reactor

|   |                              | Maintenance Period |              |             |  |
|---|------------------------------|--------------------|--------------|-------------|--|
| Items to Check                                | Methods and Criterion        | Daily              | Half<br>Year | One<br>Year |  |
| Are there abnormal vibrating noises or odors? | Visual inspection, auditory, |                    | TCar         | <u>rca</u>  |  |
|   | smell                        | 0                  |              |             |  |

### Main circuit electromagnetic contactor and relay

|  |                       | Maintenance Period |              |             |  |
|--|-----------------------|--------------------|--------------|-------------|--|
| Items to Check                               | Methods and Criterion | Daily              | Half<br>Year | One<br>Year |  |
|  |                       |                    | Teal         | TEal        |  |
| Is there a vibrating noise during operation? | Auditory inspection   | 0                  |              |             |  |
| Are the contacts well connected?             | Visual inspection     | 0                  |              |             |  |

### Control circuit control printed circuit board and connector

|  |                          | Maintenance Period |              |             |  |
|--|--------------------------|--------------------|--------------|-------------|--|
| Items to Check                                   | Methods and Criterion    | Daily              | Half<br>Year | One<br>Year |  |
| Are there any loose screws or connectors?        | Securely tighten         |                    | 0            |             |  |
| Are there any abnormal odors or discoloration?   | Smell, visual inspection |                    | 0            |             |  |
| Are there cracks, damages, deformations, or      | Visual inspection        |                    | 0            |             |  |
| obvious corrosions?                              |                          |                    |              |             |  |
| Are there signs of leakage or deformation in the | Visual inspection        |                    | 0            |             |  |
| capacitors?                                      |                          |                    |              |             |  |

### Cooling system cooling fan

|  |                             | Maintenance Period |              |             |  |
|--|-----------------------------|--------------------|--------------|-------------|--|
| Items to Check                                 | Methods and Criterion       | Daily              | Half<br>Year | One<br>Year |  |
|  | Auditory, visible           |                    |              |             |  |
|  | inspection, and turn the    |                    |              |             |  |
| Are there abnormal sounds or vibrations?       | fan by hand (turn off the   |                    | 0            |             |  |
|  | power before operation) to  |                    |              |             |  |
|  | see if it rotates smoothly. |                    |              |             |  |
| Are any bolts loose?                           | Securely tighten            |                    | 0            |             |  |
| Is there any discoloration due to overheating? | Visual inspection           |                    | 0            |             |  |

### Cooling system ventilation channel

|  |                       | Maintenance Period |              |             |  |
|--|-----------------------|--------------------|--------------|-------------|--|
| Items to Check                                     | Methods and Criterion | Daily              | Half<br>Year | One<br>Year |  |
| Are heat sinks or vents blocked or obstructed with | Visual inspection     |                    | 0            |             |  |
| abnormal objects?                                  |                       |                    |              |             |  |

Use a chemically neutral cloth for cleaning and use dust cleaner to remove dust when necessary.


### 9-2 Greasy Dirt Problems

Serious greasy dirt problems generally occur in processing industries such as machine tools, punching machines and so on. Please be aware of the possible damages that greasy oil may cause to your Power Regenerative Unit.

- 1. Electronic components that silt up with greasy oil may cause the Power Regenerative Unit to burn out or even explode.
- 2. Most greasy dirt contains corrosive substances that may damage the Power Regenerative Unit.

### Solution

Install the Power Regenerative Unit in a dedicated cabinet to keep it away from greasy dirt. Clean and remove greasy dirt regularly to prevent damage to the unit.



# 9-3 Fiber Dust Problems

Serious fiber dust problems generally occur in the textile industry. Please be aware of the possible damages that fiber may cause to your Power Regenerative Unit.

- 1. Fiber that accumulates or adheres to the fans leads to poor ventilation and causes overheating problems.
- 2. Plant environments in the textile industry have higher degrees of humidity that may cause the Power Regenerative Unit to burn out, become damaged or explode due to wet fiber dust adhering to the devices.

### Solution

Install the Power Regenerative Unit in a dedicated cabinet to keep it away from fiber dust. Clean and remove fiber dust regularly to prevent damage to the unit.







### PLC1.ir


### 9-4 Corrosion Problems

Corrosion problems may occur if any fluids flow into the Power Regenerative Units. Please be aware of the possible damages that corrosion may cause to your Power Regenerative Unit.

1. Corrosion of internal components may cause the unit to malfunction and possibility to explode.

### Solution

Install the Power Regenerative Unit in a dedicated cabinet to keep it away from fluids. Clean the unit regularly to prevent corrosion.



# 9-5 Industrial Dust Problems


Serious industrial dust pollution frequently occur in environments such as stone processing plants, flour mills, cement plants, and so on. Please be aware of the possible damages that industrial dust may cause to your Power Regenerative Unit.

- 1. Dust accumulating on electronic components may cause overheating problem and shorten the service life of the Power Regenerative Unit.
- 2. Conductive dust may damage the circuit board and may even cause the unit to explode.

### Solution

Install the Power Regenerative Unit in a dedicated cabinet and cover the unit with a dust cover. Clean the cabinet and ventilation holes regularly for good ventilation.





### 9-6 Installation and Wiring Problems

When wiring the Power Regenerative Unit, the most common problem is incorrect wire installation or poor wiring. Please be aware of the possible damages that poor wiring may cause to your units.

- 1. If screws are not fully tightened, then sparking may occur as impedance increases.
- 2. If you have opened the unit and modified the internal circuit board, the internal components may have been damaged.

### Solution

Ensure that all screws are tightened when installing the Power Regenerative Unit. If the unit functions abnormally, send it back to Delta for repair. DO NOT try to modify or repair the internal components or wiring.







PLC1.ir


# 9-7 Multi-function Input/Output Terminal Application Problems


Multi-function input/output terminal errors are generally caused by over-usage of the terminals and not following the specifications. Please be aware of the possible damages that multi-function input/output terminal errors may cause to your Power Regenerative Unit.

1. Input/output circuit may burn out when the terminal usage exceeds the specified limit.

### Solution

Refer to the user manual for multi-function input output terminals usage and follow the specified voltage and current. DO NOT exceed the specification limits.





### PLC1.ir

# 10 Power Regenerative Unit Selection

Delta offers four ways to select a REG2000 model.

- A. Select the model based on the brake resistor specifications. Select the model according to the applications that require rapid acceleration and deceleration, such as tapping, drilling machines, and lathes.
- B. Select the model based on the drive's overload ability. A servo drive has a higher overload ability than an AC motor drive. So select the model that has a larger capacity if you use the servo drive.
- C. Select the model based on the application load characteristics. Calculate the regenerated power for the applications using the application's system characteristics and specifications, especially for elevator and hoist application.
- D. Use the Delta REG2000 Sizing Wizard:

中文: http://deltavfdsizingtool.deltaww.com/REG2000/TC/index.html

ENGLISH: http://deltavfdsizingtool.deltaww.com/REG2000/EN/index.html

This chapter describes the first three model selection methods in more detail.

Model selection method 1 (based on the brake resistor specifications)

Take 220 V as an example; if you select a 1500 W 13  $\Omega$  brake resistor with brake level set to 380 V, then the total braking current would be 380 V / 13  $\Omega$  = 29 A.

DC power equals to AC power, that is,  $V_{DC} * I_{DC} = \sqrt{3} * V_{AC} * I_{AC}$ .

 $V_{AC}\xspace$  is AC voltage

 $I_{\text{AC}}$  is AC current

 $V_{\text{DC}}$  is DC voltage

 $I_{\text{DC}}$  is DC current

For example,  $I_{AC} = (V_{DC} * I_{DC}) / (\sqrt{3} * V_{AC}) = (380*29) / (\sqrt{3} * 220) = 28.9 \text{ A}.$ 

The brake resistor's braking torque is 125% at 10% ED, and REG2000 is 150% at 10% ED; therefore, you can make your selection using the REG2000's current at 150% in the following tables. In this example, you can select REG075A23A-21, as the current at 150% of 30 A > total braking current of 28.9 A.

#### 230V Series

| Frames   |                       | ļ   | A B C |            |      | В   |     |     |
|----------|-----------------------|-----|-------|------------|------|-----|-----|-----|
| Model R  | EGA23A-21             | 075 | 110   | 150        | 185  | 220 | 300 | 370 |
| Rated Po | ower (kW)             | 7.5 | 11    | 15 18.5 22 |      | 30  | 37  |     |
| Mains    | Input current (A)     | 20  | 32    | 38         | 49   | 60  | 80  | 100 |
| IVIAILIS | Input current at 150% | 30  | 48    | 57         | 73.5 | 90  | 120 | 150 |

#### 460V Series

| Frames   |                       |      | А    |     |             | В  |      |      | С   |       |
|----------|-----------------------|------|------|-----|-------------|----|------|------|-----|-------|
| Model R  | EGA43A-21             | 075  | 110  | 150 | 185 220 300 |    | 370  | 450  | 550 |       |
| Rated Po | ower (kW)             | 7.5  | 11   | 15  | 18.5        | 22 | 30   | 37   | 45  | 55    |
| Mains    | Input current (A)     | 10.5 | 17   | 20  | 25          | 32 | 43   | 49   | 60  | 75    |
| mains    | Input current at 150% | 15.8 | 25.5 | 30  | 37.5        | 48 | 64.5 | 73.5 | 90  | 112.5 |

\*Please contact Delta if the required current exceeds the units listed above.

### Model selection method 2 (based on the drive's overload ability)

Select the model based on the drive's overload ability. The table below is an example for the C2000 using with REG2000 when the condition is 10% ED and the maximum regenerated working time during one cycle is 10 seconds. The overload ability of C2000 is 160% 3 seconds and 120% 60 seconds based on the rated output current.

| Voltage | 10% ED 10 seconds |                                     |          |  |  |  |  |
|---------|-------------------|-------------------------------------|----------|--|--|--|--|
|         | Drive             | REG select                          | tion     |  |  |  |  |
|         | kW                | Model                               | Quantity |  |  |  |  |
|         | 0.7               | REG075A23A                          | 1        |  |  |  |  |
|         | 1.5               | REG075A23A                          | 1        |  |  |  |  |
|         | 2.2               | REG075A23A                          | 1        |  |  |  |  |
|         | 3.7               | REG075A23A                          | 1        |  |  |  |  |
|         | 5.5               | REG075A23A                          | 1        |  |  |  |  |
|         | 7.5               | REG075A23A                          | 1        |  |  |  |  |
| 220 V   | 11                | REG110A23A                          | 1        |  |  |  |  |
| 220 V   | 15                | REG110A23A                          | 1        |  |  |  |  |
|         | 18                | REG150A23A                          | 1        |  |  |  |  |
|         | 22                | REG185A23A                          | 1        |  |  |  |  |
|         | 30                | REG220A23A                          | 1        |  |  |  |  |
|         | 37                | REG300A23A                          | 1        |  |  |  |  |
|         | 45                | REG370A23A                          | 1        |  |  |  |  |
|         | 55                | Diagon contest                      |          |  |  |  |  |
|         | 75                | Please contact<br>Delta Electronics | -        |  |  |  |  |
|         | 90                |                                     |          |  |  |  |  |

| Voltage |       | 10% ED 10 seconds                   | 5        |
|---------|-------|-------------------------------------|----------|
|         | Drive | REG selecti                         | on       |
| 440 V   | kW    | Model                               | Quantity |
|         | 0.7   | REG075A43A                          | 1        |
|         | 1.5   | REG075A43A                          | 1        |
|         | 2.2   | REG075A43A                          | 1        |
|         | 3.7   | REG075A43A                          | 1        |
|         | 4     | REG075A43A                          | 1        |
|         | 5.5   | REG075A43A                          | 1        |
|         | 7.5   | REG075A43A                          | 1        |
|         | 11    | REG075A43A                          | 1        |
|         | 15    | REG110A43A                          | 1        |
|         | 18    | REG150A43A                          | 1        |
|         | 22    | REG185A43A                          | 1        |
|         | 30    | REG220A43A                          | 1        |
|         | 37    | REG300A43A                          | 1        |
|         | 45    | REG370A43A                          | 1        |
|         | 55    | REG450A43A                          | 1        |
|         | 75    | REG550A43A                          | 1        |
|         | 90    |                                     |          |
|         | 110   |                                     |          |
|         | 132   |                                     |          |
|         | 160   | Please contact<br>Delta Electronics |          |
|         | 185   |                                     | -        |
|         | 220   |                                     |          |
|         | 280   |                                     |          |
|         | 315   |                                     |          |
|         | 355   |                                     |          |


Model selection method 3 (based on the application load characteristics)

### **Crane/Hoist Application**

The equipment weighs 10 tons, drive model: VFD075CH43A, with a 5.5 kW motor. From the crane's specification we know

| Model No. V10C   | 4 <b>B</b> 036I-V | V18I         | Serial No.   | erial No. |  |
|------------------|-------------------|--------------|--------------|-----------|--|
| Capacity 10      | то                | N Duty Cy    | cle 40%ED, 1 | SO M5     |  |
| Lifting Height 9 | m H               | loisting Spe | ed 3.6/0.36  | m/min     |  |
| Trolley Type W   |                   | raveling Sp  | eed 24/2.4   | m/min     |  |

- 1. In high speed operation, the time it takes from top to bottom is 9 (m)/3.6 (m/min) = 2.5 (min) = 150 (sec).
- Assuming the motor efficiency is 85%, the mechanical efficiency is 85%, and the drive and the REG2000's efficiencies are both 95%, the useful power output would be 5.5 kW\*0.85<sup>2</sup>\*0.95<sup>2</sup> = 3.57 kW.
- 3. When using the REG2000, and the mains voltage is 380 V, the current would be 3.57 kW/(sqrt(3)\*380 V) = 5.4 A.
- 4. From the table below, at 40% ED, and a working duration of 150 seconds, the output current must be lower than 90% of the rated current to avoid overload.



% The diagram above shows the testing result by combining REG and a DC choke.


Definition of ED%: See Chapter 03 Specifications.

5. From the specification sheet, the REG075A43A-21 rated current is 10.5 A, and 10.5 A\*90% = 9.45 A > 5.4 A; therefore, in this case, you can select the REG075A43A-21.

#### **Elevator Application**

For this example, take an elevator with two tons of working load, a speed of 60 m/min, floors from B1–4F, using 22 kW motor, and a counterweight of 48%.

- 1. The elevator takes 30 seconds to reach floor 4F from B1, and the whole trip takes 100 seconds, then ED = 30/100 = 30%.
- 2. Assuming the motor efficiency is 85%, mechanical efficiency is 85%, and the drive and the REG2000's efficiencies are both 95%, the useful power output would be 22 kW \* 85% \* 85% \* 95% \* 95% = 14.3 kW.
- 3. When using the REG2000, and the mains voltage is 380 V, the current would be 14.3 kW/(sqrt(3)\*380 V) = 21.8 A.
- 4. From the table below, at 30% ED, and a working duration of 30 seconds, the output current must be lower than 115% of the rated current to avoid overload.



- % The diagram above shows the testing result by combining REG and a DC choke.
  - Definition of ED%: See Chapter 03 Specifications.
- 5. From the specification sheet,

the REG110A43A-21 rated current is 17 A, 17 A\*115% = 19.55 A < 21.8 A, and the REG150A43A-21 rated current is 20 A, 20 A\*115% = 23 A > 21.8 A; therefore, in this case, you can select the REG150A43A-21.