



## Appendix I FBs-PACK Operation Instruction


The main unit of FBs series PLC provides the function to write ladder program and the selected data registers into MEMORY\_PACK directly.

FBs-PACK is the product name of MEMORY PACK; the memory capacity is 64K WORD. Setting the DIP switch of the MEMORY\_PACK at the unprotect position while writing, and at the protect ON position to avoid accidental writing.

To operate friendly, WinProladder supports the corresponding MEMORY PACK operation interface; but for general usage, the direct register's access method is also introduced for further reference.


### 1.1 Write Program and Register Data to FBs-PACK Through WinProladder

Select Run MEMORY\_PACK from Tool :  : 



- Write program and data to MEMORY\_PACK :

Users can write programs and data into the MEMORY\_PACK with this function. After clicking Next, the window display below :



Users can assign the range of registers which you want to read from MEMORY\_PACK and write into PLC. If you don't want to back-up any data of register, press "Execute" to start. The execution time may differ depending on the size of ladder program and register data. During writing data into MEMORY\_PACK, the system will appear the message "Under programming, please wait...". If the data are successfully stored into MEMORY\_PACK, the message "MEMORY\_PACK write OK" will appear. If it failed, the message "MEMORY\_PACK write error" will appear.

- ※ It is allowed up to 4 groups of register or system backup for MEMORY\_PACK manipulation, click "Add" or "Edit" or "Delete" to accomplish the writing and further retrieve of the selected registers.
- ※ The item "System Backup" means stored all of data (including the PLCID and station number of PLC) into MEMORY\_PACK.

- System backup

There are two kinds of system backup for ROM PACK writing as below:

- ◆ System backup with PLC ID
- ◆ System backup without PLC ID

- While selecting the "System backup with PLC ID" for ROM PACK writing, the PLC main unit will read the PLC ID and ladder program from ROM PACK every power up if the ROM PACK has been installed for working; but all data registers and discrete status will read only once (Selecting "After initial system, read back the data one time") or every time (Selecting "When power on, read back the data every time") depending on the selective item.

It can make the ID (PLC ID and PROGRAM ID) copy for the main unit needing ID protection through this kind of ROM PACK without the intervention of programming tools.

This kind of ROM PACK can't be installed for working to have intellectual ID protection.

- While selecting the “System backup without PLC ID” for ROM PACK writing, the PLC main unit will read the ladder program from ROM PACK every power up if the ROM PACK has been installed for working; but all data registers and discrete status will read only once (Selecting “After initial system, read back the data one time”) or every time (Selecting “When power on, read back the data every time”) depending on the selective item.

It needs to have correct PLC ID setting for the PLC main unit to enter RUN mode if being installed ROM PACK with program ID protection; it means the PLC ID of the main unit must be same with the program ID of the ROM PACK, then the PLC main unit can work without problem.

This kind of ROM PACK can be installed for working to have intellectual ID protection; it is very suitable for mass production and long term maintenance with intellectual property protection.

- ※ While changing the PLC ID, the PLC ID will be written into the internal system FLASH ROM once at the next power up; it will keep the ID information even battery low.
- ※ While executing system initialization, the PLC ID will be erased from the internal system FLASH ROM once at the next power up if it exists.
- ※ While writing the ROM PACK with system backup, the motion parameter table (Assigned by FUN141) will also be included; it means the motion parameters will remain the settings even the system initialization being executed
- ※ It can support “Only read one time” function for ROM PACK accessing while writing the ROM PACK and selecting the item “After initial system, read back the data one time” for both data backup or system backup.

- Data Registers read PLC settings

- ※ “After initial system, read back the data one time” : the PLC main unit will read the data register and discrete status from the ROM PACK only one time at the first power up, and then the main unit doesn’t read the data register and discrete status again from the ROM PACK at the following power up. It is very useful to have default settings for the data registers from the ROM PACK, and after the default initialization, the data register can remain the new setting without loss at the next power up.
- ※ “When power on, read back the data every time” : the PLC main unit will read the data register and discrete status from the ROM PACK every power up. It is very useful to have the default settings for the data registers from the ROM PACK at every power up, the PLC main unit being equipped with this kind of ROM PACK can work properly even the battery low.

### 1.1.2 Erase MEMORY\_PACK

Users can clear programs or data stored in MEMORY\_PACK with this function. Click “NEXT”, it is showing “Under erase, please wait...”. It will show “MEMORY\_PACK erase OK” if this erase is successful. It will show “MEMORY\_PACK erase error” if this erase is failed.

### 1.1.3 Disable FLASH Content Loading When Power On:

Users can enter the test run modification mode with this function. Please Next to enter test run modification mode (Disable programs and data overwrite).

- ※ If the user needs to equip with a new MEMORY\_PACK, selecting this item first to avoid the undesired overwrite of ladder program by which storing in the new MEMORY\_PACK while power up. This function is used to let the main unit enter into the "Modify and Testing" mode for programming if it equips with the MEMORY\_PACK. Please refer to the next page for detailed description.

### 1.1.4 Enable FLASH Content Loading When Power On:

Please Next to complete normal mode setup.

- ※ Every power up, the ladder program and the selected data registers storing in battery backup RAM of the main unit will be placed by which storing in the MEMORY\_PACK (if this MEMORY\_PACK was equipped with the main unit and it had ever been written the ladder program), and the PLC will enter into "RUN" mode automatically regardless it's "RUN" or "STOP" mode before.

## 1.2 Write Program and Register Data to FBs-PACK Through Special Register Operation

To meet the application needs of different customers, users can write data into MEMORY\_PACK by setting special register. WinProladder users can skip this section because setting actions will be completed at the same time when executing MEMORY\_PACK options with WinProladder.

#### Operation relevant special register

- R4052 : Dedicated register for MEMORY\_PACK operation.

Register	Content value	Functions
R4052	5530H (Test run modification mode)	<p>Modify &amp; Test mode for PLC programming while main unit being equipped with the MEMORY_PACK.</p> <p>There are 2 kinds of memory on main unit to store the ladder program and data registers; one is the battery backup RAM, this is standard equipment and the ladder program and data registers must be executed here; another memory to store the ladder program and data registers is the optional MEMORY_PACK, the ladder program and data registers can't be executed here directly. In Modify &amp; Test mode, the ladder program and data registers storing in battery backup RAM of main unit will not be overwritten by the MEMORY_PACK's while power up; it means the content of the battery backup RAM will be kept, and the modification if ever will not be lost, this is so called "Modify &amp; Test mode".</p> <p>After the modification and testing has been finished, writing the ladder program and data registers into the MEMORY_PACK is a better way for long term saving and easy after sale service of maintenance or for mass</p>

R4052		copy of same machine's program. During the modification and testing, if the user want to give up the change, it is only to set R4052 to be 0, and turn off then turn on the power again, the ladder program and data registers storing in battery backup RAM will be overwritten by which storing in the MEMORY_PACK while power up, the main unit will return to the environment before modification.
	Other value	Normal operation or Writing mode. If the main unit equips with the optional MEMORY_PACK, and the MEMORY_PACK had ever been written the ladder program before, while every power up, the ladder program storing in battery backup RAM of the main unit will be replaced by which storing in the MEMORY_PACK, and the PLC will enter into "RUN" mode automatically regardless it's "RUN" or "STOP" mode before.

- R4046 : Dedicated register to retrieve the data registers storing in ROM\_PACK.

While writing the ladder program into the MEMORY\_PACK along with the selected data registers, the content of the selected data registers (locating at the RAM of the main unit) will be initialized with the values which previously being written into the MEMORY\_PACK on each power up; it is very useful for machine turning parameter's long term saving and after sale service of maintenance.

But in many applications, it needs only one time initialization for the selected data registers while the first power up and then the contents of those will be retentive after followings' power up.

User may control the value of R4046 to accomplish above mentioned applications.

Register	Content value	Functions
R4046	5530H	The selected data registers of the main unit will not be initialized with the values which previously being written into the MEMORY_PACK while power up.
	Other value	The selected data registers of the main unit will be initialized with the values which previously being written into the MEMORY_PACK while power up.

- ※ If it needs only one time initialization for selected data registers while the first power up, fill the register R4046 with the value 5530H in the ladder program.

- Either PLC in RUN or in STOP mode, the user can give the command to clear MEMORY\_PACK or write the ladder program and selected registers into MEMORY\_PACK.

Register	Content value	Functions
	5550H	giving the command to clear MEMORY_PACK
	5551H	the status to say " Being cleared"
	5552H	the status to say "Verify for clearing"
	5553H	the status to say "Complete the clear command "
	5554H	the status to say "Failed to clear the MEMORY_PACK"
	5560H	giving the command to write ladder program and selected registers into MEMORY_PACK

R4052	5562H	the status to say "Writing the Ladder Program"
	5563H	the status to say "Writing the Registers"
	5566H	the status to say "Verify the Ladder Program"
	5567H	the status to say "Verify the Registers"
	556AH	the status to say "Complete the writing"
	556BH	the status to say "Failed to write ladder program"
	556CH	the status to say "Failed to write registers"

### 1.3 Assigning the Retrieval of Register Stored FBs-PACK

- The contents of the selected registers can be written into the MEMORY\_PACK and those will be read back from the MEMORY\_PACK for initialization while every power up. The turning values or fixed preset values can be written into the MEMORY\_PACK for this kind of application to keep proper operation even the loss of the battery power.
- The special registers of R4030~R4039 are used to assign which group of registers needed to be written into MEMORY\_PACK for above mentioned application, it is necessary to do the assignment first before giving command to write the MEMORY\_PACK.

Register	Content value	Functions
R4030	A66AH	It is the identification flag to tell the selected registers needed be written into and read back from the MEMORY_PACK according to the following settings of R4031~R4039 (Retentive registers support this function).
	Other value	There is not any register needed be written into and read back from the MEMORY_PACK.
R4031	1~4	Quantity of register groups needed be written into and read back from the MEMORY_PACK (4 in maximum).
R4032	Length 0	The data length of register group 0. The length is between 1 ~ 3840 for register R0 ~ R3839; The length is between 1 ~ 3072 for register R5000 ~ R8071; The length is between 1 ~ 4096 for register D0 ~ D4095; The length is between 1 ~ 166 for register R4000 ~ R4165; While the length is 7FF7H, it means for system backup including the PLC ID and station number of PLC ; It will not work when illegal length or out of range;
R4033	Start 0	The starting address of register group 0. The address is between 0 ~ 3839 for register R0 ~ R3839; The address is between 5000 ~ 8071 for R5000 ~ R8071; The address is between 10000 ~ 14095 for D0 ~ D4095; (The address must be added by 10000 for register Dxxxx) The address is between 4000 ~ 4165 for R4000 ~ R4165; R4033 and R4032 are used in pair.

R 4034	Length 1	The data length of register group 1. The ranges of length same as mentioned above for R4032;
R 4035	Start 1	The starting address of of register group 1. The ranges of address same as mentioned above for R4033; R4035 and R4034 are used in pair.
R 4036	Length 2	The data length of register group 2 The ranges of length same as mentioned above for R4032;
R 4037	Start 2	the starting address of of register group 2 The ranges of address same as mentioned above for R4033; R4037 and R4036 are used in pair.
Register	Content value	Functions
R 4038	Length 3	The data length of register group 3 The ranges of length same as mentioned above for R4032;
R 4039	Start 3	the starting address of of register group 3 The ranges of address same as mentioned above for R4033; R4039 and R4038 are used in pair.

#### 1.4 Read and Write FBs-PACK by Function Instruction

You also can read and write data or ladder program by Function Instruction( FUN161 、FUN162 ). Please refer to 7-144 ~ 7-147 for the instructions explanation and program example for FUN161 and FUN162.