

## Chapter 18 AIO Module


### 18.1 FBs-6AD Analog Input Module

FBs-6AD is one of the analog input modules of FATEK FBs series PLC. It provides 6 channels A/D input with 12 or 14 bits effective resolution.. Base on the different jumper settings it can measure the varieties of current or voltage signal. The reading value is represented by a 14-bit value no matter the effective resolution is set to 12 or 14 bits. In order to filter out the field noise imposed on the signal, it also provides the average of sample input function.

#### 18.1.1 Specifications of FBs-6AD

Item			Specifications		Remark
Total Channel			6 Channel		
Digital Input Value			-8192~-+8191 or    0~16383(14 bits) -2048~-+2047 or    0~4095(12 bits)		
Span Of Analog input	Bipolar*	10V*	*1.Voltage : -10~10V	5.Current : -20~20mA	* : It means the default setting
		5V	2. Voltage : -5~5V	6. Current : -10~10mA	
	Unipolar	10V	3. Voltage : 0~10V	7. Current : 0~20mA	
		5V	4. Voltage : 0~5V	8. Current : 0~10mA	
Resolution			14 or 12 bits		
Finest resolution			Voltage : 0.3mV Current : 0.61μA		= Analog input signal / 16383
I/O Points Occupied			6 IR(Input Register)		
Accuracy			Within ±1% of full scale		
Conversion Time			Updated each scan		
Maximum absolute input signal			Voltage : ±15V ( max ) Current : ±30mA ( max )		It may cause the destruction to hardware if exceeds this value.
Input resistance			63.2KΩ ( Voltage input ) 、 250Ω ( Current input )		
Isolation			Transformer(Power) and photocouple(Signal)		
Indicator(s)			5V PWR LED		
Supply Power			24V-15%/+20% 、 2VA		
Internal Power Consumption			5V 、 100mA		
Operating Temperature			0 ~ 60 ℃		
Storage Temperature			-20 ~ 80 ℃		
Dimensions			40(W)x90(H)x80(D) mm		

### 18.1.2 The Procedure of Using FBs-6AD Module



### 18.1.3 Address Allocation of FBs-PLC Analog Inputs


The I/O addressing of FBs-6AD inputs is beginning from the module closest to main unit, it is orderly numbered as CH0~CH5 (1st module), CH6~CH11 (2nd module), CH12~CH17 (3rd module)…… and increased with occurring order number, i.e. for each module, it adds with 6 and is totally 64 inputs from CH0~CH63, and they are corresponding to the respective internal analogue input register of PLC (so called as IR register) R3840~R3903 as listed in following table. After connecting FBs-6AD to the expansion interface on the PLC, FBs-PLC will automatically detect the number of AD points. WinProladder will automatically detect and calculate the IRs on the system after connecting to the PLC. Users may refer to the I/O Module Number Configuration provided by WinProladder in order to find out the exact I/O address of each expansion module to facilitate programming.

Numeric Input Register (IR)	Content of IR (CH0~CH63)	Input label Of FBs-6AD
	B15 B14 B13 B12 B11 B10 B9 B8 B7 B6 B5 B4 B3 B2 B1 B0	
IR+0	14/12 bit ; 14-bit , B14~ B15= B13 ; 12-bit, B12~ B15= B11	CH0
IR +1	14/12 bit ; 14-bit , B14~ B15= B13 ; 12-bit, B12~ B15= B11	CH1
IR +2	„	CH2
IR +3	„	CH3
IR +4	„	CH4
IR +5	„	CH5
IR +6	Depends on module type	CHX
IR +7	Depends on module type	CHX
IR +8	„	CHX
IR +9	„	CHX

} FBs-6AD

⋮	⋮	⋮	} Other Modules
R3896	"	CHX	
R3897	"	CHX	
R3898	"	CHX	
R3899	"	CHX	
R3900	"	CHX	
R3901	"	CHX	
R3902	Depends on module type	CHX	
R3903	Depends on module type	CHX	

#### 18.1.4 FBs-6AD Hardware Description




※ FBs-6AD contains 3 PCBs overlapping one another. The lowest one is the power supply unit (isolated power supply). The middle one is the I/O board (connectors are on this layer). The upper one is the control board (control/expansion I/O connections) as described below.:


Outlook of top view

- ① External power input terminal : Power supply of analogue circuit for FBs-6AD, the voltage can be 24VDC±20% and should be supplied with 4W of power at least.
- ② Protecting ground terminal : Connect to the shielding of the signal cable.
- ③ Expansion input cable : It should be connected to the front expansion unit, or the expansion output of main unit.
- ④ Expansion output connector : Provides the connection for next expansion unit.
- ⑤ Power indicator : It indicates whether the power supply at analogue circuit and external input power source are normal.
- ⑥ AG Ground : No connection is needed in general; except when the common mode signal is too high. See examples overleaf for details.
- ⑦ ~ ⑫ : Input terminal of CH0~CH5.

#### 18.1.4.1 FBs-6AD Hardware Jumper Setting





Pin layout in control board (open top cover)



Pin layout on I/O board (remove control board)











### 1. Input code format selection (JP1)

Users can select between unipolar and bipolar codes. The input range of unipolar codes and bipolar codes is 0~16383 and -8192~8191, respectively. The two extreme values of these formats correspond to the lowest and highest input signal values, respectively (see table below). For example, if the input signal type is set to -10V~ +10V, the unipolar code corresponding to the input is 8192 and the bipolar code corresponding to the input is 0 for 0V input. If the input is 10V, the unipolar code corresponding to the input is 16383 and the bipolar code corresponding to the input is 8191. In general, the input code format is selected according to the form of input signals; i.e. unipolar codes for unipolar input signals; and bipolar codes for bipolar input signals. In doing so, their correlations will become more heuristics. Unless it is necessary to make a deviation conversion through FUN33; otherwise, do not select bipolar codes for unipolar input signals (see FUN33 description for details). The format of input codes of all channels is selected from JP1. See above diagram for the location of JP1 :

Input Code Format	JP1 Setting	Input Value Range	Corresponding Input Signals
Bipolar	JP1 	-8192 ~ 8191	-10V ~ 10V (-20mA ~ 20mA) -5V ~ 5V (-20mA ~ 20mA)
Unipolar	JP1 	0 ~ 16383	0V ~ 10V (0mA ~ 20mA) 0V ~ 5V (0mA ~ 10mA)



### 2. Input signal form setup (JP2&JP3)

Users can set the input signal form (voltage/current) of individual channels; except the polarity and amplitude which are common. The location of jumpers are tabulated below :

Signal Form	JP3 Setting	JP2 Setting
0 ~ 10V or 0 ~ 20mA		 5V  10V
0 ~ 5V or 0 ~ 10mA		 5V  10V
-10 ~ +10V or -20 ~ +20mA		 5V  10V
-5 ~ +5V or -10mA ~ +10mA		 5V  10V

CH0~CH5 share the JP2 and JP3 jumper, therefore all channels must be of the same type that is one of the four types listed at above table. Only the current/voltage setting can be chosen arbitrary :

### 3. Voltage or current setting (JP4~JP9)

Signal Type	JP4(CH0) ~ JP9(CH5) Setting
Voltage	
Current	


\*The default factory settings of 6AD analogue input module are :

Input code format → Bipolar(-8192~+8191)

Input signal type and range → Bipolar(-10V ~ +10V)

For those applications that require the setting differ than the above default setting should make some modifications of jumper position according to above tables. While application, besides the setting of jumper should be conducted, the AI module configuration of WinProladder also need to be performed.

### 18.1.5 FBs-6AD Input Circuit Diagram




### 18.1.6 FBs-6AD Input Characteristics and Jumper Setting

Users can select the Input ranges of FBs-6AD from the jumpers described above, such as V/I, U/B (I/O codes), U/B (signal form), 5V/10V, etc. The Input signals conversion characteristics of these settings are illustrated below. Users can adjust different Input forms by coordinating the conversion curve with various V/I (voltage/current) Input settings. See Section 18.1.4 for details of V/I settings :

Diagram 1 : Bipolar 10V ( 20mA ) Span

Input Range	Voltage	-10V ~ 10V	Jumper Setting	<div><div>JP3</div><div>B</div><div>U</div></div> <div><div>JP2</div><div>5V</div><div>10V</div></div>	<div><div></div><div>-----</div></div>	<div><div>JP1</div><div><div></div><div></div><div></div></div></div>
	Current	-20mA ~ 20mA				<div><div>JP1</div><div><div></div><div></div><div></div></div></div>

14 bit input format



12 bit input format







Diagram 2 : Bipolar 5V ( 10mA ) Span

Input Range	Voltage	-5V ~ 5V	Jumper Setting	<div>JP3</div> <div>B</div> <div>U</div>	<div>JP2</div> <div>5V</div> <div>10V</div>		<div>JP1</div> <div></div>
	Current	-10mA ~ 10mA					

14 bit input format



12 bit input format







Diagram 3 : Unipolar 10V ( 20mA ) Span

Input Range	Voltage	0V ~ 10V	Jumper Setting	<div>JP3</div> <div>B</div> <div>U</div> <div>JP2</div> <div>5V</div> <div>10V</div>	<div>_____</div> <div>-----</div>	<div>JP1</div> <div></div>
	Current	0mA ~ 20mA				<div>JP1</div> <div></div>

14 bit input format



12 bit input format







Diagram 4 : Unipolar 5V ( 10mA ) Span

Input Range	Voltage	0V ~ 5V	Jumper Setting	<div>JP3</div> <div>B</div> <div>U</div>	<div>JP2</div> <div>5V</div> <div>10V</div>		<div>JP1</div> <div></div>
	Current	0mA ~ 10mA					

14 bit input format



12 bit input format




### 18.1.7 Configuration of Analog Input

For the analog input reading of FBs series PLC, there are 3 kinds of data formats used to represent the reading value in compliance with the variation of the external analog inputs. Also, it supports the average method to improve the drift of the reading value away from the noise interference or unstable original analog signal.


The WinProladder provides the friendly and convenient operation interface for the purpose of analog input configuration. There are "analog input data format", "valid bits", and "number of average" for settings.

#### The procedures for analog inputs configuration with WinProladder

Click the item "I/O Configuration" which in Project Windows :



- If FBs main unit connects with AD Expansion module, then it will auto detect and allotted the system resource(IR).



Description of the configuration screen :

- **AI Data Format** : All analog inputs can be assigned as 12-bit or 14-bit resolution of data format.
- **AI Modules** : This window displays the information of installed analog input modules, click the selective module will bring the setting window for valid bits and times of average.
- **AI Setup** : When the data format is 12-bit resolution, each channel of analog input can be allowed to set the times of average; When the data format is 14-bit resolution, each channel of analog input can be allowed to set the valid bits and times of average.

#### AI Data Format

- 12-bit resolution with sign representation (-2048~2047) :

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
B11	B11	B11	B11	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1

\* B11 = 0----- Positive reading value

1----- Negative reading value

\* B15 ~ B12 = B11

- 12-bit resolution without sign representation (0~4095) :

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
0	0	0	0	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1

- 14-bit but valid 12-bit resolution with sign representation (-8192~8188) :

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
B13	B13	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0	0

\* B13 = 0----- Positive reading value

1----- Negative reading value

\* B15 ~ B14 = B13 ; B1 ~ B0 = 0

\* In this Data Format, because B1 and B0 are fixed 0 then value change by times of 4.

- 14-bit but valid 12-bit resolution without sign representation (0~16380) :

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
0	0	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0	0

\* In this Data Format, because B1 and B0 are fixed 0 then value change by time of 4.

- 14-bit resolution with sign representation (-8192~8191) :

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
B13	B13	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1

\* B13 = 0----- Positive reading value

1----- Negative reading value

\* B15 ~ B14 = B13

- 14-bit resolution without sign representation (0~16383) :

B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
0	0	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1

#### Relative registers of AI configuration

This introduction is for HMI or SCADA User, because they may modify through registers. Winprolader's User can ignore this introduction. When you configure Analog Input format with Winproladder, these value of registers will be finished.

Register	Content	Description
D4042	5612H	all analog inputs are the 12-bit resolution ; it is allowed to set times of average for each channel.
"	5614H	all analog inputs are the 14-bit resolution ; it is allowed to set times of average for each channel.

Register	Content	Description
D4006	B0 = 0	AI channel 0 is valid 12-bit resolution.
	B0 = 1	AI channel 0 is valid 14-bit resolution.
"	⋮	⋮
D4006	B15 = 0	AI channel 15 is valid 12-bit resolution.
	B15 = 1	AI channel 15 is valid 14-bit resolution.
D4007	B0 = 0	AI channel 16 is valid 12-bit resolution.
	B0 = 1	AI channel 16 is valid 14-bit resolution.
"	⋮	⋮
D4007	B15 = 0	AI channel 31 is valid 12-bit resolution.
	B15 = 1	AI channel 31 is valid 14-bit resolution.

Register	Content	Description
D4008	B0 = 0	AI channel 32 is valid 12-bit resolution.
	B0 = 1	AI channel 32 is valid 14-bit resolution.
"	⋮	⋮
	⋮	⋮
D4008	B15 = 0	AI channel 47 is valid 12-bit resolution.
	B15 = 1	AI channel 47 is valid 14-bit resolution.
D4009	B0 = 0	AI channel 48 is valid 12-bit resolution.
	B0 = 1	AI channel 48 is valid 14-bit resolution.
"	⋮	⋮
	⋮	⋮
D4009	B15 = 0	AI channel 63 is valid 12-bit resolution.
	B15 = 1	AI channel 63 is valid 14-bit resolution.

Register	Content	Description
D4010	1 ~ 16	Low byte is used to define the times of average for AI channel 0.
	1 ~ 16	High byte is used to define the times of average for AI channel 1.
⋮	⋮	⋮
	⋮	⋮
D4041	1 ~ 16	Low byte is used to define the times of average for AI channel 62.
	1 ~ 16	High byte is used to define the times of average for AI channel 63.

※ The default of AI data format is 14-bit resolution, valid 12-bit, and times of average is 1.

※ The legal setting value for times of average is 1~16, if it is not the value :

The default for times of average is 1 when it is valid 12-bit resolution.

The default for times of average is 8 when it is valid 14-bit resolution.

### 18.1.8 Tacking on the OFFSET Mode Input

For the process of input for signal source of offset mode (take 4~20mA input for example), the user can set A/D input range to be 0 ~ 20mA, convert the IR value to unipolar (0 ~ 16383), lessen the offset (4mA) value (16383x4/20=3276), then times the maximum input amount (20mA), and divide by the maximum span (4mA~20mA); and it can acquire the offset input conversion from 4mA~20mA reflect to 0~16383, the procedure is as follows :

- Set the A/D input range of analogue input module to be 0~20mA.
- Add the IR (R3840~R3903) value with \* 8192 and then store it into register Rn (the value of Rn is 0~16383).
- Deduct  $3276 (16383 \times \frac{4}{20})$  from value of register Rn, and store the calculated value back to register Rn; if the value is negative, clear the content of register Rn to 0 (the value of Rn is 0~13107).

d. The value of register Rn times 20 and then divide by 16 ( $Rn \times \frac{20}{16}$ ), and it will convert the 4mA~20mA input to range of 0~16383.

e. To sum up the items from a~d, the mathematical equation is as follows :


$$\text{Offset mode conversion value} = [IR + 8192(\text{or } 0) - (16383 \times \frac{4}{20})] \times \frac{20}{16} ; \text{ value is } 0 \sim 16383$$

※ Special to 4~20 mA Offset mode, you can use FUN32 to substitute for processing above, but another offset mode please refer to above processing.

\* note : Step b “Add 8192” is means input code setting in bipolar mode( JP1 setting in position B). If input code setting in unipolar mode (JP1 setting in position U) then you don’t have to “Add 8192”.

#### Using Linear Conversion(FUN33) reading on 4~20mA OFFSET mode

Except using the above mathematical methods and FUN32 to read 4~20mA analog reading conversion, when the OS version is later than 4.08 (including), you may use linear conversion instruction (FUN33) to read 4~20mA conversion input parameters.



- When M0 is “ON”, it will continuous perform 6 registers of conversion starting from R0, where R1000 is the starting address of the table of the conversion parameters, and the corresponding values will be stored into R50~R55.

The converted result is in below:

		Ts	
R1000		3276	
R1001		16383	
R1002		0	
R1003		16383	
		S	
R0	0		
R1	3000		
R2	6000		
R3	9000		
R4	12000		
R5	16383		
		D	
R50	-4094		
R51	-345		
R52	3405		
R53	7155		
R54	10904		
R55	16383		




## 18.2 FBs-4DA/2DA Analog Output Module

FBs-4DA and FBs-2DA are two of the analog output modules of FATEK FBs series PLC. They provide 4 and 2 channels 14 bits D/A output respectively. Base on the different jumper settings it can provide varieties of current or voltage output signal. The output code can be configured as unipolar or bipolar which makes the relation of output code and real output signal more intuitive. For safety, the output signal will be automatically forced to zero(0V or 0mA) when the module is not serviced by CPU for 0.5 second.

### 18.2.1 Specifications of FBs-4DA/2DA

Item			Specifications		Remark
Total Channel			4 Channel（FBs-4DA）、2 Channel（FBs-2DA）		
Digital Output Value			-8192~+8191(Bipolar) or 0~16383(Unipolar)		*：It means the default setting
Span Of Analog output	Bipolar*	*10V	*1. Voltage：-10~10V	5. Current：-20~20mA	
		5V	2. Voltage：-5~5V	6. Current：-10~10mA	
	Unipolar	10V	3. Voltage：0~10V	7. Current：0~20mA	
		5V	4. Voltage：0~5V	8. Current：0~10mA	
Resolution			14 bits		
Finest resolution			0.3mV(Voltage)、0.61μA(Current)		
I/O Points Occupied			4(4DA) or 2(2DA) OR(Output register)		
Accuracy			Within ±1% of full scale		
Conversion Time			Updated each scan		
Maximum accommodation for resistance loading			Voltage：500Ω~1MΩ Current：0Ω~500Ω		The deviation will be enlarged if exceeding this range
Isolation			Transformer(Power) and photocouple(Signal)		
Indicator(s)			5V PWR LED		
Internal Power Consumption			5V、20mA		
Operating Temperature			0~60℃		
Storage Temperature			-20~80℃		
External power supply			24V-15%/+20%、120mA(4DA)、70mA(2DA)		
Dimensions			40(W)x90(H)x80(D) mm		

## 18.2.2 The Procedure of Using FBs-4DA/2DA Analog Output Module



## 18.2.3 Address Allocation of FBs-PLC Analog Outputs

FBs-4DA/2DA Provides 4 points of outputs(4DA) or 2 points of outputs(2DA). The I/O addressing of output is beginning from the module closest to main unit; it is orderly numbered as CH0~CH1 (1st module), CH2~CH3 (2nd module), CH4~CH5 (3rd module)…… and increased with occurring order number, which reaches 64 points in total, and they are corresponding to the respective internal analogue output registers (so called OR register) R3904~R3967. User needs only to expand connecting FBs-DA modules through expansion interface, and main unit will automatically detect the quantity of the outputs and send out the value to corresponding output of each DA modules. The following table is detailed OR registers (R3904~R3967) corresponding to the expansion analogue outputs (CH0~CH63). WinProladder will automatically detect and calculate the ORs on the system after connecting to the PLC. Users may refer to the I/O Module Number Configuration provided by WinProladder in order to find out the exact I/O address of each expansion module to facilitate programming.

I/O allocation of FBs-2DA

Numeric Output Register (OR)	Contents (CH0~CH63)																Output lable Of FBs-2DA
	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0	
OR+0	*	*	B13													B0	CH0
OR+1	*	*															CH1
OR+2	*	*															CH0
OR+3	*	*															CH1
⋮	⋮	⋮															⋮
⋮	⋮	⋮															⋮
⋮	⋮	⋮															⋮
⋮	⋮	⋮															⋮
⋮	⋮	⋮															⋮

FBs-2DA

FBs-2DA

Other modules

R3966	Depends on module type	CHX
R3967	Depends on module type	CHX

\* \* ----- Unipolar code output (0~16383) , B14 、 B15 = 00  
 Bipolar code output (-8192~8191) , B14 、 B15 = B13


#### I/O allocation of FBs-4DA

Numeric Output Register ( OR )	Contents (CH0 ~ CH63)																Output lable Of FBs-4DA
	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0	
OR+0	*	*	B13	CH0 output value												B0	CH0
OR+1	*	*	CH1 output value													CH1	
OR+2	*	*	CH2 output value													CH2	
OR+3	*	*	CH3 output value													CH3	
.	.		.												.		
.	.		.												.		
.	.		.												.		
.	.		.												.		
R3964	Depends on module type																CHX
R3965	Depends on module type																CHX
R3966	Depends on module type																CHX
R3967	Depends on module type																CHX

FBs-4DA


Other modules

## 18.2.4 FBS-2DA /4DA Hardware Description



- ① External power input terminal: Power supply of analogue circuit for this module, the voltage can be  $24\text{VDC} \pm 20\%$  and should be supplied with 4W of power at least.
- ② Protecting ground terminal : Connect to the shielding signal cable.
- ③ Expansion input cable : It should be connected to the front expansion unit, or the expansion output of main unit.
- ④ Expansion output connector : Provides the connection for next expansion unit.
- ⑤ Power indicator : It indicates whether the power supply at analogue circuit and external input power source are normal.
- ⑥ AG Ground : No connection is needed in general; except when the common mode signal is too high. See examples overleaf for details.
- ⑦ 、 ⑧ : Output terminal of CH0~CH1.
- ⑨ 、 ⑩ : Output terminal of CH2~CH3.



18.2.4.1 FBs-4DA/2DA Hardware Jumper Setting



FBs-4DA/2DA Jumper location











Output code format selection (JP1)

Users can select between unipolar and bipolar codes. The output range of unipolar codes and bipolar codes is 0~16383 and -8192~8191, respectively. The two extreme values of these formats correspond to the lowest and highest output signal values, respectively (see table below). In general, the output code format is selected according to the form of output signals; i.e. unipolar codes for unipolar output signals; and bipolar codes for bipolar output signals. In doing so, their correlations will become more heuristics. Yet, as the format of output code on all channels is selected from JP1, it is the user's choice to select unipolar or bipolar codes if both are used on different channels. See diagram above for location of JP1 :


Output Code Format	JP1 Setting	Output Value Range	Corresponding Input Signals
Bipolar	JP1 	-8192 ~ 8191	-10V ~ 10V(-20mA ~ 20mA) -5V ~ 5V(-10mA ~ 10mA)
Unipolar	JP1 	0 ~ 16383	0V ~ 10V(0mA ~ 20mA) 0V ~ 5V(0mA ~ 10mA)

# Output signal form setup (JPA&JPB)

Users can set the output signal form (voltage/current) of individual channels; except the polarity and amplitude which are common.

Signal Form	JPA (voltage/current) Setting	JPB (polarity/amplitude) Setting
0V ~ 10V		
-10V ~ 10V		
0V ~ 5V		
-5V ~ 5V		
0mA ~ 20mA		
-20mA ~ 20mA		
0mA ~ 10mA		
-10mA ~ 10mA		



## 18.2.5 FBs-4DA/2DA Output Circuit Diagram



## 18.2.6 FBs-4DA/2DA Output Characteristics and Jumper Setting

Users can select the output ranges of FBs-4DA/2DA from the jumpers described above, such as V/I, U/B (I/O codes), U/B (signal form), 5V/10V, etc. The Output signals conversion characteristics of these settings are illustrated below. Users can adjust different Output forms by coordinating the conversion curve with various V/I (voltage/current) Output settings. See Section 18.2.4 for details of V/I settings :

Diagram 1 : Bipolar 10V ( 20mA ) Span

Output Range	Voltage	-10V ~ 10V	Jumper Setting		
	Current	-20mA ~ 20mA			






Diagram 2 : Bipolar 5V ( 10mA ) Span

Output Range	Voltage	-5V ~ 5V	Jumper Setting		
	Current	-10mA ~ 10mA			






Diagram 3 : Unipolar 10V ( 20mA ) Span

Output Range	Voltage	0V ~ 10V	Jumper Setting			JP1	<input type="checkbox"/> U <input checked="" type="checkbox"/> B
	Current	0mA ~ 20mA				JP1	<input checked="" type="checkbox"/> U <input type="checkbox"/> B








Diagram 4 : Unipolar 5V ( 10mA ) Span

Output Range	Voltage	0V ~ 5V	Jumper Setting		
	Current	0mA ~ 10mA			



### 18.2.7 Tracking on the OFFSET Mode Output

For the process of output for signal source of offset mode (take 4~20mA output for example), when the OS version is later than 4.08 (including), you may use linear conversion instruction (FUN33) to read 4~20mA conversion output parameters.



- When M0 is “ON”, it will continuous perform 6 registers of conversion starting from R0, where R1000 is the starting address of the table of the conversion parameters, and the corresponding values will be stored into R50~R55.

The converted result is in below:

		Ts	
		R1000	0
		R1001	16383
		R1002	3276
		R1003	16383
		S	
R0		0	
R1		3000	
R2		6000	
R3		9000	
R4		12000	
R5		16383	
		⇒	
		D	
R50		3276	
R51		5676	
R52		8076	
R53		10476	
R54		12876	
R55		16383	

## 18.3 FBs-4A2D Analog Input/Output Module

FBs-4A2D is one of the analog I/O modules of FATEK FBs series PLC. For analog output it provides 2 channels of 14 bit D/A output. Base on the different jumper settings it can provide varieties of current or voltage output signal. The output code can be configured as unipolar or bipolar which makes the relation of output code and real output signal more intuitive. For safety, the output signal will be automatically forced to zero(0V or 0mA) when the module is not serviced by CPU for 0.5 second.

For analog input it provides 4 channels A/D input with 12 or 14 bits effective resolution. Base on the different jumper settings it can measure the varieties of current or voltage signal. The reading value is represented by a 14 bit value no matter the effective resolution is set to 12 or 14 bits The output code also can be configured as unipolar or bipolar which makes the relation of input code and real input signal more intuitive.. In order to filter out the field noise imposed on the signal, it also provides the average of sample input function.

### 18.3.1 Specifications of FBs-4A2D

#### Analog output specifications

Item			Specifications		Remark
Output Channel			2 Channel (2DA)		
Digital Output Value			−8192 ~ +8191(Bipolar) or 0 ~ 16383(Unipolar)		* : It means the default setting
Span Of Analog output	Bipolar*	*10V	*1. Voltage : −10 ~ 10V	5. Current : −20 ~ 20mA	
		5V	2. Voltage : −5 ~ 5V	6. Current : −10 ~ 10mA	
	Unipolar	10V	3. Voltage : 0 ~ 10V	7. Current : 0 ~ 20mA	
		5V	4. Voltage : 0 ~ 5V	8. Current : 0 ~ 10mA	
Resolution			14 bits		
Finest resolution			0.3mV(Voltage)・0.61μA(Current)		
I/O Points Occupied			2 OR(Output register)		
Accuracy			Within ±1% of full scale		
Conversion Time			Updated each scan		
Maximum accommodation for resistance loading			Voltage : 500Ω~1MΩ Current : 0Ω~300Ω		The deviation will be enlarged if exceeding this range

#### Analog input specifications


Item			Specifications		Remark
Input Channel			4 Channel (4AD)		
Digital Input Value			-8192~+8191or 0~16383(14bit) -2048~+2047or 0~4095(12bit)		
Span Of Analog Input	Bipolar*	*10V	*1. Voltage : -10~10V	5. Current : -20~20mA	* : It means the default setting
		5V	2. Voltage : -5~5V	6. Current : -10~10mA	
	Unipolar	10V	3. Voltage : 0~10V	7. Current : 0~20mA	
		5V	4. Voltage : 0~5V	8. Current : 0~10mA	
Resolution			14 or 12 bit		

Finest resolution	Voltage : 0.3mV Current : 0.61μA	=Analog Input Signal/ 16383(rounded the third decimal place)
I/O Points Occupied	4 IR(Input register)	
Accuracy	Within ±1% of full scale	
Conversion Time	Updated each scan	
Maximum absolute input signal	Voltage : ±15V ( max ) Current : ±30mA ( max )	It may cause the destruction to hardware if exceeds this value.
Input resistance	63.2KΩ ( Voltage input ) 、 250Ω ( Current Input )	

#### General specifications

Isolation	Transformer(Power) and photocouple(Signal)	
Indicator(s)	5V PWR LED	
Internal Power Consumption	5V 、 100mA	
External power supply	24V-15%/+20% 、 100mA	
Operating Temperature	0 ~ 60 ℃	
Storage Temperature	-20 ~ 80 ℃	
Dimensions	40(W)x90(H)x80(D) mm	

### 18.3.2 The Procedure of Using FBs-4A2D Analog Input/Output Module



### 18.3.3 Address Allocation of FBs-PLC Analog Inputs/Outputs

FBs-4A2D offers 4 AD points and 2 DA points. The AD points number starts from the one nearest to the PLC, the number in order is CH0~CH3 (module 1); CH4~CH7 (module 2); CH8~CH11 (module 3); etc, accumulates in serial; i.e. add 4 to each module, the total is 64 points (CH0~CH63) corresponding top the value IRs inside the PLC (R3840~R3903), respectively. In DA point numbering, from the one nearest to the PLC, the number runs from CH0 through to CH63 in serial, the total is 64 points corresponding top the value ORs inside the PLC (R3904~R3967), respectively. After connecting FBs-4A2D to the expansion interface on the PLC, FBs-PLC will automatically detect the number of AD/DA points. WinProladder will automatically detect and calculate the value IRs/ORs on the system after connecting to the PLC. Users may refer to the I/O Module Number Configuration provided by WinProladder in order to find out the exact I/O address of each expansion module to facilitate programming (see I/O Number Configuration, Section 12.6, WinProladder User's Manual for details).

#### Address allocation of FBs-4A2D(Analog output)

Numeric Output  Register ( OR )	Content of OR (CH0~CH63)															Output lable		
	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1		B0	
OR+0	*	*	B13	CH0 output value												B0	CH0	} FBs-4A2D
OR+1	*	*	CH1 output value														CH1	
OR+2	Depends on module type															CHX	}	
OR+3																CHX		
⋮	⋮		⋮												⋮	⋮	} Other modules	
⋮	⋮		⋮												⋮	⋮		
⋮	⋮		⋮												⋮	⋮		
⋮	⋮		⋮												⋮	⋮		
⋮	⋮		⋮												⋮	⋮		
R3966	Depends on module type															CHX	}	
R3967	Depends on module type															CHX		

\* \* ----- Unipolar code output (0~16383) , B14 、 B15 = 00  
 Bipolar code output (-8192~8191) , B14 、 B15 = B13


### Address allocation of FBs-4A2D(Analog input)

Numeric Input Register ( IR )	Content of IR (CH0~CH63)	Input lable
	B15 B14 B13 B12 B11 B10 B9 B8 B7 B6 B5 B4 B3 B2 B1 B0	
IR+0	14/12 bit ; 14-bit , B14~ B15= B13 ; 12-bit, B12~ B15= B11	CH0
IR+1	14/12 bit ; 14-bit , B14~ B15= B13 ; 12-bit, B12~ B15= B11	CH1
IR+2	„	CH2
IR+3	„	CH3
⋮	⋮	⋮
R3900	Depends on module type	CHX
R3901	Depends on module type	CHX
R3902	„	CHX
R3903	„	CHX

FBs-4A2D

Other modules

### 18.3.4 FBs-4A2D Hardware Description




※ FBs-4A2D contains 3 PCBs overlapping one another. The lowest one is the power supply unit (isolated power supply). The middle one is the I/O board (connectors are on this layer). The upper one is the control board (control/expansion I/O connections) as described below.:


Outlook of top view

- ① External power input terminal : Power supply of analogue circuit for this module, the voltage can be  $24\text{VDC} \pm 20\%$  and should be supplied with 4W of power at least.
- ② Protecting ground terminal : Connect to the shielding of signal cable.
- ③ Expansion input cable : It should be connected to the front expansion unit, or the expansion output of main unit.
- ④ Expansion output connector : Provides the connection for next expansion unit.
- ⑤ Power indicator : It indicates whether the power supply at analogue circuit and external input power source are normal.
- ⑥ AG Ground : No connection is needed in general; except when the common mode signal is too high. See examples overleaf for details.
- ⑦ 、 ⑧ : Output terminal of CH0~CH1.
- ⑨ 、 ⑫ : Input terminal of CH0~CH3.

#### 18.3.4.1 FBs-4A2D Hardware Jumper Setting



Pin Layout in Control Board (open top cover)



Pin Layout on I/O Board (Remove Control Board)



#### ● (Analog output)

##### 1. Output code format selection (JP1)

Users can select between unipolar and bipolar codes. The output range of unipolar codes and bipolar codes is 0~16383 and -8192~8191, respectively. The two extreme values of these formats correspond to the lowest and highest output signal values, respectively (see table below). In general, the output code format is selected according to the form













of output signals; i.e. unipolar codes for unipolar output signals; and bipolar codes for bipolar output signals. In doing so, their correlations will become more heuristics. Yet, as the format of output code on all channels is selected from JP1, it is the user's choice to select unipolar or bipolar codes if both are used on different channels. See diagram above for location of JP1 :

Output Code Format	JP1 Setting	Output Value Range	Corresponding Input Signals
Bipolar	JP1  (D/A)	-8192 ~ 8191	-10V ~ 10V (-20mA ~ 20mA) -5V ~ 5V (-10mA ~ 10mA)
Unipolar	JP1  (D/A)	0 ~ 16383	0V ~ 10V (0mA ~ 20mA) 0V ~ 5V (0mA ~ 10mA)

## 2. Output signal form setup (JPA&JPB)

Users can set the output signal form (voltage/current) of individual channels; except the polarity and amplitude which are common.

Signal Form	JPA (voltage/current) Setting	JPB (polarity/amplitude) Setting
0V ~ 10V		
-10V ~ 10V		
0V ~ 5V		
-5V ~ 5V		
0mA ~ 20mA		
-20mA ~ 20mA		
0mA ~ 10mA		
-10mA ~ 10mA		



## ● (Analog input)

### 1. Input code format selection (JP1)

Users can select between unipolar and bipolar codes. The input range of unipolar codes and bipolar codes is 0~16383 and -8192~8191, respectively. The two extreme values of these formats correspond to the lowest and highest input signal values, respectively (see table below). For example, if the input signal type is set to -10V~ +10V, the unipolar code corresponding to the input is 8192 and the bipolar code corresponding to the input is 0 for 0V input. If the input is 10V, the unipolar code corresponding to the input is 16383 and the bipolar code corresponding to the input is 8191. In general, the input code format is selected according to the form of input signals; i.e. unipolar codes for unipolar input













signals; and bipolar codes for bipolar input signals. In doing so, their correlations will become more heuristics. Unless it is

necessary to make a deviation conversion through FUN33; otherwise, do not select bipolar codes for unipolar input signals (see FUN33 description for details). The format of input codes of all channels is selected from JP1. See above diagram for the location of JP1 :



Input Code Format	JP1 Setting	Input Value Range	Corresponding Input Signals
Bipolar	JP1  (A/D)	-8192 ~ 8191	-10V ~ 10V (-20mA ~ 20mA) -5V ~ 5V (-10mA ~ 10mA)
Unipolar	JP1  (A/D)	0 ~ 16383	0V ~ 10V (0mA ~ 20mA) 0V ~ 5V (0mA ~ 10mA)

## 2. Input signal form setup (JP3&JP4)


Users can set the input signal form (voltage/current) of individual channels; except the polarity and amplitude which are common. The location of jumpers are tabulated below :

Signal Form	JP3 Setting	JP4 Setting
0 ~ 10V or 0 ~ 20mA	U  B 	 5V  10V
0 ~ 5V or 0 ~ 10mA		 5V  10V
-10 ~ +10V or -20 ~ +20mA	U  B 	 5V  10V
-5 ~ +5V or -10mA ~ +10mA		 5V  10V

## 3. Voltage or current setting (JP5~JP8)

Signal Type	JP5(CH0) ~ JP8(CH3) Setting
Voltage	
Current	

### 18.3.5 FBs-4A2D Input/Output Circuit Diagram



### 18.3.6 FBs-4A2D Input/Output Characteristics

Users can select the I/O ranges of FBs-4A2D from the jumpers described above, such as V/I, U/B (I/O codes), U/B (signal form), 5V/10V, etc. The I/O conversion characteristics of these settings are illustrated below. Users can adjust different I/O forms by coordinating the conversion curve with various V/I (voltage/current) I/O settings. See Section 18.3.4 for details of V/I settings.