

Chapter 11 The NC Positioning Control of FBs-PLC

People use ordinary motor to exercise positioning control in early stage; since the speed and precision demand was not so high then, it was enough to fulfill the demand. As the increasing of mechanical operation speed for the efficiency purpose, finished product quality standard, and precision demands are getting higher, the stopping position control of motor is no more what the ordinary motor is capable to do. The best solution for this problem is to adopt NC positioning controller which incorporate with stepping or servo motor to do the position control. In the past, the extremely high cost limited the prevailing of its usage; however, the technology advance and cost decreasing, which made the pricing affordable, had helped to increase the prevailing of usage gradually. To cope with this trend, the FBs-PLC integrated into its internal SoC chip the special NC positioning controller that is available on the market, therefore makes it free from the bothersome data transaction and linking procedure between PLC and special NC positioning controller. Furthermore, it greatly lowered the entire gadget cost hence provides the user the solution for a good bargain, high quality, simple, and convenient integrated NC positioning control with PLC.

11.1 The Methods of NC Positioning

The methods for controlling interface of PLC and stepping or servo driver are as follows:

- Giving command by way of digital I/O: Easy to use but less dexterity in application.
- Giving command by way of analogue output: Better dexterity in controlling reaction but it is with a higher cost and easy to be interfered by noise.
- Giving command by way of communication: There is no standard for communication protocol and it is confined in communication reaction thus constitutes a bottleneck for application.
- Giving command by way of high speed pulse: The cost is low and is easy to precisely controlled.

Of these methods, controlling stepping or servo driver with high speed pulse is more frequently used method. The main unit of PLC contains multi-axis high speed pulse output and hardware high speed counter, and it can provide easy using, designing for positioning program editing. Therefore it makes the related application even more convenient and comfortable.

Following two kinds are frequently used NC server system that constituted by PLC associates with servo drivers:

- **Semi closed loop control**

The PLC is responsible for sending high speed pulse command to servo driver. The motion detector installed on servo motor will forward directly to server driver, closed loop reaches only to server driver and servo motor. The superior point is that the control is simple and the precision is satisfactory (which is suitable for most of the applications). The defect is that it can't fully reflect the actual shift amount after the transmission element; furthermore, the element being consumed, become aging, or has defect will not be able to be compensated nor checked to verify.

- **Closed loop control**

The PLC is responsible for sending high speed pulse command to servo driver. In addition to that the shift detection signal installed on servo motor which will be forwarded directly to servo driver, the attached shifting detector installed after the transmission element can fully reflect the actual shift amount and forward it to the high speed counter that PLC contains. So as to make the control becomes more delicate, and help to avoid the defect of above mentioned semi closed loop.

11.2 Absolute Coordinate and Relative Coordinate

The designation of moving distance can be assigned by absolute location (absolute coordinate positioning), or assigned by relative distance (relative coordinate positioning). And the DRV instruction is used to drive motor.


While marking the moving distance with absolute coordinate,

if it is located at 100mm at the present, for moving to 300 mm, the positioning instruction is : DRV ABS, ,300, Ut
if it is located at 300mm at the present, for moving to 0mm, the positioning instruction is : DRV ABS, , 0, Ut.


While marking the moving distance with relative coordinate,

if it is located at 100mm at the present, for moving to 300 mm, the positioning instruction is : DRV ADR, +, 200, Ut.
if it is located at 300mm at the present, for moving to 0mm, the positioning instruction is : DRV ADR, -, 300, Ut.


- Absolute coordinate labeling



- Relative coordinate labeling



11.3 Procedures of Using FBs-PLC Positioning Control



11.4 Explanation for the Positioning Control Hardware of FBs-PLC

11.4.1 Structure of Output Circuit of HPSO

According to different main unit, it provides different frequency of output pulse, it includes 20KHz (Medium speed) of single ended transistor output model (FBs-xxMCT), and high speed differential output model (FBs-xxMNT) which can reach 920KHz (for single phase), two series of models.

High speed pulse output circuit share to use the Y0~Y7 exterior output of FBs-PLC. While it is not yet using the HPSO function (haven't configured the PSO function under configuration function), the Y0~Y7 exterior output of FBs-PLC is corresponding to the Y0~Y7 status of internal output relay. When the HPSO has been configured, the Y0~Y7 exterior output will switch directly to HPSO output circuit within SoC, which has no relation with Y0~Y7 relay inside PLC.


The following is the detailed signals list for respective axis output of main unit and the selectable output modes:

Axis No.	Exterior output	Output modes			
		U/D output	P/R output	A/B output	Single PLS output
PSO0	Y0 , Y1	Y0=U , Y1=D	Y0=P , Y1=R	Y0=A , Y1=B	Y0=PLS
PSO1	Y2 , Y3	Y2=U , Y3=D	Y2=P , Y3=R	Y2=A , Y3=B	Y2=PLS
PSO2	Y4 , Y5	Y4=U , Y5=D	Y4=P , Y5=R	Y4=A , Y5=B	Y4=PLS
PSO3	Y6 , Y7	Y6=U , Y7=D	Y6=P , Y7=R	Y6=A , Y7=B	Y6=PLS


11.4.2 Hardware Wiring Layout for FBs-PLC Positioning Control

Take the 0th axis (PSO0) of FBs-XXMCT, FBs-XXMAT, and FBs-XXMNR(T) main unit for example, it is illustrated with diagrams as follows; the others are the same.



A, FBs-XXMCT , FBs-XXMAT single ended output wiring layout.



* Please refer to Hardware manual H7-6 for the usage of speed-up resistor "R".




B、FBS-XXMNR(T) differential output wiring layout




(For line receiver input, it must make PLC connect to FG of driver to eliminate common mode voltage)

Configuration of HPSO with WinProladder

Click the “I/O Configuration” Item which in project windows :



When “Output Setup” windows appear, then you can configure the Output type :



11.5 The Explanation for the Position Control Function of FBs-PLC


The position control function of FBs-PLC incorporates the dedicated NC position controller, which is available in the market, into the PLC. This makes the PLC and NC controller be able to share the same data block without the demand of complicated works like data exchange and synchronized controlling between these two systems. And it can still use the usual NC positioning control instruction (e.g. SPD, DRV, etc.).

One main unit can control up to 4 axes of their position control, and can drive multi axis simultaneously. However, it provides point to point positioning and speed control, but also it provides the linear interpolation function. When the system is applying for more than 4 axes, it can also employ CPU LINK function of FBs-PLC to attain control over more positioning actions.

The NC position control instruction for FBs-XXMCT、FBs-XXMN main units are identical to each other. The difference is only on the different circuit output, as previously revealed. Hereby we assume that FBs-XXMCT main unit is used in the control of stepping motor or server with lower speed, and FBs-XXMN main unit is used in high speed servo motor control. Consequently, we illustrate only with the connecting diagram of FBs-XXMCT main unit that driving stepping motor and the diagram of FBs-XXMN main unit that driving servo motor. Of course we can also use FBs-XXMCT main unit to drive servo motor or use FBs-XXMN main unit to drive stepping motor instead, they can still work perfectly, as long as its circuit structure (single ended or differential) and frequency can match.

11.5.1 Interface of Stepping Motor

FBs-XXMCT main unit



- Stepping motor is designed to receive input pulse to attain to the control of desired angle or distance, therefore the turning angle and the input pulse count has a positive correlation ship, and the turning speed also depends on the input pulse frequency.

$$N \text{ (RPM)} = 60 \times f / n$$

N : Revolving speed of motor (RPM)

f : Pulse frequency (PLS/Sec)


n : Pulse counts for motor to turn for a revolution (PLS/ Rev).

$$n = 360 / \theta_s$$

θ_s : Angle (Deg)


Phase	Basic pulse angle	FULL		HALF	
		Pulse angle	Pulse counts for turning one revolution	Pulse angle	Pulse counts for turning one revolution
5 phase	0.36°	0.36°	1000	0.18°	2000
	0.72°	0.72°	500	0.36°	1000
4 phase	0.90°	0.90°	400	0.45°	800
2 phase	1.80°	1.80°	200	0.90°	400

11.5.2 Interface of Servo Motor



- * Except that the Y0~Y7 of above diagram are for dedicated purpose, Y8~Y11 and respective inputs can be adjusted for using according to demand.
- * The left over travel, right over travel limit switches for safety detection also need to be connected to PLC to assure proper operation.

11.5.3 Working Diagram Illustration for Servo Motor



- The Encoder of servo motor feedback the shifting detection signal to servo driver. The driver gets the pulse frequency, and pulse count of input signal (pulse command), as well as the frequency and pulse count of feedback signal processed with internal error counter and frequency to voltage conversion circuit, and acquired the pulse and turning speed deviations. Using these operations to control the servo motor, so as to obtain a high speed, precise speed and positional closed-loop processing system.
- The revolving speed of servo motor depends on the pulse frequency of input signal; the turning stroke of motor is determined by pulse count.
- Generally speaking, the final control error deviation of servo motor is ± 1 pulse.

11.6 Explanation of Function for NC Position Control Instruction

The NC position control of FBS-PLC has following four related instructions:

- FUN140 (HPSO) high speed pulse output instruction, which includes following 9 extension positioning instructions:

1. SPD	4. DRVZ	7. EXT	Used for positioning program coding and stored to SR operand area of FUN140
2. DRV	5. WAIT	8. GOTO	
3. DRVC	6. ACT	9. MEND	
- FUN141 (MPARA) positioning parameter setting instruction
- FUN142 (PSOFF) enforcing pulse output stop instruction.
- FUN143 (PSCNV) converting the current pulse value to displaying value instruction.
- FUN147 (MHSPO) multi high speed pulse output instruction, which includes following 7 extension positioning instructions:

1. SPD	4. WAIT	7. MEND	Used for positioning program coding and stored to SR operand area of FUN147
2. LIN	5. EXT		
3. LINE	6. GOTO		

The following function explanations are for the above mentioned 5 instructions:

FUN 140 HPSO	High Speed Pulse Output (Including the extended positioning instruction)	FUN 140 HPSO																									
	<p style="text-align: right;">Ps : The set number of Pulse Output (0~3)</p> <p style="text-align: center;"><u>Ladder symbol</u></p> <p>Execution control — EN — Ps : — ACT — Acting</p> <p>Pause — INC — SR : — ERR — Error</p> <p>Abort — ABT — WR : — DN — Done</p>	<p style="text-align: center;">0:Y0 & Y1 1:Y2 & Y3 2:Y4 & Y5 3:Y6 & Y7</p> <p>SR: Starting register for positioning program (example explanation)</p> <p>WR: Starting register for instruction operation (example explanation). It controls 7 registers, which the other program cannot repeat in using.</p>																									
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">Range</th> <th style="text-align: center;">HR</th> <th style="text-align: center;">DR</th> <th style="text-align: center;">ROR</th> <th style="text-align: center;">K</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Oper- and</td> <td style="text-align: center;">R0 R3839</td> <td style="text-align: center;">D0 D3999</td> <td style="text-align: center;">R5000 R8071</td> <td></td> </tr> <tr> <td style="text-align: center;">Ps</td> <td></td> <td></td> <td></td> <td style="text-align: center;">0~3</td> </tr> <tr> <td style="text-align: center;">SR</td> <td style="text-align: center;"><input type="radio"/></td> <td style="text-align: center;"><input type="radio"/></td> <td style="text-align: center;"><input type="radio"/></td> <td></td> </tr> <tr> <td style="text-align: center;">WR</td> <td style="text-align: center;"><input type="radio"/></td> <td style="text-align: center;"><input type="radio"/></td> <td style="text-align: center;"><input checked="" type="radio"/>*</td> <td></td> </tr> </tbody> </table>			Range	HR	DR	ROR	K	Oper- and	R0 R3839	D0 D3999	R5000 R8071		Ps				0~3	SR	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		WR	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/> *	
Range	HR	DR	ROR	K																							
Oper- and	R0 R3839	D0 D3999	R5000 R8071																								
Ps				0~3																							
SR	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																								
WR	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/> *																								

Instruction Explanation

1. The NC positioning program of FUN140 (HPSO) instruction is a program written and edited with text programming. We named every position point as a step (which includes output frequency, traveling distance, and transfer conditions). For one FUN140, it can be arranged with 250 steps of positioning points at the most, with every step of positioning point controlled by 9 registers.
2. The best benefit to store the positioning program into the registers is that in the case of association with MMI (Man Machine Interface) to operate settings, it may save and reload the positioning program via MMI when replacing the molds.
3. When execution control "EN"=1, if the other FUN140 instructions to control Ps0 ~ 3 are not active (corresponding status of Ps0=M1992, Ps1=M1993, Ps2=M1994, and Ps3=M1995 will be ON), it will start to execute from the next step of positioning point (when goes to the last step, it will be restarted from the first step to perform); if Ps0 ~ 3 is controlled by other FUN140 instruction (corresponding status of Ps0=M1992, Ps1=M1993, Ps2=M1994, and Ps3=M1995 would be OFF), this instruction will acquire the pulse output right of positioning control once the controlling FUN140 has released the control right.
4. When execution control input "EN" =0, it stops the pulse output immediately.
5. When output pause "PAU" =1 and execution control "EN" was 1 beforehand, it will pause the pulse output. When output pause "PAU" =0 and execution control is still 1, it will continue the unfinished pulse output.
6. When output abort "ABT"=1, it stops pulse output immediately. (When the execution control input "EN" becomes 1 next time, it will restart from the first step of positioning point to execute.)
7. While the pulse is in output transmitting, the output indication "ACT" is ON.
8. When there is execution error, the output indication "ERR" will be ON.
(The error code is stored in the error code register.)
9. When each step of positioning point is complete, the output indication "DN" will be ON.

NC Positioning Control Instruction

FUN 140 HPSO	High Speed Pulse Output (Including the extended positioning instruction)	FUN 140 HPSO
-----------------	---	-----------------

*** The working mode of Pulse Output must be set (without setting, Y0~Y7 will be treated as general output) to be one of U/D, P/R, or A/B mode, thus the Pulse Output may have a regular output.

U/D Mode : Y0 (Y2, Y4, Y6), it sends out upward counting pulse.
Y1 (Y3, Y5, Y7), it sends out downward counting pulse.

P/R Mode : Y0 (Y2, Y4, Y6), it sends the pulse out.
Y1 (Y3, Y5, Y7), it sends out the directional signal;
ON=upward counting, OFF= downward counting.

A/B Mode : Y0 (Y2, Y4, Y6), it sends out the phase A pulse.
Y1 (Y3, Y5, Y7), it sends out the phase B pulse.

- The output polarity for Pulse Output can select to be Normal ON or Normal OFF.

[The interfaces for positioning control]

M1991	ON : stop or pause FUN140, slow down and stop pulse output.
	OFF : stop or pause FUN140, stop pulse output immediately.
M1992	ON : Ps0 Ready
	OFF : Ps0 is in action
M1993	ON : Ps1 Ready
	OFF : Ps1 is in action
M1994	ON : Ps2 Ready
	OFF : Ps2 is in action
M1995	ON : Ps3 Ready
	OFF : Ps3 is in action
M1996	ON : Ps0 has finished the last step
M1997	ON : Ps1 has finished the last step
M1998	ON : Ps2 has finished the last step
M1999	ON : Ps3 has finished the last step

M2000 : ON, multi axes acting simultaneously (At the same scan, when execution control "EN"= 1 of FUN140 instructions which control Ps0~3, their pulses output will be sent at the same time without any time lag).

: OFF, as the FUN140 for Ps0~3 starts, corresponding axis pulse output will be sent immediately; since the ladder program is executed in sequence, therefore even the FUN140 for Ps0~3 started at the same scan, there must be some time lag between them.

Ps No.	Current output frequency	Current pulse position	The remaining pulse counts to be transmitted	Error code
Ps0	DR4080	DR4088	DR4072	R4060
Ps1	DR4082	DR4090	DR4074	R4061
Ps2	DR4084	DR4092	DR4076	R4062
Ps3	DR4086	DR4094	DR4078	R4063

* R4056 : When the value of low byte=5AH, it can be dynamically changed for its output frequency during the high speed pulse output transmitting at any time.

When the value of low byte is not 5AH, it can not be dynamically changed for its output frequency during the high speed pulse output transmitting.

The default value of R4056 is 0

FUN 140 HPSO	High Speed Pulse Output (Including the extended positioning instruction)	FUN 140 HPSO
-----------------	--	-----------------

R4064 : The step number (positioning point) which has been completed of Ps0.


R4065 : The step number (positioning point) which has been completed of Ps1.

R4066 : The step number (positioning point) which has been completed of Ps2.

R4067 : The step number (positioning point) which has been completed of Ps3.

- Format of positioning program:

SR: Starting register of registers block which reserved to store positioning program, explained as follows:



NC Positioning Control Instruction


FUN 140 HPSO	High Speed Pulse Output (Including the extended positioning instruction)	FUN 140 HPSO														
● Explanation for working register of instruction operation:																
WR is the starting register.																
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="width: 10%;">WR+0</td><td>Being executed or stopped step</td></tr> <tr><td>WR+1</td><td>Working flag</td></tr> <tr><td>WR+2</td><td>Controlled by system</td></tr> <tr><td>WR+3</td><td>Controlled by system</td></tr> <tr><td>WR+4</td><td>Controlled by system</td></tr> <tr><td>WR+5</td><td>Controlled by system</td></tr> <tr><td>WR+6</td><td>Controlled by system</td></tr> </table>			WR+0	Being executed or stopped step	WR+1	Working flag	WR+2	Controlled by system	WR+3	Controlled by system	WR+4	Controlled by system	WR+5	Controlled by system	WR+6	Controlled by system
WR+0	Being executed or stopped step															
WR+1	Working flag															
WR+2	Controlled by system															
WR+3	Controlled by system															
WR+4	Controlled by system															
WR+5	Controlled by system															
WR+6	Controlled by system															
<p>WR+0 : If this instruction is in execution, the content of this register represents the step (1~N) being performed. if this instruction is not in execution, the content of this register represents the step where it stopped at present</p> <p>When execution control "EN" =1, it will perform the next step, i.e. the current step plus 1 (if the current step is at the last step, it will restart to perform from the first step).</p> <p>Before starting the execution control "EN" =1, the user can renew the content of WR+0 to determine starting from which step to perform (when the content of WR+0 =0, and execution control "EN" =1, it represents that the execution starts from the first step).</p>																
<p>WR+1 : B0~B7, total steps</p> <p>B8 = ON, output paused</p> <p>B9 = ON, waiting for transfer condition</p> <p>B10 = ON, endless output (the stroke operand of DRV command is set to be 0)</p> <p>B12 = ON, pulse output transmitting (the status of output indicator "ACT")</p> <p>B13 = ON, instruction execution error (the status of output indicator "ERR")</p> <p>B14 = ON, finished being executed step (the status of output indicator "DN")</p> <p>*** When step which has been completed, the output indication "DN" will turn ON and keep such status if suspending ; the user may turn OFF the status of "DN" by using the rising edge of output coil controlled by "DN" to clear the content of WR+1 register to be 0, and it can be attained.</p>																

FUN 140 HPSO	High Speed Pulse Output (Including the extended positioning instruction)	FUN 140 HPSO
<p>Error indication Error code</p> <p>R4060 (Ps0) 0 : Error free R4061 (Ps1) 1 : Parameter 0 error R4062 (Ps2) 2 : Parameter 1 error R4063 (Ps3) 3 : Parameter 2 error 4 : Parameter 3 error 5 : Parameter 4 error 6 : Parameter 5 error 7 : Parameter 6 error 8 : Parameter 7 error 9 : Parameter 8 error 10 : Parameter 9 error 13 : Parameter 12 error 15 : Parameter 14 error 30 : Error of variable address for speed setting 31 : Error of setting value for speed setting 32 : Error of variable address for stroke setting 33 : Error of setting value for stroke setting 34 : Illegal positioning program 35 : Length error of total step 36 : Over the maximum step 37 : Limited frequency error 38 : Initiate/stop frequency error 39 : Over range of compensation value for movement 40 : Over range of moving stroke 41 : ABS positioning is not allowed within DRVC commands 42 : DRVC instruction not allow ABS addressing 50 : Illegal operation mode of DRVZ 51 : Illegal DOG input number 52 : Illegal PG0 input number 53 : Illegal CLR output number 60 : Illegal linear interpolation command</p>		<p>The possible error codes for FUN141 execution</p> <p>The possible error codes for FUN140 execution</p>

Note : The content of error indication register will keep the latest error code. Making sure that no more error to happen, you can clear the content of error indication register to be 0; as long as the content maintains at 0, it represents that there's no error happened.

Editing Servo Program Table with WinProladder

Click the "Servo Program Table" Item which in project windows :




NC Positioning Control Instruction


FUN 140
HPSO

High Speed Pulse Output
(Including the extended positioning instruction)

FUN 140
HPSO



- Table Type : It will be fixed to " Servo Program Table ".
- Table Name : For modify or debug, you can give a convenient name.
- Table Starting address : Enter the address which Starting register of Servo Program Table.



FUN 140 HPSO	High Speed Pulse Output (Including the extended positioning instruction)	FUN 140 HPSO
-----------------	---	-----------------

- For easy programming and trouble shooting, the WinProladder provides the text editing environment to edit the motion program(servo program table) for FUN140 execution; Key in the complete FUN140 instruction first and then move the cursor to the position of it, pressing the hot key "Z", then comes the text editing environment. The user can create the new motion program or display the existed program under this friendly user interface operation.
- Extended positioning instructions are listed as follows:

Instruction	Operand	Explanation
SPD	XXXXXX or Rxxxx or Dxxxx	<ul style="list-style-type: none"> Moving speed in frequency or velocity (FUN141 Parameter_0=0 represents velocity; Parameter_0=1 or 2 for frequency; the system default is frequency). The operand can be input directly with constant or variable (Rxxxx, Dxxxx); when the operand is variable, it needs 2 registers, e.g. D10 represents D10 (Low Word) and D11 (High Word), which is the setting of frequency or velocity. When selecting to use the velocity setting, the system will automatically convert the velocity setting to corresponding output frequency. Output frequency range: $1 \leq \text{output frequency} \leq 921600 \text{ Hz}$. <p>*** When the output frequency is 0, this instruction will wait until the setting value isn't 0 to execute the positioning pulse output.</p>
DRV	ADR , + , XXXXXXXX , Ut ADR , + , XXXXXXXX , Ps ADR , - , XXXXXXXX , Ut ADR , - , XXXXXXXX , Ps ADR , , XXXXXXXX , Ut ADR , , -XXXXXXX , Ut ADR , , XXXXXXXX , Ps ADR , , -XXXXXXX , Ps ADR , + , Rxxxx , Ut ADR , + , Rxxxx , Ps ADR , - , Rxxxx , Ut ADR , - , Rxxxx , Ps ADR , , Rxxxx , Ut ADR , , Rxxxx , Ps ADR , + , Dxxxx , Ut ADR , + , Dxxxx , Ps ADR , - , Dxxxx , Ut ADR , - , Dxxxx , Ps ADR , , Dxxxx , Ut ADR , , Dxxxx , Ps ABS , , XXXXXXXX , Ut ABS , , -XXXXXXX , Ut ABS , , XXXXXXXX , Ps ABS , , -XXXXXXX , Ps ABS , , Rxxxx , Ut ABS , , Rxxxx , Ps ABS , , Dxxxx , Ut ABS , , Dxxxx , Ps	<ul style="list-style-type: none"> Moving stroke setting in Ps or mm,Deg,Inch (When FUN141 Parameter_0=1, the setting stroke in Ut is Ps; Parameter_0=0 or 2, the setting stroke in Ut is mm, Deg, Inch; the system default for Ut is Ps). When 4_th operand of DRV is Ut (not Ps) , according to parameter setting of 1, 2, 3 of FUN141, the system will convert the corresponding pulse count to output. There are 4 operands to construct DRV instruction as follows: <p>1_st operand: coordinate selection. ADR or ABS: ADR, relative distance movement ABS, absolute position movement</p> <p>2_nd operand: revolving direction selection (Valid for ADR only). '+' , forward or clockwise '-' , backward or counterclockwise ' ' , direction is determined by the setting value (positive value: forward; negative value: backward)</p> <p>3_rd operand: moving stroke setting XXXXXX: It can directly input with constant or variable (Rxxxx, Dxxxx); it needs 2 registers when adopting the variable, e.g. R0 represents R0 (Low Word) and R1 (High Word) as the setting of moving stroke. or -XXXXXX or Rxxxx or Dxxxx</p> <p>*** When the setting of moving stroke is 0 and 1_st operand is ADR, it represents to revolve endless.</p> <p>Stroke setting range: $-99999999 \leq \text{stroke setting} \leq 99999999$</p> <p>4_th operand: resolution of stroke setting Ut or Ps:for Ut, the resolution is one unit; (it is determined by parameter 0, 3 of FUN141); for Ps, the enforced resolution is one pulse.</p>


NC Positioning Control Instruction

FUN 140 HPSO	High Speed Pulse Output (Including the extended positioning instruction)	FUN 140 HPSO
-----------------	---	-----------------

Instruction	Operand	Explanation
DRVC	ADR , + , XXXXXXXX , Ut or or or or ABS , - , Rxxxx , Ps or Dxxxx	<p>The usage of DRVC and the operand explanation is the same as DRV's instruction.</p> <p>*** DRVC is used to do successive speed changing control (8 speeds at the most).</p> <p>*** Of the successive speed changing control, only the first DRVC instruction can use the absolute value coordinate for positioning.</p> <p>*** The revolution direction of DRVC can only be decided by '+' or '-'.</p> <p>*** The revolution direction only determined by the first DRVC of successive DRVC instructions; i.e. the successive speed changing control can only be the same direction.</p> <p>For example: successive 3 speed changing control</p> <pre> 001 SPD 10000 * Pulse frequency = 10KHz. DRVC ADR , + , 20000 , Ut * Forward 20000 units. GOTO NEXT 002 SPD 50000 * Pulse frequency = 50 KHz DRVC ADR , + , 60000 , Ut * Forward 60000 units. GOTO NEXT 003 SPD 3000 * Pulse frequency = 3KHz. DRV ADR , + , 5000 , Ut * Forward 5000 units. WAIT X0 * Wait until X0 ON to restart from the first step to execute. </pre> <p>Note: The number of DRVC instructions must be the number of successive speeds deducted by 1, i.e. the successive speed changing control must be ended with the DRV instruction.</p> <ul style="list-style-type: none"> • The above mentioned example is for successive 3 speeds changing control, which used 2 DRVC instructions and the third must use DRV instruction. • Diagram illustration for the above mentioned example:

Note: Comparison explanation between the relative coordinate positioning (ADR) and the absolute coordinate positioning (ABS)

To move from position 30000 to -10000, the coding for programming is:



To move from position -10000 to 10000, the coding for programming is:

DRV ADR,+,20000,Ut or DRV ABS, ,10000,Ut

FUN 140 HPSO	High Speed Pulse Output (Including the extended positioning instruction)	FUN 140 HPSO
-----------------	---	-----------------

Instruction	Operand	Explanation
WAIT	Time, XXXXX or Rxxxx or Dxxxx or X0~X255 or Y0~Y255 or M0~M1911 or S0~S999	<ul style="list-style-type: none"> When pulse output is complete, performing the wait instruction for going to the next step. There are 5 kind of operands that explained as follows: <p>Time: The waiting time (the unit is 0.01 second), it can be directly input with constant or variable (Rxxxx or Dxxxx); when it is time up, performs the step that assigned by GOTO.</p> <p>X0~X255: Waiting until the input status is ON, it performs the step that assigned by GOTO.</p> <p>Y0~Y255: Waiting until the output status is ON, it performs the step that assigned by GOTO.</p> <p>M0~M1911: Waiting until the internal relay is ON, it performs the step that assigned by GOTO.</p> <p>S0~S999: Waiting until the step relay is ON, it performs the step that assigned by GOTO.</p>
ACT	Time · XXXXX or Rxxxx or Dxxxx	<ul style="list-style-type: none"> After the time to output pulses described by operand of ACT, it performs immediately the step that assigned by GOTO, i.e. after the pulse output for a certain time, it performs the next step immediately. The action time (the unit is 0.01 second) can be directly input with constant or variable (Rxxxx or Dxxxx); when the action time is up, it performs the step assigned by GOTO.
EXT	X0~X255 or Y0~Y255 or M0~M1911 or S0~S999	<ul style="list-style-type: none"> External trigger instruction; when it is in pulse output (the number of pulses sending is not complete yet), if the status of external trigger is ON, it will perform the step assigned by GOTO immediately. If the status of external trigger is still OFF when the pulse output has been complete, it is the same as WAIT instruction; waiting the trigger signal ON, then perform the step assigned by GOTO.
GOTO	NEXT or 1~N or Rxxxx or Dxxxx	<ul style="list-style-type: none"> When matching the transfer condition of WAIT, ACT, EXT instruction, by using GOTO instruction to describe the step to be executed. <p>NEXT: It represents to perform the next step.</p> <p>1~N: To perform the described number of step.</p> <p>Rxxxx: The step to be performed is stored in register Rxxxx.</p> <p>Dxxxx: The step to be performed is stored in register Dxxxx.</p>
MEND		The end of the positioning program.


NC Positioning Control Instruction

FUN 140 HPSO	High Speed Pulse Output (Including the extended positioning instruction)	FUN 140 HPSO
<ul style="list-style-type: none">● The coding for positioning programming :		
<p>First, it must complete the FUN140 instruction before the editing of positioning program, and assigned in FUN140 instruction the starting register of registers block to store positioning program. While editing the positioning program, it will store the newly edited positioning program to the assigned registers block; for every one positioning point (called as one step) edited, it is controlled by 9 registers. If there are N positioning points, it will be controlled by $N \times 9 + 2$ registers in total.</p>		
<p>Note: The registers storing the positioning program can not be repeated in using!</p>		
<ul style="list-style-type: none">● Format and example for the positioning program 1:		
<pre>001 SPD 5000 ; Pulse frequency = 5KHz. DRV ADR,+,10000,Ut ; Moving forward 10000 units. WAIT Time,100 ; Wait for 1 second. GOTO NEXT ; Perform the next step. 002 SPD R1000 ; Pulse frequency is stored in DR1000 (R1001 and R1000). DRV ADR,+,D100,Ut ; Moving forward, the stroke is stored in DD100 (D101 and D100). WAIT Time,R500 ; The waiting time is stored in R500. GOTO NEXT ; To perform the next step. 003 SPD R1002 ; Pulse frequency is stored in DR1002 (R1003 and R1002). DRV ADR,-,D102,Ut ; Moving backward, the stroke is stored in DD102 (D103 and D102). EXT X0 ; When external trigger X0 (slow down point) ON, it performs the next GOTO NEXT ; step immediately. 004 SPD 2000 ; Pulse frequency = 2KHz. DRV ADR,-,R4072,Ps ; Keep outputting the remain (stored in DR4072). WAIT X1 ; Wait until X1 ON, GOTO 1 ; Perform the first step.</pre>		

Program example: Jog forward

As the jog forward button has been pressed for less than 0.5 second (changeable), it sends out only one (changeable) pulse;


As the jog forward button has been pressed for more than 0.5 second (changeable), it continuously sends pulses out (the frequency is 10KHz, changeable), until the release of the jog forward button to stop the pulse transmitting; or it may be designed to send N pulses out at the most.



Program example: Jog Backward

As the jog backward button has been pressed for less than 0.5 second (changeable) it sends out only one (changeable) pulse;

As the jog backward button has been pressed for more than 0.5 second (changeable), it continuously sends pulses out (the frequency is 10KHz, changeable), until the release of the jog backward button to stop the pulse transmitting; or it may be designed to send N pulses out at the most.





NC Positioning Instruction

FUN 141 MPARA	Instruction of Parameter Setting for Positioning Program	FUN 141 MPARA																																																																										
<p>Execution control— EN</p> <p>141.MPARA</p> <p>Ps : R0 / R3839</p> <p>SR : D3999</p> <p>ERR —</p>	<p><u>Ladder symbol</u></p> <p>Ps: The set number of Pulse Output (0~3).</p> <p>SR: Starting register for parameter table, it has totally 18 parameters which controlled by 24 registers.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <th rowspan="2">Operand</th> <th>Range</th> <th>HR</th> <th>DR</th> <th>ROR</th> <th>K</th> </tr> <tr> <td>R0 R3839</td> <td>D0 D3999</td> <td>R5000 R8071</td> <td></td> <td></td> </tr> <tr> <td>Ps</td> <td></td> <td></td> <td></td> <td>0~3</td> </tr> <tr> <td>SR</td> <td>○</td> <td>○</td> <td>○</td> <td></td> </tr> </table>	Operand	Range	HR	DR	ROR	K	R0 R3839	D0 D3999	R5000 R8071			Ps				0~3	SR	○	○	○																																																							
Operand	Range		HR	DR	ROR	K																																																																						
	R0 R3839	D0 D3999	R5000 R8071																																																																									
Ps				0~3																																																																								
SR	○	○	○																																																																									
<p>Instruction explanation</p> <ol style="list-style-type: none"> This instruction is not necessary if the system default for parameter value is matching what users need. However, if it needs to open the parameter value to do dynamic modification, this instruction is required. This instruction incorporates with FUN140 for positioning control purpose, each axis can have one FUN140 instruction only. Whether the execution control input “EN” = 0 or 1, anyway, this instruction will be performed. When there is error in parameter value, the output indication “ERR” will be ON, and the error code is appeared in the error code register. <p>Explanation for the parameter table:</p> <p>SR =Starting register of parameter table, suppose it is R2000.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">R2000</td> <td style="width: 30%;">0~2</td> <td>Parameter 0</td> <td>System default =1</td> </tr> <tr> <td>R2001</td> <td>1~65535 Ps/Rev</td> <td>Parameter 1</td> <td>System default =2000</td> </tr> <tr> <td rowspan="3">DR2002</td> <td>1~999999 μM/Rev</td> <td rowspan="3">Parameter 2</td> <td rowspan="3">System default =2000</td> </tr> <tr> <td>1~999999 mDeg/Rev</td> </tr> <tr> <td>1~999999 \times 0.1 mInch/Rev</td> </tr> <tr> <td>R2004</td> <td>0~3</td> <td>Parameter 3</td> <td>System default =2</td> </tr> <tr> <td rowspan="2">DR2005</td> <td>1~921600 Ps/Sec</td> <td rowspan="2">Parameter 4</td> <td rowspan="2">System default =460000</td> </tr> <tr> <td>1~153000</td> </tr> <tr> <td rowspan="2">DR2007</td> <td>0~921600 Ps/Sec</td> <td rowspan="2">Parameter 5</td> <td rowspan="2">System default =141</td> </tr> <tr> <td>1~153000</td> </tr> <tr> <td>R2009</td> <td>1~65535 Ps/Sec</td> <td>Parameter 6</td> <td>System default =1000</td> </tr> <tr> <td>R2010</td> <td>0~32767</td> <td>Parameter 7</td> <td>System default =0</td> </tr> <tr> <td>R2011</td> <td>0~30000</td> <td>Parameter 8</td> <td>System default =5000</td> </tr> <tr> <td>R2012</td> <td>0~1</td> <td>Parameter 9</td> <td>System default =0100H</td> </tr> <tr> <td>R2013</td> <td>-32768~32767</td> <td>Parameter 10</td> <td>System default =0</td> </tr> <tr> <td>R2014</td> <td>-32768~32767</td> <td>Parameter 11</td> <td>System default =0</td> </tr> <tr> <td>R2015</td> <td>0~30000</td> <td>Parameter 12</td> <td>System default =0</td> </tr> <tr> <td>R2016</td> <td>0~30000</td> <td>Parameter 13</td> <td>System default =500</td> </tr> <tr> <td>DR2017</td> <td>0~1999999</td> <td>Parameter 14</td> <td>System default =0</td> </tr> <tr> <td>DR2019</td> <td>00H~FFH</td> <td>Parameter 15</td> <td>System default =FFFFFFFH</td> </tr> <tr> <td>DR2021</td> <td>-999999~999999</td> <td>Parameter 16</td> <td>System default =0</td> </tr> <tr> <td>R2023</td> <td>0~255</td> <td>Parameter 17</td> <td>System default =1</td> </tr> </table>	R2000	0~2	Parameter 0	System default =1	R2001	1~65535 Ps/Rev	Parameter 1	System default =2000	DR2002	1~999999 μ M/Rev	Parameter 2	System default =2000	1~999999 mDeg/Rev	1~999999 \times 0.1 mInch/Rev	R2004	0~3	Parameter 3	System default =2	DR2005	1~921600 Ps/Sec	Parameter 4	System default =460000	1~153000	DR2007	0~921600 Ps/Sec	Parameter 5	System default =141	1~153000	R2009	1~65535 Ps/Sec	Parameter 6	System default =1000	R2010	0~32767	Parameter 7	System default =0	R2011	0~30000	Parameter 8	System default =5000	R2012	0~1	Parameter 9	System default =0100H	R2013	-32768~32767	Parameter 10	System default =0	R2014	-32768~32767	Parameter 11	System default =0	R2015	0~30000	Parameter 12	System default =0	R2016	0~30000	Parameter 13	System default =500	DR2017	0~1999999	Parameter 14	System default =0	DR2019	00H~FFH	Parameter 15	System default =FFFFFFFH	DR2021	-999999~999999	Parameter 16	System default =0	R2023	0~255	Parameter 17	System default =1
R2000	0~2	Parameter 0	System default =1																																																																									
R2001	1~65535 Ps/Rev	Parameter 1	System default =2000																																																																									
DR2002	1~999999 μ M/Rev	Parameter 2	System default =2000																																																																									
	1~999999 mDeg/Rev																																																																											
	1~999999 \times 0.1 mInch/Rev																																																																											
R2004	0~3	Parameter 3	System default =2																																																																									
DR2005	1~921600 Ps/Sec	Parameter 4	System default =460000																																																																									
	1~153000																																																																											
DR2007	0~921600 Ps/Sec	Parameter 5	System default =141																																																																									
	1~153000																																																																											
R2009	1~65535 Ps/Sec	Parameter 6	System default =1000																																																																									
R2010	0~32767	Parameter 7	System default =0																																																																									
R2011	0~30000	Parameter 8	System default =5000																																																																									
R2012	0~1	Parameter 9	System default =0100H																																																																									
R2013	-32768~32767	Parameter 10	System default =0																																																																									
R2014	-32768~32767	Parameter 11	System default =0																																																																									
R2015	0~30000	Parameter 12	System default =0																																																																									
R2016	0~30000	Parameter 13	System default =500																																																																									
DR2017	0~1999999	Parameter 14	System default =0																																																																									
DR2019	00H~FFH	Parameter 15	System default =FFFFFFFH																																																																									
DR2021	-999999~999999	Parameter 16	System default =0																																																																									
R2023	0~255	Parameter 17	System default =1																																																																									

FUN 141 MPARA	Instruction of Parameter Setting for Positioning Program	FUN 141 MPARA
------------------	--	------------------

Editing Servo Parameter Table with WinProladder

Click the "Servo Parameter Table" Item which in project windows :



- Table Type : It will be fixed to " Servo Parameter Table ".
- Table Name : For modify or debug, you can give a convenient name.
- Table Starting address : Enter the address which Starting register of Servo Parameter Table.

NC Positioning Instruction

FUN 141 MPARA	Instruction of Parameter Setting for Positioning Program	FUN 141 MPARA																																													
Servo Parameter Table - [Servo Parameter Table]																																															
 Calculator(C)  Setup(S) <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">0.Unit :</td> <td style="width: 20%; text-align: center;">1:Pulse</td> <td style="width: 30%;">7.Backlash Compensation :</td> <td style="width: 20%; text-align: center;">0</td> <td style="width: 10%;">Ps</td> </tr> <tr> <td>1.Pulse/Rev.(16Bit):</td> <td style="text-align: center;">2000</td> <td>8.Acc./Dec. Time :</td> <td style="text-align: center;">5000</td> <td>mS</td> </tr> <tr> <td>2.Distance/Rev. :</td> <td style="text-align: center;">2000</td> <td>9.Direction Control :</td> <td style="text-align: center;">0:Up</td> <td>▼</td> </tr> <tr> <td>3.Min. Unit :</td> <td style="text-align: center;">2</td> <td>10.+ Movement Compensation :</td> <td style="text-align: center;">0</td> <td>Ps</td> </tr> <tr> <td>4.Max. Speed :</td> <td style="text-align: center;">512000</td> <td>11.- Movement Compensation :</td> <td style="text-align: center;">0</td> <td>Ps</td> </tr> <tr> <td>5.Start/End Speed :</td> <td style="text-align: center;">141</td> <td>12.Dec. Time :</td> <td style="text-align: center;">0</td> <td>mS</td> </tr> <tr> <td></td> <td></td> <td>14.Pulse/Rev.(32Bit):</td> <td style="text-align: center;">0</td> <td></td> </tr> <tr> <td colspan="2">Allow: 3072 words(Auto)</td><td>Used: 24 words</td><td colspan="2">Position: R5000-R5023</td></tr> <tr> <td colspan="2" style="text-align: center; padding-top: 10px;"> <input type="button" value="Reset To Default"/> </td><td style="text-align: center;"> <input checked="" type="button" value="OK"/> </td><td colspan="2" style="text-align: center;"> <input type="button" value="Cancel"/> </td></tr> </table>			0.Unit :	1:Pulse	7.Backlash Compensation :	0	Ps	1.Pulse/Rev.(16Bit):	2000	8.Acc./Dec. Time :	5000	mS	2.Distance/Rev. :	2000	9.Direction Control :	0:Up	▼	3.Min. Unit :	2	10.+ Movement Compensation :	0	Ps	4.Max. Speed :	512000	11.- Movement Compensation :	0	Ps	5.Start/End Speed :	141	12.Dec. Time :	0	mS			14.Pulse/Rev.(32Bit):	0		Allow: 3072 words(Auto)		Used: 24 words	Position: R5000-R5023		<input type="button" value="Reset To Default"/>		<input checked="" type="button" value="OK"/>	<input type="button" value="Cancel"/>	
0.Unit :	1:Pulse	7.Backlash Compensation :	0	Ps																																											
1.Pulse/Rev.(16Bit):	2000	8.Acc./Dec. Time :	5000	mS																																											
2.Distance/Rev. :	2000	9.Direction Control :	0:Up	▼																																											
3.Min. Unit :	2	10.+ Movement Compensation :	0	Ps																																											
4.Max. Speed :	512000	11.- Movement Compensation :	0	Ps																																											
5.Start/End Speed :	141	12.Dec. Time :	0	mS																																											
		14.Pulse/Rev.(32Bit):	0																																												
Allow: 3072 words(Auto)		Used: 24 words	Position: R5000-R5023																																												
<input type="button" value="Reset To Default"/>		<input checked="" type="button" value="OK"/>	<input type="button" value="Cancel"/>																																												

Explanation for the parameter:

- Parameter 0: The setting of unit, its default is 1.
 - When the setting value is 0, the moving stroke and speed setting in the positioning program will all be assigned with the unit of mm, Deg, Inch, so called machine unit.
 - When the setting value is 1, the moving stroke and speed setting in the positioning program will all be assigned with the unit of Pulse, so called motor unit.
 - When the setting value is 2, the moving stroke setting in the positioning program will all be assigned with the unit of mm, Deg, Inch, and the speed setting will all be assigned with the unit of Pulse/Sec, which is called as compound unit.

Parameter 0, unit setting	“0” machine unit	“1” motor unit	“2” compound unit
Parameter 1, 2	Must be set	No need to set	Must be set
Parameter 3, 7, 10, 11	mm , Deg , Inch	Ps	mm , Deg , Inch
Parameter 4,5,6,15,16	Cm/Min , Deg/Min , Inch/Min	Ps/Sec	Ps/Sec

- Parameter 1: Pulse count/1-revolution, its default is 2000, i.e. 2000 Ps/Rev.
 - The pulse counts needed to turn the motor for one revolution
 $A = 1 \sim 65535$ (for value greater than 32767, it is set with unsigned decimal) Ps/Rev
 - When Parameter 14 = 0, Parameter 1 is the setting for Pulse /Rev
 - When Parameter 14 ≠ 0, Parameter 14 is the setting for Pulse/Rev

- Parameter 2: Movement/1 revolution, its default is 2000, i.e. 2000 Ps/Rev.
 - The movement while motor turning for one revolution.
 $B = 1 \sim 999999 \mu\text{M}/\text{Rev}$
 $1 \sim 999999 \text{ mDeg}/\text{Rev}$
 $1 \sim 999999 \times 0.1 \text{ mlInch}/\text{Rev}$

FUN 141 MPARA	Instruction of Parameter Setting for Positioning Program			FUN 141 MPARA
● Parameter 3: The resolution of moving stroke setting, its default is 2.				
Parameter 0	Set value=0, machine unit; Set value=2, compound unit;			Set value=1 motor unit (Ps)
Parameter 3	mm	Deg	Inch	
Set value =0	$\times 1$	$\times 1$	$\times 0.1$	$\times 1000$
Set value =1	$\times 0.1$	$\times 0.1$	$\times 0.01$	$\times 100$
Set value =2	$\times 0.01$	$\times 0.01$	$\times 0.001$	$\times 10$
Set value =3	$\times 0.001$	$\times 0.001$	$\times 0.0001$	$\times 1$

- Parameter 4: The limited speed setting, its default is 460000, i.e. 460000 Ps/Sec.
 - Motor and compound unit: 1~921600 Ps/Sec.
 - Machine unit: 1~153000 (cm/Min, $\times 10$ Deg/Min, Inch/Min).

However, the limited frequency can't be greater than 921600 Ps/Sec.
 $f_{max} = (V_{max} \times 1000 \times A) / (6 \times B) \leq 921600 \text{ Ps/Sec}$
 $f_{min} \geq 1 \text{ Ps/Sec}$

Note: A = Parameter 1, B = Parameter 2.

- Parameter 5: Initiate/Stop speed, the default = 141.
 - Motor and compound unit: 1~921600 Ps/Sec.
 - Machine unit: 1~15300 (cm/Min, $\times 10$ Deg/Min, Inch/Min).

However, the limited frequency can't be greater than 921600 Ps/Sec.
- Parameter 6: Creep speed for machine zero return; the default is 1000.
 Motor and compound unit: 1~65535 Ps/Sec
 Machine unit: 1~15300 (cm/Min, $\times 10$ Deg/Min, Inch/Min).
- Parameter 7: Backlash compensation, the default =0.
 - Setting range: 0~32767 Ps.
 - While backward traveling, the traveling distance will be added with this value automatically.
- Parameter 8: Acceleration/Deceleration time setting, the default = 5000, and the unit is mS.
 - Setting range: 0~30000 mS.
 - The setting value represents the time required to accelerate from idle state up to limited speed state or decelerate from the limited speed state down to the idle state.
 - The acceleration/deceleration is constant slope depending on Parameter 4 / Parameter 8
 - When Parameter 12 = 0, Parameter 8 is the deceleration time
 - There will have the auto deceleration function for short stroke movement.
- Parameter 9: Rotation and zero return direction; the default is 0100H (Not used in linear interpolation mode)

b15	b8 b7	b0
SR+12	Para 9-1	Para 9-0

NC Positioning Instruction

FUN 141 MPARA	Instruction of Parameter Setting for Positioning Program	FUN 141 MPARA													
<ul style="list-style-type: none"> • Parameter 9-0: Rotation direction setting; the default is 0 Setting value =0, the present value increases while in forward pulse output; the present value decreases while in backward pulse output. Setting value =1, the present value decreases while in forward pulse output; the present value increases while in backward pulse output. • Parameter 9-1: Zero return direction setting; the default is 1 Setting value =0, direction in which the present value increases. Setting value =1, direction in which the present value decreases. <p>● Parameter 10: Forward movement compensation, the default = 0.</p> <ul style="list-style-type: none"> • Setting range: -32768~32767 Ps. • When it is in forward pulse output, it will automatically add with this value as the moving distance. <p>● Parameter 11: Backward movement compensation, the default =0.</p> <ul style="list-style-type: none"> • Setting range: -32768~32767 Ps. • When it is in backward pulse output, it will automatically add with this value as the moving distance. <p>● Parameter 12: Deceleration time setting, the default =0, and the unit is mS.</p> <ul style="list-style-type: none"> • Setting range: 0~30000 mS. • When Parameter 12 = 0, Parameter 8 is the deceleration time • When Parameter 12 ≠ 0, Parameter 12 is the deceleration time <p>● Parameter 13: Interpolation time constant; the default is 500.</p> <ul style="list-style-type: none"> • Setting range: 0~30000 mS. • Set the time required to achieve the speed specified by the program. (The initiate speed is always regarded as "0.") • This parameter is valid while interpolation control. <p>● Parameter 14: Pulse count/1-revolution, the default = 0.</p> <ul style="list-style-type: none"> • The pulse counts needed to turn the motor for one revolution • When Parameter 14 = 0, Parameter 1 is the setting for Pulse /Rev • When Parameter 14 ≠ 0, Parameter 14 is the setting for Pulse/Rev <p>● Parameter 15: I/O control interface for DRVZ; the default is FFFFFFFFH</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td style="width: 10%;"></td> <td style="width: 20%; text-align: center;">b15</td> <td style="width: 20%; text-align: center;">b8 b7</td> <td style="width: 20%; text-align: center;">b0</td> <td style="width: 20%;"></td> </tr> <tr> <td style="text-align: right;">SR+19</td> <td style="text-align: center;">Para 15-1</td> <td style="text-align: center;">Para 15-0</td> <td style="text-align: center;"></td> <td></td> </tr> <tr> <td style="text-align: right;">SR+20</td> <td style="text-align: center;">Para 15-3</td> <td style="text-align: center;">Para 15-2</td> <td style="text-align: center;"></td> <td></td> </tr> </table> <ul style="list-style-type: none"> • Parameter 15-0: Setting of DOG input (SR+19), it must be the input of the main unit b6~b0: Reference number of DOG input (0~15, it means X0~X15) b7=0: Contact A or Normal Open =1: Contact B or Normal Close b7~b0=FFH, without DOG input 		b15	b8 b7	b0		SR+19	Para 15-1	Para 15-0			SR+20	Para 15-3	Para 15-2		
	b15	b8 b7	b0												
SR+19	Para 15-1	Para 15-0													
SR+20	Para 15-3	Para 15-2													

FUN 141 MPARA	Instruction of Parameter Setting for Positioning Program	FUN 141 MPARA
<ul style="list-style-type: none"> ● Parameter 15-1: Setting of stroke limit input (SR+19) <ul style="list-style-type: none"> b14~b8: Reference number of limit input (0~125, it means X0~X125) b15 = 0 : Contact A or Normal Open = 1 ; Contact B or Normal Close b15~b8 = FFH, without limit input ● Parameter 15-2: Setting of PG0 signal input (SR+20), it must be the input of the main unit <ul style="list-style-type: none"> b6~b0: Reference number of PG0 input (0~15, it means X0~X15) b7= 0 : Start counting at front end of sensing DOG input b7= 1 ; Start counting at rear end of sensing DOG input b7~b0 = FFH, without PG0 input ● Parameter 15-3: Setting of CLR signal output (SR+20), it must be the output of the main unit <ul style="list-style-type: none"> b15~b8: Reference number of CLR output (0~23, it means Y0~Y23) b15~b8 =FFH, without CLR output ● Parameter 16: Machine zero point address; the default is 0. Setting range: -999999 ~ 999999 Ps ● Parameter 17: Number of zero point signals (Sensing of PG0 input); the default is 1. Setting range : 0~255 count 		
<p>The graph illustrates a trapezoidal motion profile. The vertical axis represents Speed and the horizontal axis represents Time. The profile starts at a low speed (Parameter 5 Initiate/Stop speed), rises linearly to a maximum speed (Parameter 4 : Max. speed) over a time interval defined by Parameter 8 Acceleration/Deceleration time setting. It then moves at a constant speed (Work speed) until it reaches the end of the cycle. The deceleration phase is identical to the acceleration phase, both taking Parameter 8 time.</p>		


. For reference with FUN140 instruction

NC Positioning Instruction

FUN 141
MPARA


Instruction of Parameter Setting for Positioning Program

FUN 141
MPARA



. For reference with FUN147 instruction

- ※ The parameter 13 of the axis with longest movement is used for acceleration and deceleration control for linear interpolation if each axis owns its own motion parameter table
- ※ Using the same motion parameter table (through FUN141 and give the same starting address of SR operand for each axis) for the simultaneous linear interpolation axes, it is the best way for multi-axis linear interpolation motion control

FUN 142 P PSOFF	Enforcing to Stop Pulse Output	FUN 142 P PSOFF
<u>Ladder symbol</u>	N: 0~3, enforces the assigned set number of Pulse Output to stop its output.	
		
Instruction Explanation		
<p>1. When stop control "EN" =1, or changes from 0→1(P instruction), this instruction will enforce the assigned set number of Pulse Output to stop its output.</p> <p>2. When applying in the process of return home , as the home has returned, it can immediately stop the pulse output by using this instruction, so as to make it stop at the same position every time when performing machine homing.</p>		
Program example		
		; When M0 changes from 0→1, it enforces the Ps0 to stop the pulse output.

NC Positioning Instruction

FUN 143 P PSCNV	Converting the Current Pulse Value to the Displaying Value (mm, Deg, Inch, PS)	FUN 143 P PSCNV																								
<p><u>Ladder symbol</u></p> <pre> M0 --- EN --- 143P.PSCNV Ps : [] D : [] </pre>	<p>Ps: 0~3; converting the assigned pulse position to mm (Deg, Inch, PS) which has the same unit as the set point, so as to make the current position displayed.</p> <p>D: Registers that store the current position after conversion. It uses 2 registers, e.g. D10 represents D10 (Low Word) and D11 (High Word) two registers.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Range</th> <th>HR</th> <th>DR</th> <th>ROR</th> <th>K</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Operand</td> <td>R0</td> <td>D0</td> <td>R5000</td> <td>2</td> </tr> <tr> <td>R3839</td> <td>D3999</td> <td>R8071</td> <td>256</td> </tr> <tr> <td>Ps</td> <td></td> <td></td> <td></td> <td>0~3</td> </tr> <tr> <td>D</td> <td>○</td> <td>○</td> <td>○*</td> <td></td> </tr> </tbody> </table>	Range	HR	DR	ROR	K	Operand	R0	D0	R5000	2	R3839	D3999	R8071	256	Ps				0~3	D	○	○	○*		
Range	HR	DR	ROR	K																						
Operand	R0	D0	R5000	2																						
	R3839	D3999	R8071	256																						
Ps				0~3																						
D	○	○	○*																							
<p>Instruction Explanation</p> <ol style="list-style-type: none"> When execution control "EN" =1 or changes from 0→1(P instruction), this instruction will convert the assigned current pulse position (PS) to be the mm (or Deg, Inch, or PS) that has the same unit as the set value, so as to make current position displaying. After the FUN140 and FUN 147 instructions have been performed, it will then be able to get the correct conversion value by executing this instruction. <p>Program Example</p> <pre> M0 --- EN --- 143P.PSCNV Ps : 0 D : D10 </pre> <p>; When M0=1, it converts the current pulse position of Ps0 (DR4088) to the mm (or Deg or Inch or PS) that has the same unit as the set value, and store it into the DD10 to make the current position displaying.</p>																										

FUN147 MHSPO	Multi-Axis High Speed Pulse Output	FUN147 MHSPO																																	
	<p><u>Ladder symbol</u></p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td rowspan="2">Range</td> <td>HR</td> <td>DR</td> <td>ROR</td> <td>K</td> </tr> <tr> <td>R0</td> <td>D0</td> <td>R5000</td> <td></td> </tr> <tr> <td rowspan="2">Operand</td> <td> </td> <td> </td> <td> </td> <td></td> </tr> <tr> <td>R3839</td> <td>D3999</td> <td>R8071</td> <td></td> </tr> <tr> <td>Gp</td> <td></td> <td></td> <td></td> <td>0~1</td> </tr> <tr> <td>SR</td> <td><input type="circle"/></td> <td><input type="circle"/></td> <td><input type="circle"/></td> <td></td> </tr> <tr> <td>WR</td> <td><input type="circle"/></td> <td><input type="circle"/></td> <td><input type="circle"/>*</td> <td></td> </tr> </table>	Range	HR	DR	ROR	K	R0	D0	R5000		Operand					R3839	D3999	R8071		Gp				0~1	SR	<input type="circle"/>	<input type="circle"/>	<input type="circle"/>		WR	<input type="circle"/>	<input type="circle"/>	<input type="circle"/> *		<p>Gp : Group number (0~1) SR : Starting register for positioning program (example explanation) WR : Starting register for instruction operation (example explanation). It controls 9 registers, which the other program cannot repeat in using.</p>
Range	HR		DR	ROR	K																														
	R0	D0	R5000																																
Operand																																			
	R3839	D3999	R8071																																
Gp				0~1																															
SR	<input type="circle"/>	<input type="circle"/>	<input type="circle"/>																																
WR	<input type="circle"/>	<input type="circle"/>	<input type="circle"/> *																																

Instruction Explanation

1. The FUN147 (MHSPO) instruction is used to support the linear interpolation for multi-axis motion control, it consists of the motion program written and edited with tex programming. We named every position point as a step (which includes output frequency, traveling distance, and transfer conditions). Every step of positioning point owns 15 registers for coding.
2. The FUN147 (MHSPO) instruction can support up to 4 axes for simultaneous linear interpolation; or 2 sets of 2-axis linear interpolation (i.e. Gp0 = Axes Ps0 & Ps1 ; Gp1 = Axes Ps2 & Ps3)
3. The best benefit to store the positioning program into the registers is that in the case of association with MMI (Man Machine Interface) to operate settings, it may save and reload the positioning program via MMI when replacing the molds.
4. When execution control "EN"=1, if the other FUN147/FUN140 instructions to control Ps0~3 are not active (corresponding status of Ps0=M1992, Ps1=M1993, Ps2=M1994, and Ps3=M1995 will be ON), it will start to execute from the next step of positioning point (when goes to the last step, it will be restarted from the first step to perform); if Ps0~3 is controlled by other FUN147/FUN140 instruction (corresponding status of Ps0=M1992, Ps1=M1993, Ps2=M1994, and Ps3=M1995 would be OFF), this instruction will acquire the pulse output right of positioning control once the controlling FUN147/FUN140 has released the control right.
5. When execution control input "EN" =0, it stops the pulse output immediately.
6. When output pause "PAU" =1 and execution control "EN" was 1 beforehand, it will pause the pulse output. When output pause "PAU" =0 and execution control is still 1, it will continue the unfinished pulse output.
7. When output abort "ABT"=1, it stops pulse output immediately. (When the execution control input "EN" becomes 1 next time, it will restart from the first step of positioning point to execute.)
8. While the pulse is in output transmitting, the output indication "ACT" is ON.
9. When there is execution error, the output indication "ERR" will be ON. (The error code is stored in the error code register.)
10. When each step of positioning point is complete, the output indication "DN" will be ON.

NC Positioning Instruction

FUN147 MHSPO	Multi-Axis High Speed Pulse Output	FUN147 MHSPO	
*** The working mode of Pulse Output must be set (without setting, Y0~Y7 will be treated as general output) to be one of U/D, or A/B mode, thus the Pulse Output may have a regular output.			
U/D mode : Y0 (Y2, Y4, Y6), it sends out upward counting pulse. Y1 (Y3, Y5, Y7), it sends out downward counting pulse.			
A/B mode : Y0 (Y2, Y4, Y6), it sends out the phase A pulse. Y1 (Y3, Y5, Y7), it sends out the phase B pulse.			
<ul style="list-style-type: none"> The output polarity for Pulse Output can select to be Normal ON or Normal OFF. 			
【The interfaces for positioning control】			
M1991	ON : Stop or pause FUN147, slow down then stop pulse output OFF : Stop or pause FUN147, stop pulse output immediately		
M1992	ON : Ps0 is ready OFF : Ps0 is in action		
M1993	ON : Ps1 is ready OFF : Ps1 is in action		
M1994	ON : Ps2 is ready OFF : Ps2 is in action		
M1995	ON : Ps3 is ready OFF : Ps3 is in action		
M1934	ON : Gp0 has finished the last step		
M1935	ON : Gp1 has finished the last step		
DR4068	Gp0 vector speed		
DR4070	Gp1 vector speed		
D4060	Gp0 error code		
D4061	Gp1 error code		
D4062	The step number (positioning point) which has been completed of Gp0.		
D4063	The step number (positioning point) which has been completed of Gp1.		
Ps No.	Current output frequency	Current pulse position	The remaining pulse counts to be transmitted
Ps0	DR4080	DR4088	DR4072
Ps1	DR4082	DR4090	DR4074
Ps2	DR4084	DR4092	DR4076
Ps3	DR4086	DR4094	DR4078
※ FUN147 doesn't support dynamic change for its output frequency during the pulse transmitting.			

FUN147 MHSPO	Multi-Axis High Speed Pulse Output	FUN147 MHSPO																																						
<ul style="list-style-type: none"> ● Format of positioning program with linear interpolation : <p>SR : Starting register of registers block which reserved to store positioning program, explained as follows :</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr><td style="text-align: right;">SR</td><td style="text-align: center;">A55CH</td><td>: The effective positioning program; its starting register must be A55CH</td></tr> <tr><td style="text-align: right;">SR+1</td><td style="text-align: center;">Total steps</td><td></td></tr> <tr><td style="text-align: right;">SR+2</td><td></td><td rowspan="15" style="vertical-align: middle; text-align: center;"> The first positioning point (step) of positioning program (every step owns 15 registers for coding). </td></tr> <tr><td style="text-align: right;">SR+3</td><td></td></tr> <tr><td style="text-align: right;">.</td><td style="text-align: center;">.</td></tr> <tr><td style="text-align: right;">SR+14</td><td></td></tr> <tr><td style="text-align: right;">SR+15</td><td></td></tr> <tr><td style="text-align: right;">SR+16</td><td></td></tr> <tr><td style="text-align: right;">.</td><td></td></tr> <tr><td style="text-align: right;">SR+Nx15+2</td><td></td><td style="vertical-align: bottom; text-align: center;"> The Nth step of positioning program. </td></tr> </table>			SR	A55CH	: The effective positioning program; its starting register must be A55CH	SR+1	Total steps		SR+2		The first positioning point (step) of positioning program (every step owns 15 registers for coding).	SR+3		SR+14		SR+15		SR+16			SR+Nx15+2		The Nth step of positioning program.
SR	A55CH	: The effective positioning program; its starting register must be A55CH																																						
SR+1	Total steps																																							
SR+2		The first positioning point (step) of positioning program (every step owns 15 registers for coding).																																						
SR+3																																								
.	.																																							
.	.																																							
.	.																																							
.	.																																							
SR+14																																								
SR+15																																								
SR+16																																								
.																																								
.																																								
.																																								
.																																								
.																																								
SR+Nx15+2			The Nth step of positioning program.																																					




NC Positioning Instruction

FUN147 MHSPO	Multi-Axis High Speed Pulse Output	FUN147 MHSPO																		
<ul style="list-style-type: none"> ● Explanation for working register of instruction operation : 																				
WR is the starting of working registers.																				
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%;">WR+0</td><td>Being executed or stopped step</td></tr> <tr> <td>WR+1</td><td>Working flag</td></tr> <tr> <td>WR+2</td><td>Controlled by system</td></tr> <tr> <td>WR+3</td><td>Controlled by system</td></tr> <tr> <td>WR+4</td><td>Controlled by system</td></tr> <tr> <td>WR+5</td><td>Controlled by system</td></tr> <tr> <td>WR+6</td><td>Controlled by system</td></tr> <tr> <td>WR+7</td><td>Controlled by system</td></tr> <tr> <td>WR+8</td><td>Controlled by system</td></tr> </table>			WR+0	Being executed or stopped step	WR+1	Working flag	WR+2	Controlled by system	WR+3	Controlled by system	WR+4	Controlled by system	WR+5	Controlled by system	WR+6	Controlled by system	WR+7	Controlled by system	WR+8	Controlled by system
WR+0	Being executed or stopped step																			
WR+1	Working flag																			
WR+2	Controlled by system																			
WR+3	Controlled by system																			
WR+4	Controlled by system																			
WR+5	Controlled by system																			
WR+6	Controlled by system																			
WR+7	Controlled by system																			
WR+8	Controlled by system																			
<p>WR+0 : If this instruction is in execution, the content of this register represents the step (1~N) being performed. If this instruction is not in execution, the content of this register represents the step where it stopped at present</p> <p>When execution control "EN" =1, it will perform the next step, i.e. the current step plus 1 (if the current step is at the last step, it will restart to perform from the first step).</p> <p>Before starting the execution control "EN" =1, the user can renew the content of WR+0 to determine starting from which step to perform (when the content of WR+0 =0, and execution control "EN" =1, it represents that the execution starts from the first step).</p>																				
<p>WR+1 : B0~B7, total steps</p> <p>B8 = ON, output paused</p> <p>B9 = ON, waiting for transfer condition</p> <p>B10 = ON, endless output</p> <p>B12 = ON, pulse output transmitting (the status of output indicator "ACT")</p> <p>B13 = ON, instruction execution error (the status of output indicator "ERR")</p> <p>B14 = ON, finished being executed step (the status of output indicator "DN")</p>																				
<p>*** When step which has been completed, the output indication "DN" will turn ON and keep such status if suspending ; the user may turn OFF the status of "DN" by using the rising edge of output coil controlled by "DN" to clear the content of WR+1 register to be 0, and it can be attained.</p>																				

FUN147 MHSPO	Multi-Axis High Speed Pulse Output	FUN147 MHSPO
<p>Error indication Error code</p> <p>R4060 (Ps0) 0 : Error free</p> <p>R4061 (Ps1) 1 : Parameter 0 error</p> <p>R4062 (Ps2) 2 : Parameter 1 error</p> <p>R4063 (Ps3) 3 : Parameter 2 error</p> <p>D4060 (Gp0) 4 : Parameter 3 error</p> <p>D4061 (Gp1) 5 : Parameter 4 error</p> <p> 6 : Parameter 5 error</p> <p> 7 : Parameter 6 error</p> <p> 8 : Parameter 7 error</p> <p> 9 : Parameter 8 error</p> <p> 10 : Parameter 9 error</p> <p> 13 : Parameter 12 error</p> <p> 14 : Parameter 13 error</p> <p> 15 : Parameter 14 error</p> <p> 30 : Error of variable address for speed setting</p> <p> 31 : Error of setting value for speed setting</p> <p> 32 : Error of variable address for stroke setting</p> <p> 33 : Error of setting value for stroke setting</p> <p> 34 : Illegal positioning program</p> <p> 35 : Length error of total step</p> <p> 36 : Over the maximum step</p> <p> 37 : Limited frequency error</p> <p> 38 : Initiate/stop frequency error</p> <p> 39 : Over range of compensation value for movement</p> <p> 40 : Over range of moving stroke</p> <p> 41 : ABS positioning is not allowed within DRVC commands</p> <p> 42 : DRVZ can't follow DRVC</p> <p> 50 : Illegal operation mod of DRVZ</p> <p> 51 : Illegal DOG input number</p> <p> 52 : Illegal PG0 input number</p> <p> 53 : Illegal CLR output number</p> <p> 60 : Illegal linear interpolation command</p>		<p>The possible error codes For FUN141 execution</p> <p>The possible error codes For FUN140 and FUN147 execution</p>

Note : The content of error indication register will keep the latest error code. Making sure that no more error to happen, you can clear the content of error indication register to be 0, and it still maintains the value at 0.

NC Positioning Instruction

FUN147 MHSPO	Multi-Axis High Speed Pulse Output	FUN147 MHSPO
Editing Servo Program Table with WinProladder		
Click the “Servo Program Table” item which in project window:		
		
		
<ul style="list-style-type: none">• Table Type: Multi-Axis positioning table• Table Name: For modify or debug, you can give a convenient name.• Table Starting address: Enter the address which Starting register		
		


FUN147 MHSPO	Multi-Axis High Speed Pulse Output	FUN147 MHSPO
<ul style="list-style-type: none"> For easy programming and trouble shooting, the WinProladder provides the text editing environment to edit the motion program (servo program table) for FUN147 execution. Extended positioning instructions for linear interpolation are listed as follows: 		
Instruction	Operand	Explanation
SPD	XXXXXX or Rxxxxx or Dxxxxx	<ul style="list-style-type: none"> Setting of the vector speed for linear interpolation $1 \leq \text{setting value} \leq 1840000$ Moving speed in frequency or velocity (FUN141 Parameter_0=0 represents velocity; Parameter_0=1 or 2 for frequency; the system default is frequency). The operand can be input directly with constant or variable (Rxxxxx, Dxxxx); when the operand is variable, it needs 2 registers, e.g. D10 represents D10 (Low Word) and D11 (High Word), which is the setting of frequency or velocity. When selecting to use the velocity setting, the system will automatically convert the velocity setting to corresponding output frequency The corresponding axis frequency for output will be calculate from the setting of the vector speed Output frequency range: $1 \leq \text{output frequency} \leq 921600 \text{ Hz}$.
LIN	ADR , X , Y , Z , W , Ut or ABS Ps Where, X : Stroke setting of Ps0 Y : Stroke setting of Ps1 Z : Stroke setting of Ps2 W : Stroke setting of Ps3	<ul style="list-style-type: none"> Moving stroke setting in Ps or mm,Deg,Inch (When FUN141 Parameter_0=1, the setting stroke in Ut is Ps; Parameter_0=0 or 2, the setting stroke in Ut is mm, Deg, Inch; the system default for Ut is Ps). When 6_th operand of LIN is Ut (not Ps) , according to the settings of parameter 1, 2, 3 of FUN141, the system will convert the corresponding pulse count to output. There are 6 operands to construct LIN instruction as follows: 1_st operand: coordinate selection. ADR or ABS: ADR, relative distance movement ABS, absolute position movement 2_nd~5_th operands: moving stroke setting for each axis XXXXXXX: or -XXXXXXX or Rxxxxx or Dxxxxx It can directly input with constant or variable (Rxxxxx, Dxxxx); it needs 2 registers when adopting the variable, e.g. R0 represents R0 (Low Word) and R1 (High Word) as the setting of moving stroke. Positive setting value moves forward Negative setting value moves backward *** When the setting of moving stroke is 0 or in space and 1_st operand is ADR, it means no movement for this axis *** When the setting of moving stroke is in space and 1_st operand is ABS, it means no movement for this axis Maximum setting for one movement must be under ± 1999999 Ps 6_th operand: resolution of stroke setting Ut or Ps: for Ut, the resolution is one unit (it is determined by parameter 0, 3 of FUN141); for Ps, the enforced resolution is one pulse.

NC Positioning Instruction

FUN147 MHSPO	Multi-Axis High Speed Pulse Output	FUN147 MHSPO
Instruction LINE	Operand ADR , X , Y , Z , W , Ut or ABS Where, X : Stroke setting of Ps0 Y : Stroke setting of Ps1 Z : Stroke setting of Ps2 W : Stroke setting of Ps3	Explanation <ul style="list-style-type: none"> •LINE is used for linear interpolation in endless movement •There are 6 operands to construct LINE instruction as LIN's Description •The stroke setting for each axis means the output ratio between the active axes, the axis with longest movement is followed by others i.e. In LINE mode, if the stroke settings are 1000·500·300·0(In Ps), it means if Ps0 axis sends 1000Ps, then Ps1 and Ps2 will send 500Ps and 300Ps respectively. (Axis Ps3 doesn't work due to the setting value is 0). It will follow this ratio (1000/500/300/0) for pulse output until the FUN147 instruction is stopped or exists from the LINE mode.

Note: Comparison explanation between the relative coordinate positioning (ADR) and the absolute coordinate positioning (ABS)

To move from position 30000 to -10000, the coding for programming is:



To move from position -10000 to 10000, the coding for programming is:

DRV ADR,+,20000,Ut or DRV ABS, ,10000,Ut

Instruction	Operand	Explanation
WAIT	TIME , XXXXX or Rxxxx or Dxxxx or X0~X255 or Y0~Y255 or M0~M1911 or S0~S999	<ul style="list-style-type: none"> • When pulse output is complete, performing the wait instruction to go to the assigned step. There are 5 kind of operands that explained as follows: <p>Time: The waiting time (the unit is 0.01 second), it can be directly input with constant or variable (Rxxxx or Dxxxx); when it is time up, performs the step that assigned by GOTO.</p> <p>X0~X255: Waiting until the input status is ON, it performs the step that assigned by GOTO.</p> <p>Y0~Y255:Waiting until the output status is ON, it performs the step that assigned by GOTO.</p> <p>M0~M1911: Waiting until the internal relay is ON, it performs the step that assigned by GOTO.</p> <p>S0~S999: Waiting until the step relay is ON, it performs the step that assigned by GOTO.</p>

FUN147 MHSPO	Multi-Axis High Speed Pulse Output	FUN147 MHSPO
-----------------	------------------------------------	-----------------

EXT	X0~X255 or Y0~Y255 or M0~M1911 or S0~S999	• External trigger instruction; when it is in pulse output (the number of pulses sending is not complete yet), if the status of external trigger is ON, it will perform the step assigned by GOTO immediately. If the status of external trigger is still OFF when the pulse output has been complete, it is the same as WAIT instruction; waiting the trigger signal ON, then perform the step assigned by GOTO.
GOTO	NEXT or 1~N or Rxxxx or Dxxxx	<ul style="list-style-type: none"> When matching the transfer condition of WAIT, ACT, EXT instruction, by using GOTO instruction to describe the step to be executed. <p>NEXT: It represents to perform the next step. 1~N : To perform the described number of step Rxxxx: The step to be performed is stored in register Rxxxx Dxxxx: The step to be performed is stored in register Dxxxx</p>
MEND		End of the positioning program.

- The editing for positioning programming with linear interpolation:

First, it must complete the FUN147 instruction before the editing of positioning program, and assigned in FUN147 instruction the starting register of registers block to store positioning program. While editing the positioning program, it will store the newly edited positioning program to the assigned registers block; for every one positioning point (called as one step) edited, it owns 15 registers for coding. If there are N positioning points, it will be used by $N \times 15 + 2$ registers in total.

Note: The registers storing the positioning program can not be repeated in using!

- Format and example for the positioning program with linear interpolation:

```

001 SPD      5000          ; Vector speed is 5KHz
    LIN      ADR,500,400,300,200,Ut   ; Moving forward 500(Ps0)/400(Ps1)/300(Ps2)/200(Ps3) units
    WAIT     TIME,100           ; Wait for 1second
    GOTO     NEXT             ; Perform the next step
002 SPD      R1000          ; Vector speed is stored in DR1000 ( R1001 and R1000 )
    LIN      ADR,D100,D200, , ,Ut ; Moving stroke is stored in DD100(Ps0) & DD200(Ps1)
    WAIT     TIME,R500         ; The waiting time is stored in R500
    GOTO     NEXT             ; To perform the next step
003 SPD      R1002          ; Vector speed is stored in DR1002 ( R1003 and R1002 )
    LIN      ADR,0,0,R300,R400,Ps  ; Moving stroke is stored in DR300(Ps2) & DR400(Ps3)
    WAIT     X0                ; Wait until X0 ON
    GOTO     1                 ; Perform the first step
  
```

NC Positioning Instruction


FUN147
MHSPO

Multi-Axis High Speed Pulse Output


FUN147
MHSPO

Example and figure for description

The positioning program with linear interpolation instruction as below:



It means the moving stroke setting for axis Ps0(X axis) is 1000 Ps, for axis Ps1(Y axis) is 500 Ps; both axes Ps2 and Ps3 are inactive due to the setting values are 0.




FUN148 MPG	Manual Pulse Generator For Positioning	FUN148 MPG																		
Execution EN	<p>148. MPG</p> <table border="1" style="margin-left: 20px; border-collapse: collapse;"> <tr> <td>Sc :</td> <td>ACT</td> <td>Sc : Source of high speed counter; 0~7</td> </tr> <tr> <td>Ps :</td> <td></td> <td>Ps : Axis of pulse output; 0~3</td> </tr> <tr> <td>Fo :</td> <td></td> <td>Fo : Setting of output speed (2 registers)</td> </tr> <tr> <td>Mr :</td> <td></td> <td>Mr : Setting of multiplier (2 registers)</td> </tr> <tr> <td>WR :</td> <td></td> <td>Mr+0 : Multiplicand (Fa) Mr+1 : Dividend (Fb)</td> </tr> <tr> <td></td> <td></td> <td>WR : Starting address of working registers, it needs 4 registers</td> </tr> </table> <p>* This instruction can be supported in PLC OS firmware V4.60 or later</p>	Sc :	ACT	Sc : Source of high speed counter; 0~7	Ps :		Ps : Axis of pulse output; 0~3	Fo :		Fo : Setting of output speed (2 registers)	Mr :		Mr : Setting of multiplier (2 registers)	WR :		Mr+0 : Multiplicand (Fa) Mr+1 : Dividend (Fb)			WR : Starting address of working registers, it needs 4 registers	
Sc :	ACT	Sc : Source of high speed counter; 0~7																		
Ps :		Ps : Axis of pulse output; 0~3																		
Fo :		Fo : Setting of output speed (2 registers)																		
Mr :		Mr : Setting of multiplier (2 registers)																		
WR :		Mr+0 : Multiplicand (Fa) Mr+1 : Dividend (Fb)																		
		WR : Starting address of working registers, it needs 4 registers																		

Range	HR	ROR	DR	K
Oper- and	R0	R5000	D0	16 bit
	— R3839	— R8071	— D3999	
Sc	○	○	○	0~7
Ps	○	○	○	0~3
Fo	○	○	○	
Mr	○	○	○	
WR	○	○*	○	

- Let this instruction be executed in 50mS fixed time interrupt service routine (50MSI) or by using the 0.1mS high speed timer to generate 50mS fixed time interrupt service to have accurate repeat time to sample the pulse input from manual pulse generator. If it comes the input pulses, it will calculate the number of pulses needing to output according to the setting of multiplier (Mr+0 and Mr+1), and then outputs the pulse stream in the speed of setting (Fo) during this time interval.
The setting of output speed (Fo) must be fast enough, and the acceleration / deceleration rate (Parameter 4 and parameter 8 of FUN141 instruction) must be sharp to guarantee it can complete the sending of pulse stream during the time interval if it is under high multiplier (100 or 200 times) situation.
- When execution "EN"=1, this instruction will sample the pulse input from manual pulse generator by reading the current value of assigned high speed counter every time interval; it doesn't have any output if it doesn't have any input pulse; but If it senses the input pulses, it will calculate the number of pulses needing to output according to the setting of multiplier (Mr+0 and Mr+1), and then outputs the pulse stream in the speed of setting (Fo) during this time interval.
Number of output pulses = (Number of input pulses × Fa) / Fb
- This instruction also under the control of hardware resource management; it wouldn't be executed if the hardware is occupied.
- The output indicator ACT=1 if it outputs the pulses; otherwise ACT=0.

The diagram illustrates the timing of the instruction execution. It shows two 50mS intervals. In each interval, there are two parallel vertical arrows pointing from left to right. The top arrow is labeled "Sample pulse input". The bottom arrow is labeled "Output pulse stream in the speed of Fo". Between the two 50mS intervals, there is a horizontal ellipsis (...).

NC Positioning Instruction



FUN148 MPG	Manual Pulse Generator For Positioning	FUN148 MPG
---------------	--	---------------

Status Monitoring											
Ref. No.	Status	Data	Ref. No.	Status	Data	Ref. No.	Status	Data	Ref. No.	Status	Data
DR4080	Decimal	0	DR4082	Decimal	0	D800	Decimal	0	D810	Decimal	2
DR4088	Decimal	114200	DR4090	Decimal	21000	D801	Hexdecim	0100H	D811	Hexdecim	0001H
DR2005	Decimal	200000	DR2105	Decimal	200000	DR4096	Decimal	11703	DD802	Decimal	11703
R2011	Decimal	30	R2111	Decimal	30				M100	Enable	ON
DD600	Decimal	200000	DD602	Decimal	200000	D700	Decimal	100	D701	Decimal	1
M500	Enable	ON	M501	Enable	OFF	X34	Enable	OFF			
X32	Enable	ON	X33	Enable	OFF	X35	Enable	OFF	X36	Enable	ON

[StatusPage0](#) [StatusPage1](#)

X32 : Select axis 0(Ps0)

X33 : Select axis 1 (Ps1)

X34 : Multiplier = 1

X35 : Multiplier = 10

X36 : Multiplier = 100

M100 : Enable / disable MPG activity

DR2005 : Maximum speed of axis 0(Parameter 4 of FUN141) ; 200K Hz

R2011 : Acc/Dec time of axis 0(Parameter 8 of FUN141) ; 30mS

DD600 : Output speed of axis 0 for MPG; 200K Hz

DR2105 : Maximum speed of axis 1 (Parameter 4 of FUN141) ; 200K Hz


R2111 : Acc/Dec time of axis 1 (Parameter 8 of FUN141); 30mS

DD602 : Output speed of axis 1 for MPG; 200K Hz


Description : Let the MPG instruction (FUN148) be executed in 50mS fixed time interrupt service routine (50MSI) to handle the MPG positioning of Ps0 and Ps1. When X32=1 and M100=1, it will handle the MPG positioning of Ps0; it will sample the pulse input from reading the current value of HSC0 every 50mS time interval; it doesn't have any output if it doesn't have any input pulse; but If it senses the input pulses, it will calculate the number of pulses needing to output according to the setting of multiplier (D700 and D701), and then outputs the pulse stream in the speed of setting (DD600) during this time interval.

.Number of output pulses = (Number of input pulses from HSC0 × D700) / D701

NC Positioning Instruction



FUN148 MPG	Manual Pulse Generator For Positioning	FUN148 MPG
---------------	--	---------------



X32 : Select axis 0 (Ps0)

X33 : Select axis 1 (Ps1)

X34 : Multiplier = 1

X35 : Multiplier = 10

X36 : Multiplier = 100

M100 : Enable/disable MPG activity

DR2005 : Maximum speed of axis 0 (Parameter 4 of FUN141) ; 200K Hz

R2011 : Acc/Dec time of axis 0 (Parameter 8 of FUN141); 30mS

DD600 : Output speed of axis 0 for MPG; 200K Hz

DR2105 : Maximum speed of axis 1 (Parameter 4 of FUN141) ; 200K Hz

R2111 : Acc/Dec time of axis 1 (Parameter 8 of FUN141); 30mS

DD602 : Output speed of axis 1 for MPG; 200K Hz

Description : By using the 0.1mS high speed timer to generate 50mS fixed time interrupt service (HSTAI) to handle the MPG positioning of Ps0 and Ps1. When X33=1 and M100=1, it will handle the MPG positioning of Ps1; it will sample the pulse input from reading the current value of HSC0 every 50mS time interval; it doesn't have any output if it doesn't have any input pulse; but If it senses the input pulses, it will calculate the number of pulses needing to output according to the setting of multiplier (D700 and D701), and then outputs the pulse stream in the speed of setting (DD602) during this time interval.

.Number of output pulses = (Number of input pulses from HSC0 × D700) / D701

NC Positioning Instruction


FUN148 MPG	Manual Pulse Generator For Positioning	FUN148 MPG
<p>Manual Pulse Generator(FUN148 , MPG) instruction supports most left/right limitation for positioning control</p> <ul style="list-style-type: none"> . High byte value of R4020 ≠ 55H, not support this function ; . High byte value of R4020 = 55H, bits of low byte are used for most left/right limitation <p>R4020_b15...b8=55H ,</p> <p>R4020_b0=1 , not allowed forward movement of Ps0</p> <p>R4020_b1=1 , not allowed backward movement of Ps0</p> <p>R4020_b2=1 , not allowed forward movement of Ps1</p> <p>R4020_b3=1 , not allowed backward movement of Ps1</p> <p>R4020_b4=1 , not allowed forward movement of Ps2</p> <p>R4020_b5=1 , not allowed backward movement of Ps2</p> <p>R4020_b6=1 , not allowed forward movement of Ps3</p> <p>R4020_b7=1 , not allowed backward movement of Ps3</p> <p>. Program example</p>		

11.7 Machine Homing

The machine set which undertakes relative model Encoder as shifting detector usually need the reset action for the reference of positioning coordinate; we called this action as machine homing (seeking for zero reference).

The machine homing diagram for NC servo unit is as follows:

Method 1:




Z phase counting is up, the pulse output stops, then send out the CLR signal to clear the error counter of servo driver.

e.g.:

X3: Near home sensing input is configured as interrupt input; in the case of machine homing, it starts HSC4 to begin counting in X3+ interrupt service subroutine.

X2: Z phase counting input, it is configured as UP input of HSC4; the X2+ is prohibited to interrupt in regular time, when executing machine homing and X3 near home interrupt occurred, it starts HSC4 to begin Z phase counting. When HSC4 counting is up, it stops the pulse output, prohibit the X2+ interrupt, set home position to signal, and sends out the CLR signal to clear the error counter of servo driver. Please consult program example.

Method 2: According to application demand, it may slow down when encountering the near home sensor, while over the sensor a little far away, stop the pulse output, and then traveling slowly with backward direction; the very moment when it get out of near home sensor (the sensing signal changes from 1→0), it is treated as machine home. This program is simpler!



X3: Near home sensing input; it is configured as falling edge interrupt input.


- Once encountering the near home sensor, it will enable X3 falling edge interrupt, and slow down to stop within the near home sensing range.
- Slowly backward traveling until the near home sensing signal changes from 1→0.
- When the near home sensing signal changes from 1→0, it performs the X3- interrupt service subroutine immediately.
- The X3- interrupt service subroutine: Stops the pulse output immediately, prohibits the X3- interrupt, sets home position to signal, and sends out CLR signal to clear the error counter of servo driver. (Please consult the example program.)

Program Example 1: Machine homing (method 1)


X2: Configured as the UP input of HSC4, and connected to Z phase input.

X3: Configured as the rising edge interrupt input, and connected to near home sensing input.

Main Program




【Sub Program】




Program Example 2: Machine homing (method 2)

X3: Connected to near home sensing input, and configured as falling edge interrupt input.

【Main Program】



【Sub Program】



The above two machine homing examples are implemented by using Ladder program; although it is not difficult to understand, but it's a bit cumbersome to use, which might be inconvenient for users. Since FATEK is taking into account the customer's utility and convenience, we add machine zero return command (DRVZ) in high-speed pulse output instruction (FUN140), which provides 3 modes (MD0~MD2) of operation for different application requirement, of FBs series PLC system version (OS) V4.32 (including) or later versions.


When using DRVZ command for machine homing, it should conjoining the FUN141 motion parameter's setting of machine zero related, it can be listed as below:

	DRVZ MD0	DRVZ MD1	DRVZ MD2
Parameter 6 (Creep speed)	Must be	Must be	Must be
Parameter 9-1 (Return direction)	Must be	Must be	Must be
Parameter 15-0 (DOG input)	Must be	Must be	Must be
Parameter 15-1 (Limit input)	Optional	Optional	Optional
Parameter 15-2 (PG0 input)	No need	No need	Must be
Parameter 15-3 (CLR output)	Optional	Optional	Optional
Parameter 16 (Zero point address)	Must be	Must be	Must be
Parameter 17 (No. of PG0 signal)	No need	No need	Must be

The FUN 140 instruction can't be executed for machine zero return while encountering the following situations with the error indications:


	Error Code	Explanation
R4060(PS0) R4061(PS1) R4062(PS2) R4063(PS3)	42	DRVZ can't follow DRVC
	50	Illegal operation mode of DRVZ
	51	Illegal DOG input
	52	Illegal PG0 input
	53	Illegal CLR output

The method of using DRVZ is same as the method of two modes (DRV and DRVC) of FUN140. To see the details please choose MD0~MD2 of Movement Action mode of the servo program table in the project window (See below).



Zero return (DRVZ) operation in detailed diagram description


Mode 0



【Description】

1. Zero return starts behind the DOG sensor (Parameter 15_0)
 - a. Moving forward to zero direction in Zero Return Speed
 - b. Changing the moving speed by Creep Speed (Parameter 6) while sensing the dog sensor (Edge detection and interrupt processing)
 - c. Keeping forward until leaving the dog sensor (Edge detection and interrupt processing), it is the zero home position
 - d. If it doesn't configure the CLR output (Parameter 15_3) for servo driver, the zero return process has been finished at step c.
 - e. If it has been configured the CLR output (Parameter 15_3) for servo driver, the zero return process will be finished after the CLR output with more than 20mS duration
2. Zero return starts at or in front of the DOG sensor (Parameter 15_0) + Stroke limit sensor (Parameter 15_1)
 - a. Moving forward to zero direction in zero return speed, there will stop moving while sensing the limit sensor
 - b. Moving backward in zero return speed and after leaving the dog sensor, it will drive the zero return procedures same as mentioned above 1.


Mode 1



【Description】

1. Zero return starts behind the DOG sensor (Parameter 15_0)
 - a. Moving forward to zero direction in Zero Return Speed
 - b. Auto slow down to stop movement while sensing the dog sensor (Edge detection and interrupt processing)
 - c. Delay 0.5 second, then moving backward until leaving the dog sensor (Edge detection and interrupt processing), it is the zero home position
 - d. If it doesn't configure the CLR output (Parameter 15_3) for servo driver, the zero return process has been finished at step c
 - e. If it has been configured the CLR output (Parameter 15_3) for servo driver, the zero return process will be finished after the CLR output with more than 20mS duration
2. Zero return starts at or in front of the DOG sensor (Parameter 15_0) + Stroke limit sensor (Parameter 15_1)
 - a. Moving forward to zero direction in zero return speed, there will stop moving while sensing the limit sensor
 - b. Moving backward in zero return speed and after leaving the dog sensor, it will drive the zero return procedures same as mentioned above 1.


Mode 2 (Front edge counting)



【Description】

1. Zero return starts behind the DOG sensor (Parameter 15_0)
 - a. Moving forward to zero direction in Zero Return Speed
 - b. Changing the moving speed by Creep Speed (Parameter 6) while sensing the dog sensor (Edge detection and interrupt processing), and start counting (Edge detection and interrupt processing) the PG0 signal (Parameter 15_2)
 - c. While the counting value of PG0 signal is equal to the present value (Parameter 17), it is the zero home position
 - d. If it doesn't configure the CLR output (Parameter 15_3) for servo driver, the zero return process has been finished at step c
 - e. If it has been configured the CLR output (Parameter 15_3) for servo driver, the zero return process will be finished after the CLR output with more than 20mS duration
 2. Zero return starts at or in front of the DOG sensor (Parameter 15_0) + Stroke limit sensor (Parameter 15_1)
 - a. Moving forward to zero direction in zero return speed, there will stop moving while sensing the limit sensor
 - b. Moving backward in zero return speed and after leaving the dog sensor, it will drive the zero return procedures same as mentioned above 1.
- * Working at this mode, it should be noticed to adjust the correct position of dog sensor to incorporate with PG0 signal to avoid one count PG0 error for zero return processing

Mode 2 (Rear edge counting)




【Description】

1. Zero return starts behind the DOG sensor (Parameter 15_0)
 - a. Moving forward to zero direction in Zero Return Speed
 - b. Changing the moving speed by Creep Speed (Parameter 6) while sensing the dog sensor (Edge detection and interrupt processing); keeping forward and start counting (Edge detection and interrupt processing) the PG0 signal (Parameter 15_2) while leaving the dog sensor
 - c. While the counting value of PG0 signal is equal to the present value (Parameter 17), it is the zero home position
 - d. If it doesn't configure the CLR output (Parameter 15_3) for servo driver, the zero return process has been finished at step c
 - e. If it has been configured the CLR output (Parameter 15_3) for servo driver, the zero return process will be finished after the CLR output with more than 20 mS duration
2. Zero return starts at or in front of the DOG sensor (Parameter 15_0) + Stroke limit sensor (Parameter 15_1)
 - a. Moving forward to zero direction in zero return speed, there will stop moving while sensing the limit sensor
 - b. Moving backward in zero return speed and after leaving the dog sensor, it will drive the zero return procedures same as mentioned above 1.

*Working at this mode, it should be noticed to adjust the correct position of dog sensor to incorporate with PG0 signal to avoid one count PG0 error of zero return processing

The above three homing completion modes assume that starting point is nearly the right side of DOG sensor. But when implementing homing action, the starting point is possible located after DOG sensor or exactly located on DOG sensor. The following diagram and description are interpreted the homing action of two locations:


Zero return starts at or in front of the DOG sensor



Steps

1. When homing operation has started, it moves toward the homing direction (Parameter 9_1) in zero return speed until strokes the switch of limit input point (Parameter 15_1).
2. When it strokes the limit input point (Parameter 15_1), it immediately moving backward to the homing direction until leave the DOG sensor (sensor signal from 1 → 0).
3. Upon completion of the Step 2, you can determine that the starting point has returned back to the right of DOG sensor, and then it will complete the homing operation as we set the homing mode (MD0~MD2) earlier.

Program Example 3 : Machine homing (by using Mode 2 of DRVZ command)



- M1924 initial/end pulse set the parameter of the servo parameter command into the system.
- Clears FUN140 homing completing signal.
- Homing operation has started.
- FUN140 operates DRVZ command.

Servo Parameter Table(FUN141) Setting

Servo Parameter Table - [mpara0]			
Calculator(C)		Setup(S)	
R500	0.Unit :	1:Pulse	R513 10.+ Movement Compensation : 0 Ps
R501	1.Pulse/Rev.(16Bit):	2000	R514 11.- Movement Compensation : 0 Ps
DR502	2.Distance/Rev. :	2000	R515 12.Dec. Time : 0 mS
R504	3.Min. Unit :	2	R516 13.Interpolation Time Constant: 500 mS
DR505	4.Max. Speed :	460000	DR517 14.Pulse/Rev.(32Bit): 0
DR507	5.Start/End Speed :	141	R519_LB 15_0.DOG Input: Normal Oper 2 (X2)
R509	6.Creep Speed:	1000	R519_HB 15_1.Stroke Input: Normal Closi 40 (X40)
R510	7.Backlash Compensation :	0	R520_LB 15_2.PGO Input: P.Edge Cou 4 (X4)
R511	8.Acc./Dec. Time :	5000	R520_HB 15_3.CLR Output: Usage 8 (Y8)
R512_LB	9_0.Direction Control :	0:Up	DR521 16.Machine Zero Point: 100 Ps
R512_HB	9_1.Zero Return Direction:	1:Down(Left)	R523 17.PGO Count: 10
Allow: 3340 words(Auto) Used: 24 words Position: R500-R523			
<input type="button" value="Reset To Default"/>		<input checked="" type="button" value="OK"/> <input type="button" value="Cancel"/>	


Servo Program Table(FUN140) Setting



Program Description:

- (1). When the program has been executed, the initial pulse (M1924) will set the starting address of servo parameters table.
- (2). When M0 is from 0→1 (P instruction), the self-holding loop M1 has started and at the same time FUN140 homing operation has also started.
- (3). According to FUN140 the servo program table setting, first the speed toward to homing return direction (left) is 5000 until it touches the DOG points (X2), it immediately drops the speed to 1000 and starts PG0 counting.
- (4). When zero signal counting (X4) has reached its setting value 10, it finds the home position. Zero clear signal (Y8) sent to "ON" more than 20mS and as well as the machine zero position value, set to 100, moves to current register. (In this example we use 0 axis, then set the value 100 to DR4088), then the homing operation has completed.


Diagram



※ When set the DOG point, it should be the input points (X0~X15) of main unit.

※ When the input DOG point has been set, it cannot be conflict with interrupt and high-speed counter, for example: if X0 has been set for DOG point, then X0 cannot be set to an interrupt input or high-speed counter.

Program Example 4: JOG Forward




- Clears the completion signal

- Starts from the first step every jog execution.

- As the execution of last step completed, it sets up the completion signal.

Program Example 5: JOG Backward




- Clears the completion signal.

- Starts from the first step every jog execution.

- As the execution of the last step completed, it sets up the completion signal.

Program Example 6: Step by step, One cycle, Continuous positioning control.

M93 : Start
 M101 : Step by step operation mode
 M102 : One cycle operation mode
 M103 : Continuous operation mode
 M104 : Regular shut down.
 M105 : Emergency stop.



- Clears shut down signal.
- Clears the error signal.
- Clears the step completion signal.
- Except step by step mode, the step pointer is cleared to be 0; it starts from the first step to execute.
- Clears being active bit of FUN140

- Set up the shut down signal.