DUP Series HMI Connection Manual

Jetter JC Series PLC

HMI Factory Setting:


Baud rate: 9600. 8. Even. (RS232)

Controller Station Number: 0 (no PLC station number in protocol, one on one connection)

Control Area / Status Area: WR0/WR10

Connection





Definition of PLC Read/Write Address

a. Registers

Туре	Format Word No. (n)	Read/Write Range	Data Length	Note
16 Bits Register	WRn	WR 0 – WR 32767	16 Bits	CV.34
32 Bits Register	Rn	R 0 – R 32767	24 Bits	

b. Contacts

Туре	Format Word No. (n) Bit No. (b)	Read/Write Range	Note
Input Relay	Inbb	1101 - 13216	VCV.
Output Relay	O nbb	O 101 - O 3216	
Flag Relay	Fb	F0 - F32767	VC